

## 1 Introduction to Transport Equations

A solid body will remain stationary or in motion at constant velocity unless acted on by external forces. When acted on by external forces, the momentum of a solid body will change according to Newton's second law. For a solid body with constant mass, Newton's second law can be written concisely in differential form as:

$$\mathbf{F} = m\mathbf{a} \quad \rightarrow \quad \mathbf{F} = m \frac{d\mathbf{v}}{dt} \quad (1)$$

where  $\mathbf{F}$  is the sum of the forces acting on the body,  $\mathbf{v}$  is the velocity of the body,  $m$  is the mass of the body and bold symbols represent vector quantities. If the mass of the solid body changes with time, then equation 1 becomes:

$$\mathbf{F} = \frac{d(m\mathbf{v})}{dt} \quad (2)$$

Hence, Newton's second law physically states that the rate of change of momentum (mass multiplied by velocity), is equal to the sum of the external forces acting on the body. The solid body velocity ( $\mathbf{v}$ ) is a vector quantity. In a Cartesian coordinate system, the solid body velocity can be resolved into components in the  $x$ ,  $y$  and  $z$  directions ( $\mathbf{v} = (v_x, v_y, v_z)$ ). Hence, when written in vector form, Newton's second law is a compact way of expressing three individual equations for the change of momentum of the body in the  $x$ ,  $y$  and  $z$  directions.

$$F_x = \frac{d(mv_x)}{dt} \quad F_y = \frac{d(mv_y)}{dt} \quad F_z = \frac{d(mv_z)}{dt} \quad (3)$$

If the mass of the object and the forces acting on it are known, then Newton's second law can be solved to calculate the velocity ( $\mathbf{v}$ ) of the object at a given time. The equations are solved by integration. In the same way that the velocity of a solid body can be calculated by solving Newton's second law, the velocity of a fluid (liquid or gas) can be calculated by solving the *Navier-Stokes* equations. The Navier-Stokes equations are analogous to Newton's second law and state that the rate of change of momentum of a fluid is equal to the sum of the external forces acting on the fluid. However, the Navier-Stokes equations are applied to a parcel/finite volume of fluid rather than a solid body.


Figure 1 shows an example of a fluid parcel/volume that forms a part of the fluid continuum. The parcel has a volume  $V$  and can be any size. In concise vector form, the Navier-Stokes equations can be written as:

$$\frac{D(m\mathbf{U})}{Dt} = \mathbf{F} \quad (4)$$


where  $m$  is the mass of the fluid parcel,  $\mathbf{U}$  is the velocity of the fluid parcel and  $\mathbf{F}$  is the sum of the external forces acting on a fluid parcel. Note the similarities between this form of the Navier-Stokes equations and Newton's second law for a solid body (equation 2). It is standard practice to divide the Navier-Stokes equations by the volume of the fluid parcel, as this is constant. This simplification leads to:

$$\frac{D(\rho\mathbf{U})}{Dt} = \mathbf{f} \quad (5)$$

where  $\rho$  is the fluid density and  $\mathbf{f}$  is the sum of the external forces per unit volume, acting on the fluid parcel. In the same manner that Newton's second law can be solved by integration to



**Figure 1:** A finite parcel/volume of fluid that forms a part of the fluid continuum.



**Figure 2:** Calculating the flow of air over a wing allows the lift and drag forces acting on the wing to be calculated.


calculate the velocity of a solid body, the Navier-Stokes equations can be solved to calculate the velocity (motion) of the fluid. Once the velocity of the fluid has been determined, the forces acting on the solid surfaces that are in contact with the fluid can be computed. For example, solving the Navier-Stokes equations for the flow of air around a wing allows pressure and skin friction forces acting on the wing to be calculated (see Figure 2). These forces generate lift and drag and allow the plane to fly. Hence, solving the Navier-Stokes equations numerically (for real geometries) is of considerable interest to scientists and engineers. Solving the Navier-Stokes equations numerically will be the focus of this fundamentals course.

## Fluid Acceleration

In the Navier-Stokes equation (equation 5), the change in momentum of the fluid parcel has been written as:

$$\frac{D(\rho\mathbf{U})}{Dt} \quad (6)$$

where  $D/Dt$  is the *total derivative*. The total derivative has been used instead of the temporal derivative ( $d/dt$ ) in the Navier-Stokes equation. The reason for this change is the fluid volume may change its momentum in *time* and also change its momentum as it moves through *space*. For example, consider the flow of water through a garden hose (Figure 3), which is held at a constant flow rate. The overall flow rate of water will be constant with time if the tap is kept open at the same setting. However, the water accelerates (in space) as it moves into the nozzle. As time advances while the water moves through space, the water experiences an acceleration in time as it moves through the nozzle. The total derivative can be expanded to show the change in time and the change in space. Adopting a Cartesian coordinate system for the spatial dimensions ( $x$ ,  $y$  and  $z$ ):



**Figure 3:** The flow of water through a garden hose. The water accelerates as it moves through the nozzle due to the contraction. Even if the global flow does not change in time, a fluid parcel accelerates in time as it moves through the nozzle due to the contraction.

$$\frac{D}{Dt} = \underbrace{\frac{\partial}{\partial t}}_{\text{Time}} + \underbrace{U_x \frac{\partial}{\partial x} + U_y \frac{\partial}{\partial y} + U_z \frac{\partial}{\partial z}}_{\text{Space}} \quad (7)$$

The first term represents the change in momentum in time and the second, third and fourth terms represent the change in momentum in the  $x$ ,  $y$  and  $z$  spatial directions respectively, as the fluid parcel is convected through the flow field. In vector form, the total derivative can be written compactly as:

$$\frac{D}{Dt} = \frac{\partial}{\partial t} + \mathbf{U} \cdot \nabla \quad (8)$$

By using the expanded form of the total derivative, the Navier-Stokes equations can be written:

$$\frac{\partial(\rho\mathbf{U})}{\partial t} + \mathbf{U} \cdot \nabla(\rho\mathbf{U}) = \mathbf{f} \quad (9)$$

Equation 9 can be simplified slightly by applying conservation of mass and the product rule. For conciseness, the details are not included here.


$$\frac{\partial(\rho\mathbf{U})}{\partial t} + \nabla \cdot (\rho\mathbf{U}\mathbf{U}) = \mathbf{f} \quad (10)$$

While the Navier-Stokes equations have been expanded and rewritten, their physical interpretation remains the same. The change in momentum of a fluid parcel in time is equal to the sum of the forces acting on the fluid parcel.

### External Forces

Depending on the flow condition, a variety of external forces may act to change the momentum of a fluid. Three of the most common forces that act to change the momentum of fluids are pressure, viscosity and gravity. These terms are included in the Navier-Stokes equations as forces (per unit volume) on the right hand side of the equation:

$$\frac{\partial(\rho\mathbf{U})}{\partial t} + \nabla \cdot (\rho\mathbf{U}\mathbf{U}) = \underbrace{-\nabla p}_{\text{Pressure}} + \underbrace{\nabla \cdot \boldsymbol{\tau}}_{\text{Shear Stress}} + \underbrace{\rho\mathbf{g}}_{\text{Gravity}} \quad (11)$$



**Figure 4:** The flow of cold air over a hot plate, cooling the plate.

where  $p$  is the static pressure (normal stress),  $\tau$  is the shear stress (which includes the action of viscosity) and  $\mathbf{g}$  is the acceleration due to gravity. All of the terms on the right hand-side represent forces acting on the fluid parcel, while the terms on the left hand-side represent the acceleration of the fluid parcel in response to the forces. Physically, the equations state that pressure, gravity and viscosity all act to change the momentum of the fluid ( $\rho\mathbf{U}$ ). By solving the equations numerically, the velocity of the fluid can be computed in response to these forces. Once the equations are solved, the forces acting on the solid surfaces that contact the fluid can be computed.

In this course, the *Finite Volume Method* will be examined, which is the most popular method for solving the Navier-Stokes equations numerically. By following this course, you will develop an understanding of the fundamentals of how the finite volume method can be used to solve the Navier-Stokes and other transport equations.

## Transport Equations


In addition to solving the Navier-Stokes equations to determine the fluid velocity ( $\mathbf{U}$ ), additional equations may need to be solved, depending on the application. For example, the fluid flow may be used to cool a hot surface, as shown in Figure 4. In this instance, the fluid transports heat away from the surface, cooling the surface. In order to determine rate of cooling of the hot surface by the fluid, the temperature (and velocity) of the fluid need to be computed. For air or water cooling at low velocity (incompressible flow), the following equation can be solved to compute the temperature  $T$  of the fluid:

$$\frac{\partial(\rho c_p T)}{\partial t} + \underbrace{\nabla \cdot (\rho c_p \mathbf{U} T)}_{\text{Convection}} = \underbrace{\nabla \cdot (k \nabla T)}_{\text{Diffusion}} + S \quad (12)$$

where  $c_p$  is the specific heat capacity of the fluid,  $k$  is the thermal conductivity of the fluid and  $S$  is a heat source (per unit fluid volume). This type of equation is called a *transport equation*, as the temperature (representing the thermal energy of the fluid) is transported by the motion of the fluid ( $\mathbf{U}$ ).

Thermal energy is transported through the fluid by two main mechanisms: convection and diffusion. Thermal energy is also transported by radiation, but this will not be considered here. The mathematical form of the convective and diffusive transport mechanisms are highlighted in equation 12. Diffusion represents the physical process where thermal energy moves from areas of high temperature to areas of low temperature due to the temperature gradient (see Figure 5). The diffusion of heat takes the following mathematical form:

$$\nabla \cdot (k \nabla T) \quad \equiv \quad \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) + \frac{\partial}{\partial z} \left( k \frac{\partial T}{\partial z} \right) \quad (13)$$



**Figure 5:** Heat diffuses from regions of high temperature to regions of low temperature. This diffusion is represented mathematically by  $\nabla \cdot (k\nabla T)$ .

The thermal conductivity  $k$  gives the strength of diffusion. A highly conductive material (such as copper) will transfer significant quantities of heat with a small temperature gradient. On the other hand, thermal insulators (like oven gloves) have low thermal conductivity  $k$  and will transmit relatively little heat, even with a large temperature gradient.

Diffusion occurs in moving and stationary fluids, hence it does not depend on the velocity of the fluid  $\mathbf{U}$ . Diffusion is often referred to as conduction, when applied to solids. In a stationary fluid where the velocity  $\mathbf{U} = 0$ , the convection term is zero and the temperature equation reduces to:

$$\frac{\partial(\rho c_p T)}{\partial t} = \underbrace{\nabla \cdot (k\nabla T)}_{\text{Diffusion}} + S \quad (14)$$

Convection of heat is the transport of thermal energy by the motion (velocity) of the fluid. It has the following mathematical form:

$$\nabla \cdot (\rho c_p \mathbf{U} T) \quad \equiv \quad \frac{\partial}{\partial x} (\rho c_p T U_x) + \frac{\partial}{\partial y} (\rho c_p T U_y) + \frac{\partial}{\partial z} (\rho c_p T U_z) \quad (15)$$

The thermal energy is physically transported by the motion of the moving fluid ( $\mathbf{U}$ ). This is similar to the transport of leaves and branches that are dropped into a moving river. The leaves and branches are physically transported by the motion of the fluid and are carried along with the river. Convection increases the rate of heat transfer and is the reason why blowing over the surface of a hot drink reduces its temperature, so that we can drink it!


## Other Transport Equations

A variety of quantities that are transported by fluids follow a similar transport equation to the temperature/thermal energy equation. One example is the injection of dye or fine solid particles into a flow stream, as shown in Figure 6. The particles will be convected by the fluid and will also diffuse from areas of high concentration to low concentration. Hence, the concentration  $C$  of dye/solid particles follows a similar transport equation to temperature:

$$\frac{\partial(\rho C)}{\partial t} + \underbrace{\nabla \cdot (\rho \mathbf{U} C)}_{\text{Convection}} = \underbrace{\nabla \cdot (D \nabla C)}_{\text{Diffusion}} + S_c \quad (16)$$

where  $D$  is the diffusivity of the dye/solid particles. The transport equations that govern the convection and diffusion of quantities in a fluid flow (velocity, temperature, concentration etc.) all share the same common form:

$$\frac{\partial(\rho \phi)}{\partial t} + \nabla \cdot (\rho \mathbf{U} \phi) = \nabla \cdot (\Gamma \nabla \phi) + S_\phi \quad (17)$$



**Figure 6:** The concentration of dye/solid particles diffuses from regions of high concentration to regions of low concentration. This diffusion is represented mathematically by  $\nabla \cdot (D\nabla C)$

where  $\phi$  is a transported quantity (velocity, temperature, concentration etc.),  $\rho$  is the fluid density,  $\Gamma$  is the diffusivity of the quantity and  $S_\phi$  is the additional source per unit volume of the quantity  $\phi$ . In this course, the finite volume method will be used to solve a general transport equation that includes convection, diffusion and a source term. As the governing equations of fluid flow all share the same general form, the same method can then be applied to any transport equation (velocity, temperature, concentration etc.) that is required.

In the three remaining chapters in this course, the finite volume method will be applied to a transport equation for temperature. Temperature has been chosen specifically in this course, as it is conceptually the most straightforward quantity to understand while applying the method. The same techniques applied in this course can then be applied to any transported quantity of interest, by following the same analysis steps. The diffusion and source terms will be considered first, to develop a general understanding of the method. The convection term will then be added in the third chapter of this course, allowing the effects of diffusion and convection to be studied simultaneously. In the fourth chapter of this course, a special technique called *upwind differencing* will be introduced. This technique is essential to solve the majority of convection-diffusion equations and is adopted by all modern CFD codes.

## 2 The 1D Diffusion Equation

In the previous chapter, the convection-diffusion equation for the transport of temperature (thermal energy) was introduced.

$$\frac{\partial(\rho c_p T)}{\partial t} + \nabla \cdot (\rho c_p \mathbf{U} T) = \nabla \cdot (\kappa \nabla T) + S \quad (18)$$

In this chapter, the transport equation for temperature will be solved for the limited case of one-dimensional (1D) steady-state diffusion. This limited case will be used to introduce the finite volume method and demonstrate how it works. The same approach can also be applied to other transport equations (momentum, species concentration, turbulence etc.). Temperature has been specifically chosen for this chapter, as it is conceptually the most straightforward to follow and understand. In the next chapter, the one-dimensional steady-state diffusion example will be extended to also include convection. Starting with the three-dimensional (3D) transport equation for thermal energy (temperature), the temporal derivative and the convection term will be neglected in this chapter.

$$\cancel{\frac{\partial(\rho c_p T)}{\partial t}} + \cancel{\nabla \cdot (\rho c_p \mathbf{U} T)} = \nabla \cdot (\kappa \nabla T) + S \quad (19)$$

$$0 = \nabla \cdot (\kappa \nabla T) + S \quad (20)$$

Expand the gradient ( $\nabla$ ) and dot product ( $\nabla \cdot$ ) operators in Cartesian coordinates:

$$0 = \frac{\partial}{\partial x} \left( \kappa \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( \kappa \frac{\partial T}{\partial y} \right) + \frac{\partial}{\partial z} \left( \kappa \frac{\partial T}{\partial z} \right) + S \quad (21)$$

For one-dimensional diffusion, the  $y$  and  $z$  derivatives are zero.


$$0 = \frac{\partial}{\partial x} \left( \kappa \frac{\partial T}{\partial x} \right) + \cancel{\frac{\partial}{\partial y} \left( \kappa \frac{\partial T}{\partial y} \right)} + \cancel{\frac{\partial}{\partial z} \left( \kappa \frac{\partial T}{\partial z} \right)} + S \quad (22)$$

$$\boxed{0 = \frac{d}{dx} \left( k \frac{dT}{dx} \right) + S} \quad (23)$$


Equation 23 is the 1D steady-state heat diffusion equation. This equation will be solved using the *finite-volume method*, which is the most common approach used by modern CFD codes. The finite volume method can also be applied to more detailed equations and is not limited to one dimensional analysis. However, one dimensional flow has been specifically selected here to illustrate the principals of the method clearly.

Equation 23 is a differential equation (not an algebraic equation). Hence, the solution of this equation requires integration and the application of boundary conditions. Rather than integrate the equation over the entire domain of interest, the first stage in the finite volume method is to integrate the equation over a small piece of the domain. This piece is called a finite volume or parcel of fluid. Figure 7 shows an example of a finite volume of fluid, which forms a part of the continuum of fluid. Remember that the differential equation is valid for every finite volume of fluid in the domain, regardless of the size of the volume and its location. Mathematically, the integration process is described as:

$$\int_V \left[ \frac{d}{dx} \left( k \frac{dT}{dx} \right) + S \right] dV = 0 \quad (24)$$



**Figure 7:** A finite volume of fluid, which has been isolated from the fluid continuum.



**Figure 8:** A 1D finite volume of fluid with volume  $V$ , which has been isolated from the bar.

The integration of each term can be considered separately, as addition and integration are commutative operations (it does not matter which order they are carried out in).

$$\int_V \left[ \frac{d}{dx} \left( k \frac{dT}{dx} \right) \right] dV + \int_V [S] dV = 0 \quad (25)$$

In one-dimension, the control volume forms a part of a one-dimensional geometry, as shown in Figure 8. This control volume can be thought of as a piece of a bar that is conducting heat from one-end to the other, with constant properties over its cross-section. The second term in equation 25 represents the heat source generated in the finite volume. Assume that the heat source is constant across the control volume, with a value of  $\bar{S}$  (the volume average heat source). The second term in the finite volume integral can now be simplified.


$$\int_V \left[ \frac{d}{dx} \left( k \frac{dT}{dx} \right) \right] dV + \bar{S} \int_V dV = 0 \quad (26)$$

$$\int_V \left[ \frac{d}{dx} \left( k \frac{dT}{dx} \right) \right] dV + \bar{S}V = 0 \quad (27)$$


The source term  $\bar{S}$  has units of  $W/m^3$ . Hence, the product  $\bar{S}V$  has units of  $W$ .

The first term in equation 25 is the volume integral of the heat diffusion inside the control volume. To simplify and evaluate this term, the *divergence theorem* is required. Physically, the divergence theorem states that the rate of accumulation of a vector field inside a control volume is equal to the flux of the vector field across the surfaces of the control volume. When applied to the heat diffusion equation, this theorem can be thought of as an expression of conservation of energy. Heat accumulating inside the control volume by diffusion must cross the surfaces of the control volume if there are no additional sources of heat in the volume,





**Figure 9:** A diagram to show the physical significance of the divergence theorem applied to vector field  $\mathbf{A}$ . The accumulation of  $\mathbf{A}$  in the volume equals the flux of  $\mathbf{A}$  over the surfaces of the volume.



**Figure 10:** A diagram to show the face normal vectors on the left and right faces of the 1D cell. The cell normal vectors always point out of the cell.

as shown in Figure 9. Mathematically, the divergence theorem for a general vector field  $\mathbf{A}$  is written as:

$$\int_V (\nabla \cdot \mathbf{A}) dV = \int_A (\mathbf{A} \cdot \hat{\mathbf{n}}) dA \quad (28)$$

$$\int_V \left( \frac{\partial A_x}{\partial x} + \frac{\partial A_y}{\partial y} + \frac{\partial A_z}{\partial z} \right) dV = \int_A (A_x n_x + A_y n_y + A_z n_z) dA \quad (29)$$

where  $\hat{\mathbf{n}}$  is the unit normal vector pointing out of the control volume and  $A$  is the surface area of the control volume. In 1D, the divergence theorem can be written:

$$\int_V \left( \frac{dA_x}{dx} \right) dV = \int_A (A_x \hat{n}_x) dA \quad (30)$$

For the 1D heat diffusion equation  $\mathbf{A} = k\nabla T$ . Hence  $A_x = k dT/dx$ . Applying the 1D divergence theorem to the 1D heat diffusion equation leads to:

$$\int_A \left( \kappa \frac{dT}{dx} n_x \right) dA + \bar{S}V = 0 \quad (31)$$

Physically, equation 31 states that the flux of heat out of the cell by diffusion must balance the heat generated within the cell. To simplify this equation further, consider the 1D cell in Figure 10. The cell has a left face  $l$  and a right face  $r$ . Lower-case letters  $l$  and  $r$  are used in this course to refer to the left and right faces of the cell, while upper-case  $L$  and  $R$  are used to refer to the centroids of the neighbour cell that are on the left and right of the cell under consideration. The flow quantities (temperature, thermal conductivity etc.) are constant on the cell face. Hence, the first integral can be simplified:

$$\left( \kappa \frac{dT}{dx} n_x \right) \int_A dA + \bar{S}V = 0 \quad (32)$$



**Figure 11:** A comparison of interior cells (a) and boundary cells (b) in the mesh.

$$\left(k \frac{dT}{dx} n_x A\right)_r + \left(k \frac{dT}{dx} n_x A\right)_l + \bar{S}V = 0 \quad (33)$$

As shown in Figure 10,  $n_x$  is positive on the right face and negative on the left face. Hence:

$$\left(kA \frac{dT}{dx}\right)_r - \left(kA \frac{dT}{dx}\right)_l + \bar{S}V = 0 \quad (34)$$

This simplified form of the 1D heat-diffusion equation is valid for all cells in the mesh. However, it cannot be solved yet numerically, as the equation is written in terms of variables on the cell faces ( $l$  and  $r$ ). In the cell-centred finite volume method, the equation is solved in terms of variables at the cell centroids ( $L$ ,  $R$  and  $P$ ). To carry out the necessary simplification, *interior cells* and *boundary cells* need to be considered separately. As shown in Figure 11, interior cells are in the interior of the geometry and are connected to other cells. However, boundary cells are connected to a boundary of the domain (such as an inlet or wall) on one or more of their faces. In the sections that follow, the interior and boundary cells will be considered separately when simplifying equation 34.

### Interior Cells

Start with the general finite volume discretisation of the 1D heat-diffusion equation.

$$\left(kA \frac{dT}{dx}\right)_r - \left(kA \frac{dT}{dx}\right)_l + \bar{S}V = 0 \quad (35)$$

To simplify and solve this equation for the interior cells, the temperature gradient on the cell faces ( $l$  and  $r$ ) need to be expressed in terms of temperatures at the cell centroids ( $L$ ,  $R$  and  $P$ ). This simplification can be accomplished with linear interpolation, which is often called *central-differencing*. To help understand this simplification, remember that the spatial gradient of temperature can be thought of as:


$$\frac{dT}{dx} \sim \frac{\Delta T}{\Delta x} = \frac{\text{Change in Temperature}}{\text{Distance}} \quad (36)$$

As shown in Figure 12, the temperature gradient on the left face can be expressed using central differencing as:

$$\left(\frac{dT}{dx}\right)_l = \frac{T_P - T_L}{d_{LP}} \quad (37)$$

where  $d_{LP}$  is the distance between the cell centroids  $L$  and  $P$ . In a similar manner, the temperature gradient on the right face can also be expressed using central differencing:

$$\left(\frac{dT}{dx}\right)_r = \frac{T_R - T_P}{d_{PR}} \quad (38)$$



**Figure 12:** Central differencing (linear interpolation) of the temperature gradient on the left face of the cell using the values at the cell centroids of the interior cell ( $T_P$ ) and the left cell ( $T_L$ ).

Substitute this simplification into the 1D heat-diffusion equation (equation 35).

$$\left(k_r A_r \frac{T_R - T_P}{d_{PR}}\right) - \left(k_l A_l \frac{T_P - T_L}{d_{LP}}\right) + \bar{S}V = 0 \quad (39)$$

The 1D diffusion equation can now be solved for the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ). To simplify this process, rearrange the equation and collect the terms in terms of temperature of the interior cell ( $T_P$ ), temperature of the left cell ( $T_L$ ) and the temperature of the right cell ( $T_R$ ).

$$T_P \left(\frac{k_l A_l}{d_{LP}} + \frac{k_r A_r}{d_{PR}}\right) = T_L \left(\frac{k_l A_l}{d_{LP}}\right) + T_R \left(\frac{k_r A_r}{d_{PR}}\right) + \bar{S}V \quad (40)$$

For convenience, introduce the notation  $D = k/d$ . This quantity can be thought of as the diffusive flux of heat per unit area through the cell face and has units of  $W/m^2K$ .

$$T_P (D_l A_l + D_r A_r) = T_L (D_l A_l) + T_R (D_r A_r) + \bar{S}V \quad (41)$$

For consistency with other equations that will be introduced later, write the above equation in the following form:

$$a_p T_P = a_L T_L + a_R T_R + S_u \quad (42)$$


$$T_P \underbrace{(D_l A_l + D_r A_r + 0)}_{a_p} = T_L \underbrace{(D_l A_l)}_{a_L} + T_R \underbrace{(D_r A_r)}_{a_R} + \underbrace{\bar{S}V}_{S_u} \quad (43)$$

Hence, the following coefficients can be identified. These coefficients will be compared with other formulations of the convection-diffusion equation in the next two chapters.

$$a_p = a_L + a_R - S_p \quad a_L = D_l A_l \quad a_R = D_r A_r \quad (44)$$

$$S_p = 0 \quad S_u = \bar{S}V \quad (45)$$

At this stage, we now have an algebraic equation for the temperature at the centroid of the cell  $T_P$ . This is the unknown in the equation that we want to solve for. However, the temperature of the cells on the left and right of this cell ( $T_L$  and  $T_R$ ) are also unknown. To overcome this difficulty, one equation will be written for every cell in the mesh, with the unknown of each equation being the temperature of that cell centroid  $T_P$ . Each of these equations is coupled to the equations of the cells on the left and right of the cell through the variables  $T_L$  and  $T_R$ , as shown in equation 43. Before proceeding to assemble and solve these equations, separate treatment is required for the boundary cells.



**Figure 13:** The left boundary cell with temperature  $T_P$  at its centroid. The shared face between the boundary cell and the right cell is at a temperature  $T_r$  and the wall has a temperature  $T_l = T_A$ .

### Boundary Cell (Left)

Figure 13 shows the boundary cell at the left end of the bar. The cell is connected to the boundary (wall) at the left face, where a fixed temperature  $T_A$  is applied. The finite volume discretisation of the 1D heat-diffusion equation (equation 34) is:

$$\left(kA \frac{dT}{dx}\right)_r - \left(kA \frac{dT}{dx}\right)_l + \bar{S}V = 0 \quad (46)$$

The right face of the boundary cell is connected to an interior cell. Hence, the same central differencing scheme for the temperature gradient from the previous section can be used. However, the left face is connected to a boundary. As shown in Figure 13, the temperature gradient term for the left face is:

$$\left(\frac{dT}{dx}\right)_l = \frac{T_P - T_A}{d_{LP}/2} \quad (47)$$

The factor of  $1/2$  is required as the distance from the cell centroid to the face is  $1/2$  of  $d_{LP}$  (the distance from the cell centroid to the cell centroid of the adjacent cell). The finite volume discretisation of the 1D heat-diffusion equation for the left boundary cell is now:

$$\left(k_r A_r \frac{T_R - T_P}{d_{PR}}\right) - \left(k_l A_l \frac{T_P - T_A}{d_{LP}/2}\right) + \bar{S}V = 0 \quad (48)$$

Again, introduce the notation  $D = k/d$  for the diffusive heat flux per unit area.

$$T_P (2D_l A_l + D_r A_r) = T_R (D_r A_r) + T_A (2D_l A_l) + \bar{S}V \quad (49)$$


For consistency with the interior cell, write in the following form:

$$a_p T_P = a_L T_L + a_R T_R + S_u \quad (50)$$

$$T_P \underbrace{(0 + D_r A_r + 2D_l A_l)}_{a_p} = T_L \underbrace{(0)}_{a_L} + T_R \underbrace{(D_r A_r)}_{a_R} + \underbrace{T_A (2D_l A_l) + \bar{S}V}_{S_u} \quad (51)$$

For comparison with the interior cell, the boundary cell (left) has the following coefficients:

$$a_L = 0 \quad a_R = D_r A_r \quad a_p = a_L + a_R - S_p \quad (52)$$



**Figure 14:** The right boundary cell with temperature  $T_P$  at its centroid. The shared face between the boundary cell and the left cell is at a temperature  $T_l$  and the boundary has a temperature  $T_r = T_B$ .

$$S_P = -2D_l A_l \quad S_u = T_A(2D_l A_l) + \bar{S}V \quad (53)$$

Comparing these coefficients with the coefficients for the interior cell, it can be seen that the left coefficient  $a_L$  is zero. This makes sense physically, because the boundary cell is not connected to another cell on the left. The influence of the boundary condition is introduced into the equation through the source terms  $S_p$  and  $S_u$ .

### Boundary Cell (Right)

The boundary cell on the right of the domain is shown in Figure 14. The cell is connected to the boundary at the right face, where a fixed temperature  $T_B$  is applied. The finite volume discretisation of the 1D heat-diffusion equation from equation 34 is:

$$\left(kA \frac{dT}{dx}\right)_r - \left(kA \frac{dT}{dx}\right)_l + \bar{S}V = 0 \quad (54)$$

The left face of the boundary cell is connected to an interior cell. Hence, the same face interpolation schemes from the previous section can be used. However, the right face is connected to a boundary. As shown in Figure 14, the temperature gradient term for the right face is:

$$\left(\frac{dT}{dx}\right)_r = \frac{T_B - T_P}{d_{PR}/2} \quad (55)$$

The factor of  $1/2$  is required as the distance from the cell centroid to the face is  $1/2$  of  $d_{PR}$  (the distance from the cell centroid to the cell centroid of the adjacent cell). The finite volume discretisation of the 1D heat-diffusion equation is now:


$$\left(k_r A_r \frac{T_B - T_P}{d_{PR}/2}\right) - \left(k_l A_l \frac{T_P - T_L}{d_{LP}}\right) + \bar{S}V = 0 \quad (56)$$

Again, introduce the notation  $D = k/d$  for the diffusive heat flux per unit area.

$$T_P (D_l A_l + 2D_r A_r) = T_L (D_l A_l) + T_B (2D_r A_r) + \bar{S}V \quad (57)$$

For consistency with the interior cell, write in the standard form:

$$a_p T_p = a_L T_L + a_R T_R + S_u \quad (58)$$



**Figure 15:** An example of the meshing process, where a 1D bar is divided into 5 cells/finite volumes. Cell 1 and cell 5 are boundary cells, whereas cells 2, 3 and 4 are interior cells.

$$T_P \underbrace{(D_l A_l + 0 + 2D_r A_r)}_{a_p} = T_L \underbrace{(D_l A_l)}_{a_L} + T_R \underbrace{0}_{a_R} + \underbrace{T_B (2D_r A_r)}_{S_u} + \bar{S}V \quad (59)$$

For comparison with the interior cell, the boundary cell (right) has the following coefficients:

$$a_L = D_l A_l \quad a_R = 0 \quad a_p = a_L + a_R - S_p \quad (60)$$

$$S_P = -2D_r A_r \quad S_u = T_B (2D_r A_r) + \bar{S}V \quad (61)$$

## Summary of Coefficients

A summary of the finite volume coefficients is provided in the table below for interior and boundary cells. Notice that the boundary cells have zero contribution from the cells that would extend outside of the domain. The boundary conditions are introduced through the source terms  $S_u$  and  $S_p$ .

	$a_L$	$a_R$	$a_P$	$S_p$	$S_u$
Boundary (L)	0	$D_r A_r$	$a_L + a_R - S_p$	$-2D_l A_l$	$T_A (2D_l A_l) + \bar{S}V$
Interior	$D_l A_l$	$D_r A_r$	$a_L + a_R - S_p$	0	$\bar{S}V$
Boundary (R)	$D_l A_l$	0	$a_L + a_R - S_p$	$-2D_r A_r$	$T_B (2D_r A_r) + \bar{S}V$

## Meshing the Geometry

Before solving the finite volume equations, the physical geometry of interest needs to be divided into discrete cells/ volumes. This process is called *meshing* and is the most significant part of the CFD solution process because the quality of the mesh affects the accuracy and stability of the solution. The meshing process will not be examined here, as the primary aim of this course is the implementation of the finite volume method. An ideal quadrilateral mesh will be used for the 1D geometry, as shown in Figure 15. In the next section, the set of finite volume equations will be assembled for the all cells in the mesh.

## Write an Equation for Every Cell in the Mesh

Conceptually, the next stage in the finite volume method is to construct an equation for every cell in the mesh individually. The equation written for each cell is coupled to the equations

written for the neighbours of that cell. As an example, consider a 1D mesh with 5 cells, as shown in Figure 15. Cell 1 is the left boundary cell and cell 5 is the right boundary cell. Cells 2, 3 and 4 are interior cells. The individual finite volume equations are:

Cell 1	Boundary Cell (Left)	$a_{p1}T_1 = a_{R1}T_2 + S_{u1}$
Cell 2	Interior Cell	$a_{p2}T_2 = a_{L2}T_1 + a_{R2}T_3 + S_{u2}$
Cell 3	Interior Cell	$a_{p3}T_3 = a_{L3}T_2 + a_{R3}T_4 + S_{u3}$
Cell 4	Interior Cell	$a_{p4}T_4 = a_{L4}T_3 + a_{R4}T_5 + S_{u4}$
Cell 5	Boundary Cell (Right)	$a_{p5}T_5 = a_{L5}T_4 + S_{u5}$

where the coefficients  $a_p, a_L, a_R$  and  $S_u$  are given in the summary in the previous section. Notice that the interior cells are coupled to the temperature of the cells on the left and right hand side of them. In contrast, the boundary cells are only coupled to the temperature of a single cell centroid (the interior cell that they are in contact with). The boundary conditions enter the equations through the source terms  $S_u$ .

### Assemble the Matrices

To assemble the matrices, rearrange the equations by bringing all the temperature terms to the left hand side. Leave the source terms on the right hand side.

Cell 1	Boundary Cell (Left)	$a_{p1}T_1 - a_{R1}T_2 = S_{u1}$
Cell 2	Interior Cell	$-a_{L2}T_1 + a_{p2}T_2 - a_{R2}T_3 = S_{u2}$
Cell 3	Interior Cell	$-a_{L3}T_2 + a_{p3}T_3 - a_{R3}T_4 = S_{u3}$
Cell 4	Interior Cell	$-a_{L4}T_3 + a_{p4}T_4 - a_{R4}T_5 = S_{u4}$
Cell 5	Boundary Cell (Right)	$-a_{L5}T_4 + a_{p5}T_5 = S_{u5}$


Add additional zero values for the missing temperatures in each equation.

Cell 1	Boundary Cell (Left)	$a_{p1}T_1 - a_{R1}T_2 + 0T_3 + 0T_4 + 0T_5 = S_{u1}$
Cell 2	Interior Cell	$-a_{L2}T_1 + a_{p2}T_2 - a_{R2}T_3 + 0T_4 + 0T_5 = S_{u2}$
Cell 3	Interior Cell	$0T_1 - a_{L3}T_2 + a_{p3}T_3 - a_{R3}T_4 + 0T_5 = S_{u3}$
Cell 4	Interior Cell	$0T_1 - a_{L3}T_2 + a_{p3}T_3 - a_{R3}T_4 + 0T_5 = S_{u3}$
Cell 5	Boundary Cell (Right)	$0T_1 + 0T_2 + 0T_3 - a_{L5}T_4 + a_{p5}T_5 = S_{u5}$

Write the equations in matrix form:

$$\begin{bmatrix} a_{p1} & -a_{R1} & 0 & 0 & 0 \\ -a_{L2} & a_{p2} & -a_{R2} & 0 & 0 \\ 0 & -a_{L3} & a_{p3} & -a_{R3} & 0 \\ 0 & 0 & -a_{L4} & a_{p4} & -a_{R4} \\ 0 & 0 & 0 & -a_{L5} & a_{p5} \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} S_{u1} \\ S_{u2} \\ S_{u3} \\ S_{u4} \\ S_{u5} \end{bmatrix} \quad \mathbf{AT} = \mathbf{B} \quad (62)$$

which is the standard form used in linear algebra. Commercial CFD solvers populate the matrices by calculating the coefficients ( $a_l, a_p$  and  $a_r$ ) automatically for the user and then solve the matrix equations. In the next section, the entire process will be demonstrated with an example problem. A mesh will be defined, the coefficients will be calculated and then the matrices will be constructed and solved.



**Figure 16:** An example problem to demonstrate 1D heat-diffusion in a bar.

### Example Problem: Heat Diffusion in a Bar

Consider 1D steady-state diffusion of heat in a bar, as shown in Figure 16. The bar has a length of 5m, a cross-sectional area of 0.1 m<sup>2</sup> and a thermal conductivity of 100 W/mK. The temperature at the left end of the bar ( $T_A$ ) is 100°C and the temperature at the right end ( $T_B$ ) is 200°C. There is a constant heat source of 1000 W/m<sup>3</sup> in the bar. The temperature field in the bar is governed by the 1D steady-state diffusion equation.

$$\frac{d}{dx} \left( k \frac{dT}{dx} \right) + S = 0 \quad (63)$$

### Step 1: Divide the Geometry into a Mesh

For the example in Figure 16, divide the geometry into a mesh of 5 cells of equal length. The length of each cell ( $L_{\text{cell}}$ ) is given by:

$$L_{\text{cell}} = \frac{L}{N} = \frac{5}{5} = 1\text{m} \quad (64)$$

Because the cells are uniformly distributed and have equal size, the distance between cell centroids  $d$  is equivalent to the length of the cells. Hence:

$$d_{LP} = d_{PR} = d = 1\text{m} \quad (65)$$

### Step 2: Assign Material Properties

The thermal conductivity  $k$  and the cross-sectional area  $A$  are the same for every cell in the mesh. Hence, the parameter  $DA$  is given by:

$$DA = \frac{kA}{d} = \frac{100 * 0.1}{1} = 10 \text{ [W/K]} \quad (66)$$

$$D_l A_l = D_r A_r = DA = 10 \text{ [W/K]} \quad (67)$$

The heat source per unit volume in each cell is given by:

$$\bar{S}V = \bar{S}AL_{\text{cell}} = 1000 * 0.1 * 1 = 100 \text{ [W]} \quad (68)$$



### Step 3: Calculate Matrix Coefficients

Now calculate the coefficients required to assemble the matrices. The most straightforward way is to fill in the table of coefficients:

	$a_L$	$a_R$	$S_p$	$S_u$	$a_p$
Boundary (Left)	0	10	-20	2100	30
Interior	10	10	0	100	20
Boundary (Right)	10	0	-20	4100	30

### Step 4: Assemble the Matrices

Assign the coefficients to their correct location in the matrix.

$$\begin{bmatrix} 30 & -10 & 0 & 0 & 0 \\ -10 & 20 & -10 & 0 & 0 \\ 0 & -10 & 20 & -10 & 0 \\ 0 & 0 & -10 & 20 & -10 \\ 0 & 0 & 0 & -10 & 30 \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} 2100 \\ 100 \\ 100 \\ 100 \\ 4100 \end{bmatrix} \quad (69)$$

### Step 5: Solve the Equations

Now that the matrices have been assembled, the matrix equation can be solved with an appropriate *iterative method*. An iterative method (such as Gauss-Seidel or Pre-conditioned Conjugate Gradient) is usually chosen by modern CFD codes, as the equations are usually too large for a *direct method* (like Gaussian Elimination) to be feasible. For example, a mesh with 1 million cells will require the solution of a matrix equation with 1 million unknowns. This is not feasible to solve in a reasonable time with a direct method. In this course, different algorithms to solve the matrix equation  $\mathbf{AT} = \mathbf{B}$  will not be considered, as details can be found in any comprehensive text on linear algebra. The default solvers for linear algebra will be used instead.

### Run the Example Problem Yourself!

Now, open either the Excel spreadsheet, the Python source code or the MATLAB source code and solve the problem yourself.

Excel	<code>solve1DDiffusionEquation.xlsx</code>
Python	<code>solve1DDiffusionEquation.py</code>
MATLAB	<code>solve1DDiffusionEquation.m</code>

Examine the calculation of the coefficients, the assembly of the matrices and run the code. You can even try changing some of the geometric and material properties of the problem


(such as the thermal conductivity or the length of the bar) and examine the changes in the solution.

### Results

The blue circles in Figure 17 show the temperature variation in the 1D bar computed with the CFD code. The dashed line shows the analytical solution of the 1D heat diffusion equation with a constant heat source ( $S$ ) which is given by:

$$T = T_A + \frac{x}{L} (T_B - T_A) + \frac{S}{2k} x (L - x) \quad (70)$$

As shown in Figure 17 (a), there is a small error between the CFD solution and the analytical solution. This is because the finite volume method assumes a *linear variation* between cells, whereas the analytical solution (for this flow scenario) is quadratic in nature. To reduce the error in the CFD solution, the mesh needs to be refined by increasing the number of cells. Figure 17 (b) shows the CFD solution of the same problem, with the number of cells increased from 5 to 20. The error in the CFD solution is reduced. However, the computational cost of the simulation has increased significantly. Hence, for practical CFD applications, a careful balance must be made between increased accuracy and increased cost of the simulations.



**Figure 17:** Temperature variation along the 1D bar for a mesh of (a) 5 cells and (b) 20 cells.

### 3 The Convection-Diffusion Equation

In the previous chapter, the steady-state diffusion equation for heat transfer was analysed.

$$0 = \nabla \cdot (k\nabla T) + S \quad (71)$$

In this chapter, the analysis will be extended to also include convective heat transfer. The steady-state equation for convective and diffusive heat transfer is:

$$\nabla \cdot (\rho c_p \mathbf{U} T) = \nabla \cdot (k\nabla T) + S \quad (72)$$

Following the same steps as the previous chapter, integrate the equation over a control volume  $V$ .

$$\int_V \nabla \cdot (\rho c_p \mathbf{U} T) dV = \int_V \nabla \cdot (k\nabla T) dV + \int_V S dV \quad (73)$$

Recall the divergence theorem from the previous chapter. For a vector field  $\mathbf{A}$ :

$$\int_V (\nabla \cdot \mathbf{A}) dV = \int_A (\mathbf{A} \cdot \hat{\mathbf{n}}) dA \quad (74)$$

Apply the divergence theorem to the convection term and the diffusion term.

$$\int_A ((\rho c_p \mathbf{U} T) \cdot \hat{\mathbf{n}}) dA = \int_A ((k\nabla T) \cdot \hat{\mathbf{n}}) dA + \int_V S dV \quad (75)$$

In the same manner as the previous chapter, the analysis will only be considered in 1D (the  $x$  direction).

$$\int_A (\rho c_p U_x T) n_x dA = \int_A k \frac{dT}{dx} n_x dA + \int_V S dV \quad (76)$$

Take the volume average of the source term over the control volume ( $\bar{S}$ ):

$$\int_A (\rho c_p U_x T) n_x dA = \int_A k \frac{dT}{dx} n_x dA + \bar{S} V \quad (77)$$


As shown in Figure 18, the 1D cells have two faces: a left face ( $l$ ) and a right face ( $r$ ). The surface integrals can be evaluated directly on the left and right faces of the cell as the fluid properties are constant across the face of the cell.

$$[\rho c_p U T n_x A]_r + [\rho c_p U T n_x A]_l = \left[ k \frac{dT}{dx} n_x A \right]_r + \left[ k \frac{dT}{dx} n_x A \right]_l + \bar{S} V \quad (78)$$


The unit normal vectors always point out of the cell. Hence  $n_x = -1$  on the left face and  $n_x = 1$  on the right face.

$$\underbrace{[\rho c_p U T A]_r - [\rho c_p U T A]_l}_{\text{Convection}} = \underbrace{\left[ k A \frac{dT}{dx} \right]_r - \left[ k A \frac{dT}{dx} \right]_l}_{\text{Diffusion}} + \bar{S} V \quad (79)$$

This simplified form of the equation is valid for all cells in the mesh. However, it cannot be solved yet numerically, as the equation is written in terms of variables on the cell faces ( $l$  and  $r$ ). In the cell-centred finite volume method, the equation is solved in terms of variables at the cell centroids ( $L$ ,  $R$  and  $P$ ). Hence, further simplification is necessary. To carry out the simplification, the *interior cells* and *boundary cells* need to be considered separately.



**Figure 18:** A diagram to show the face normal vectors on the left and right faces of the 1D cell. The cell normal vectors always point out of the cell.



**Figure 19:** An interior cell in the 1D finite volume method. The cell has two neighbours: a left cell and a right cell. The interior cell has a temperature  $T_P$  at its centroid, the left cell has a temperature  $T_L$  and the right cell has a temperature  $T_R$ . The shared face between the interior cell and the left cell is at a temperature  $T_l$  and the shared face between the interior cell and the right cell is at a temperature  $T_r$ .

### Interior Cells

Figure 19 shows an interior cell in the 1D mesh. The finite volume discretisation of the 1D convection-diffusion equation for the interior cell can be expressed as:

$$\underbrace{\rho_r c_{pr} U_r T_r A_r - \rho_l c_{pl} U_l T_l A_l}_{\text{Convection}} = \underbrace{k_r A_r \frac{T_R - T_P}{d_{PR}} - k_l A_l \frac{T_P - T_L}{d_{LP}}}_{\text{Diffusion}} + \bar{S}V \quad (80)$$

The diffusion terms and the source term (the right hand side of the equation) are identical to the previous chapter. The convection terms (the left hand side of the equation) are new in this chapter. For convenience in the analysis that follows, define the following quantities:


$$D = k/d \quad [\text{W}/\text{m}^2\text{K}] \quad (81)$$

$$F = \rho c_p U A \quad [\text{W}/\text{K}] \quad (82)$$

$D$  is the diffusive flux of heat through the cell face and  $F$  is the convective flux of heat through the cell face. With these new quantities, Equation 80 can be simplified:

$$F_r T_r - F_l T_l = D_r A_r (T_R - T_P) - D_l A_l (T_P - T_L) + \bar{S}V \quad (83)$$

As the unknowns in the analysis are the temperatures at the cell centroids ( $T_L, T_R$  and  $T_P$ ), the temperatures on the cell faces that arise in the convection term ( $T_l, T_r$ ) are currently undefined. Hence, an interpolation scheme is required to calculate the face temperatures



**Figure 20:** Central differencing (linear interpolation) of  $T$  on the left face of the cell using the values at the cell centroids of the interior cell  $T_P$  and the left cell  $T_L$ .

from the temperatures at the cell centroids. In this chapter, *central differencing* will be used for the temperatures in the convection term. It will be shown later that in some scenarios central differencing is not appropriate for the convection term and an alternative interpolation scheme is required.

When using central differencing for the convection term, the temperatures on the left and right faces of the cell are given by (see Figure 20):

$$T_l = \frac{1}{2} (T_L + T_P) \quad (84)$$

$$T_r = \frac{1}{2} (T_P + T_R) \quad (85)$$

Substitute  $T_l$  and  $T_r$  into equation 83.

$$\frac{F_r}{2} (T_P + T_R) - \frac{F_l}{2} (T_L + T_P) = D_r A_r (T_R - T_P) - D_l A_l (T_P - T_L) + \bar{S}V \quad (86)$$

Rearrange and collect the terms that are associated with the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P \left[ D_l A_l + D_r A_r + \frac{F_r}{2} - \frac{F_l}{2} \right] = T_L \left[ D_l A_l + \frac{F_l}{2} \right] + T_R \left[ D_r A_r - \frac{F_r}{2} \right] + \bar{S}V \quad (87)$$

Rearrange the first term on the left-hand side slightly, for convenience:

$$\begin{aligned} T_P \left[ \underbrace{\left( D_l A_l + \frac{F_l}{2} \right) + \left( D_r A_r - \frac{F_r}{2} \right) + (F_r - F_l)}_{a_p} \right] = \\ T_L \underbrace{\left[ D_l A_l + \frac{F_l}{2} \right]}_{a_L} + T_R \underbrace{\left[ D_r A_r - \frac{F_r}{2} \right]}_{a_R} + \bar{S}V \end{aligned} \quad (88)$$

The finite volume equation is now in the standard form:


$$a_p T_P = a_L T_L + a_R T_R + S_u \quad (89)$$

with the following coefficients:

$$a_L = D_l A_l + \frac{F_l}{2} \quad a_R = D_r A_r - \frac{F_r}{2} \quad (90)$$

$$a_p = a_L + a_R + (F_r - F_l) - S_p \quad S_p = 0 \quad S_u = \bar{S}V \quad (91)$$

As a quick check, setting  $F_r$  and  $F_l = 0$  (no convection) results in the same coefficients that were derived in the previous chapter for the diffusion equation.



**Figure 21:** The left boundary cell with a temperature  $T_P$  at its centroid. The shared face between the boundary cell and the right cell is at a temperature  $T_r$  and the boundary has a temperature  $T_A$ .

### Boundary Cell (Left)

All cells in the mesh (boundary cells and interior cells) obey the same discretised form of the convection-diffusion equation:

$$[\rho c_p U T A]_r - [\rho c_p U T A]_l = \left[ k A \frac{dT}{dx} \right]_r - \left[ k A \frac{dT}{dx} \right]_l + \bar{S} V \quad (92)$$

In the same manner as the previous chapter, the temperature of the left wall is fixed at  $T_A$ . Furthermore, the distance between the cell centroids ( $d_{LP}$ ) that is used in the diffusion term is halved, as the distance from the cell centroid to the boundary is half the distance to the next cell (see Figure 21). It follows that the finite volume discretisation of the convection-diffusion equation for the left boundary cell is:

$$F_r T_r - F_l T_A = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_A) + \bar{S} V \quad (93)$$

Use central differencing for the temperature on the right face:

$$T_r = \frac{1}{2} (T_P + T_R) \quad (94)$$


$$\frac{F_r}{2} (T_P + T_R) - F_l T_A = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_A) + \bar{S} V \quad (95)$$

Rearrange in terms of temperatures at the cell-centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P \left[ 2D_l A_l + D_r A_r + \frac{F_r}{2} \right] = T_R \left[ D_r A_r - \frac{F_r}{2} \right] + T_A [2D_l A_l + F_l] + \bar{S} V \quad (96)$$

Rearrange the first term on the left-hand side slightly for convenience.

$$\begin{aligned} T_P \left[ 0 + \left( D_r A_r - \frac{F_r}{2} \right) + (F_r - F_l) + (2D_l A_l + F_l) \right] = \\ \underbrace{\hspace{15em}}_{a_p} \\ T_L \underbrace{[0]}_{a_L} + T_R \underbrace{\left[ D_r A_r - \frac{F_r}{2} \right]}_{a_R} + \underbrace{T_A [2D_l A_l + F_l] + \bar{S} V}_{S_u} \end{aligned} \quad (97)$$



**Figure 22:** The right boundary cell with a temperature  $T_P$  at its centroid. The shared face of the boundary cell and the left cell is at a temperature  $T_l$  and the boundary has a temperature  $T_B$ .

The equation is now in standard form:

$$a_p T_P = a_l T_L + a_r T_R + S_u \quad (98)$$

with the following coefficients:

$$a_L = 0 \quad a_R = D_r A_r - \frac{F_r}{2} \quad a_p = a_l + a_r + (F_r - F_l) - S_p \quad (99)$$

$$S_p = -(2D_l A_l + F_l) \quad S_u = T_A (2D_l A_l + F_l) + \bar{S}V \quad (100)$$

### Boundary Cell (Right)

The boundary cell on the right side of the domain is shown in Figure 22. Start with the 1D finite volume discretisation of the convection-diffusion equation:

$$[\rho c_p U T A]_r - [\rho c_p U T A]_l = \left[ k A \frac{dT}{dx} \right]_r - \left[ k A \frac{dT}{dx} \right]_l + \bar{S}V \quad (101)$$

The temperature on the right boundary is fixed at  $T_B$ . Hence, the temperature on the right face  $T_r = T_B$ . Furthermore, the distance between the cell centroids ( $d_{PR}$ ) that is used in the diffusion term is halved, as the distance from the cell centroid to the boundary is half the distance to the next cell (see Figure 22). It follows that the finite volume discretisation of the convection-diffusion equation for the right boundary cell is:

$$F_r T_B - F_l T_l = 2D_r A_r (T_B - T_P) - D_l A_l (T_P - T_L) + \bar{S}V \quad (102)$$

Use central differencing for the temperature on the left face:

$$T_l = \frac{1}{2} (T_L + T_P) \quad (103)$$

$$F_r T_B - \frac{F_l}{2} (T_L + T_P) = 2D_r A_r (T_B - T_P) - D_l A_l (T_P - T_L) + \bar{S}V \quad (104)$$

Rearrange in terms of temperatures at the cell-centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P \left[ D_l A_l - \frac{F_l}{2} - 2D_r A_r \right] = T_L \left[ D_l A_l + \frac{F_l}{2} \right] + T_B [2D_r A_r - F_r] + \bar{S}V \quad (105)$$



Rearrange the first term on the left-hand side slightly for convenience.

$$T_P \left[ \underbrace{\left( D_l A_l + \frac{F_l}{2} \right) + 0 + (F_r - F_l) + (2D_r A_r - F_r)}_{a_p} \right] = \quad (106)$$

$$T_L \left[ \underbrace{D_l A_l + \frac{F_l}{2}}_{a_L} \right] + T_R \underbrace{[0]}_{a_R} + T_B \underbrace{[2D_r A_r - F_r + \bar{S}V]}_{S_u} \quad (107)$$

The equation is now in standard form:

$$a_p T_P = a_L T_L + a_R T_R + S_u \quad (108)$$

with the following coefficients:

$$a_L = D_l A_l + \frac{F_l}{2} \quad a_R = 0 \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (109)$$

$$S_p = -(2D_r A_r - F_r) \quad S_u = T_B (2D_r A_r - F_r) + \bar{S}V \quad (110)$$

### Coefficient Summary

	$a_L$	$a_R$	$S_p$	$S_u$
Interior	$D_l A_l + \frac{F_l}{2}$	$D_r A_r - \frac{F_r}{2}$	0	$\bar{S}V$
Boundary (L)	0	$D_r A_r - \frac{F_r}{2}$	$-(2D_l A_l + F_l)$	$T_A (2D_l A_l + F_l) + \bar{S}V$
Boundary (R)	$D_l A_l + \frac{F_l}{2}$	0	$-(2D_r A_r - F_r)$	$T_B (2D_r A_r - F_r) + \bar{S}V$

And the central coefficient is given by:


$$a_p = a_L + a_R + (F_r - F_l) - S_p \quad (111)$$

These coefficients are identical to the coefficients for the diffusion equation from the previous chapter, with the exception of the mass fluxes across the left ( $F_l$ ) and right ( $F_r$ ) faces. Setting the mass fluxes to zero results in identical coefficients to the 1D diffusion equation from the previous chapter.

### Example Problem: Conduction and Convection in a bar

For the worked example in this chapter, the same example from the previous chapter will be used. However, the temperature field is now also convected from left to right with a constant velocity of 0.01 m/s. Figure 23 shows a diagram of 1D convection and diffusion of heat in the bar. The bar has a length of 5m, a cross-sectional area of 0.1 m<sup>2</sup>, a thermal conductivity of 100 W/mK and a specific heat capacity of 1000 J/Kg K. The temperature at the left end of the bar ( $T_A$ ) is 100°C and the temperature at the right end ( $T_B$ ) is 200°C. There is a constant source of heat of 1000 W/m<sup>3</sup> in the bar. The temperature field in the bar is governed by the 1D steady-state convection-diffusion equation.

$$\frac{d}{dx}(\rho c_p U T) = \frac{d}{dx} \left( k \frac{dT}{dx} \right) + S \quad (112)$$



**Figure 23:** An example problem to demonstrate 1D convection and diffusion in a bar.

### Step 1: Divide the Geometry into a Mesh

For the example in Figure 23, divide the geometry into a mesh of  $N = 5$  cells of equal length. The length of each cell ( $L_{\text{cell}}$ ) is given by:

$$L_{\text{cell}} = \frac{L}{N} = \frac{5}{5} = 1\text{m} \quad (113)$$

Because the cells are uniformly distributed and have equal size, the distance between cell centroids  $d$  is equivalent to the length of the cells. Hence:

$$d_{LP} = d_{PR} = d = 1\text{m} \quad (114)$$

### Step 2: Assign Material Properties

The thermal conductivity  $k$  and the cross-sectional area  $A$  are the same for every cell in the mesh. Hence, the parameter  $DA$  is given by:

$$DA = \frac{kA}{d} = \frac{100 * 0.1}{1} = 10 \text{ [W/K]} \quad (115)$$

$$D_l A_l = D_r A_r = DA = 10 \text{ [W/K]} \quad (116)$$

The convective heat flux through the cell faces is given by:

$$F = \rho c_p U A = 1.0 * 1000 * 0.01 * 0.1 = 1.0 \text{ [W/K]} \quad (117)$$

$$F_l = F_r = F = 1.0 \text{ [W/K]} \quad (118)$$

The heat source in each cell is given by:

$$\bar{S}V = \bar{S}AL_{\text{cell}} = 1000 * 0.1 * 1 = 100 \text{ [W]} \quad (119)$$

### Step 3: Calculate Matrix Coefficients

Now calculate the coefficients required to assemble the matrices. The most straightforward way is to fill in the table of coefficients:

	$a_L$	$a_R$	$a_p$	$S_p$	$S_u$
Boundary (Left)	0	9.5	30.5	-21	2200
Interior	10.5	9.5	20	0	100
Boundary (Right)	10.5	0	29.5	-19	3900

### Step 4: Assemble the Matrices

Assign the coefficients to their correct location in the matrix.

$$\begin{bmatrix} 30.5 & -9.5 & 0 & 0 & 0 \\ -10.5 & 20 & -9.5 & 0 & 0 \\ 0 & -10.5 & 20 & -9.5 & 0 \\ 0 & 0 & -10.5 & 20 & -9.5 \\ 0 & 0 & 0 & -10.5 & 29.5 \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} 2200 \\ 100 \\ 100 \\ 100 \\ 3900 \end{bmatrix} \quad (120)$$

### Step 5: Solve the Equations

Now that the matrices have been assembled, the matrix equation can be solved with an appropriate *iterative method*. Popular algorithms include Geometric Algebraic Multi-grid (GAMG) and Preconditioned Conjugate Gradient (PCG). However, as with the previous chapter, these algorithms will not be considered in detail here.

### Run the Example Problem Yourself!

Now, open either the Excel spreadsheet, the Python source code or the MATLAB code and solve the problem yourself.

Excel `solve1DConvectionDiffusionEquation.xlsx`


Python `solve1DConvectionDiffusionEquation.py`

MATLAB `solve1DConvectionDiffusionEquation.m`

Examine the calculation of the coefficients, the assembly of the matrices and run the code. You can even try changing some of the geometric and material properties of the problem (such as the thermal conductivity or the length of the bar) and examine the changes in the solution.

### Results

The temperature variation in the bar with a flow velocity of 0.01 m/s is shown in Figure 24 (a). The temperature profile is almost identical to the temperature profile from the previous chapter (where convection was not considered). This is because the strength of the convection is relatively small in comparison with the strength of diffusion in the bar.




**Figure 24:** Temperature variation along the bar for a flow velocity of (a) 0.01 m/s and (b) 0.1 m/s.

Figure 24 (b) shows the effect of increasing the flow velocity from 0.01 m/s to 0.1 m/s. The effect of convection is now much stronger and the profile is noticeably shifted to the right by the flow velocity (which is flowing from left to right). The relative strength of the convective and diffusive flux of heat through the cell is given by the cell Peclet number ( $Pe$ ).

$$Pe = \frac{\text{Convective Flux}}{\text{Diffusive Flux}} = \frac{F}{DA} = \frac{\rho c_p U A}{k A / d} \quad (121)$$

For a flow velocity of 0.01 m/s,  $Pe$  is 0.1. This indicates that the diffusive heat flux through the cell is much stronger than the convective heat flux. Increasing the flow velocity to 0.1

m/s increases  $Pe$  to 1. This indicates that the relative strength of convective and diffusive heat flux through the cell are approximately the same and the effect on the temperature profile is noticeable in Figure 24 (b). However, further increasing the flow velocity to 0.3 m/s increases  $Pe$  to 3. At this stage, the solution exhibits non-physical oscillations, as shown in Figure 25. The reason for these oscillations is the *central-differencing* scheme that has been used for the convection term is unstable when  $Pe > 2$ . Hence, an alternative discretisation scheme is required that does not lead to these instabilities. One common choice is the *upwind differencing scheme*, which will be considered in the next chapter.



**Figure 25:** Temperature variation along the bar with a flow velocity of 0.3 m/s ( $Pe = 3$ ).

## 4 Upwind Differencing

In this chapter, the 1D steady-state convection-diffusion equation will be considered again. However, an *upwind differencing* scheme will be applied to the convection term rather than a *central differencing* scheme (which was applied in the previous chapter). As a reminder, the 1D convection-diffusion equation is:

$$\frac{d}{dx}(\rho c_p U T) = \frac{d}{dx} \left( k \frac{dT}{dx} \right) + S \quad (122)$$

The finite volume discretisation of this equation for a 1D cell is:

$$[\rho c_p U T A]_r - [\rho c_p U T A]_l = \left[ k A \frac{dT}{dx} \right]_r - \left[ k A \frac{dT}{dx} \right]_l + \bar{S} V \quad (123)$$

In the previous chapter, central differencing (linear interpolation) was used to calculate the temperature of the left ( $T_l$ ) and right ( $T_r$ ) faces of the cell.

$$T_l = \frac{1}{2} (T_L + T_P) \quad (124)$$

$$T_r = \frac{1}{2} (T_P + T_R) \quad (125)$$

However, when the Peclet number  $Pe$  is  $> 2$ , non-physical oscillations are generated in the solution. An alternative to the central differencing scheme which does not lead to non-physical oscillations is an *upwind* scheme. With an upwind scheme, the temperature on the cell face takes the value of the *upwind* cell centroid. More specifically, this means that the value on the cell face will take the value at the cell centroid in the direction that the flow is coming from. As an example, consider the left face  $l$  of an interior cell in the mesh, as shown in Figure 26. When the flow is left to right,  $U > 0$  and therefore  $F > 0$ . It follows that the centroid of the left cell is upwind of the face and the temperature on the face  $T_l = T_L$ . Conversely, when the flow is right to left,  $U < 0$  and therefore  $F < 0$ . It follows that the centroid of the interior cell is upwind of the left face and the temperature of the face  $T_l = T_P$ . These two cases can be written concisely as:

$$T_l = \begin{cases} T_L & F_l > 0 \\ T_P & F_l < 0 \end{cases} \quad (126)$$

Now consider the right face of the cell, as shown in Figure 27. The temperature on this face of the cell is:


$$T_r = \begin{cases} T_P & F_l > 0 \\ T_R & F_l < 0 \end{cases} \quad (127)$$

As with the previous chapters, separate discretised equations will now be written for the interior and boundary cells. Once these equations have been written, the coefficients will be calculated and the matrices assembled, ready for solving.


### Interior Cells

Start with the general finite volume discretisation of the 1D steady-state convection-diffusion equation.

$$[\rho c_p U T A]_r - [\rho c_p U T A]_l = \left[ k A \frac{dT}{dx} \right]_r - \left[ k A \frac{dT}{dx} \right]_l + \bar{S} V \quad (128)$$



**Figure 26:** A diagram to show the temperature on the left face of the cell ( $T_l$ ) computed using upwind differencing when the flow direction is (a) left to right and (b) right to left.



**Figure 27:** A diagram to show the temperature on the right face of the cell  $T_r$  computed using upwind differencing when the flow direction is (a) left to right and (b) right to left.

As before, introduce the notation  $D = k/d$  and  $F = \rho c_p U A$  for convenience.

$$F_r T_r - F_l T_l = D_r A_r (T_R - T_P) - D_l A_l (T_P - T_l) + \bar{S} V \quad (129)$$

As an upwind differencing scheme is being used in this chapter for the convection term, two different cases will be considered. Firstly, the case where the flow is left to right will be considered, then the case where the flow is right to left.

**(a) Flow from Left to Right ( $F > 0$ )**

Using Figure 26 (a) and Figure 27 (a), the finite volume discretisation becomes:

$$F_r T_P - F_l T_L = D_r A_r (T_R - T_P) - D_l A_l (T_P - T_L) + \bar{S}V \quad (130)$$

Rearrange the equation in terms of the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P [D_l A_l + D_r A_r + F_r] = T_L [D_l A_l + F_l] + T_R [D_l A_l] + \bar{S}V \quad (131)$$

Rearrange the first term on the left-hand side slightly.

$$T_P \underbrace{[D_l A_l + F_l + D_r A_r + (F_r - F_l)]}_{a_p} = T_L \underbrace{[D_l A_l + F_l]}_{a_L} + T_R \underbrace{[D_r A_r]}_{a_R} + \underbrace{\bar{S}V}_{S_u} \quad (132)$$

The equation is now written in standard form, with the following coefficients:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (133)$$

$$a_L = D_l A_l + F_l \quad a_R = D_r A_r \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (134)$$

$$S_p = 0 \quad S_u = \bar{S}V \quad (135)$$

**(b) Flow from Right to Left ( $F < 0$ )**

Using Figure 26 (b) and Figure 27 (b), the finite volume discretisation becomes:

$$F_r T_R - F_l T_P = D_r A_r (T_R - T_P) - D_l A_l (T_P - T_L) + \bar{S}V \quad (136)$$

Rearrange the equation in terms of the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P [D_l A_l + D_r A_r - F_l] = T_L [D_l A_l] + T_R [D_r A_r - F_r] + \bar{S}V \quad (137)$$

Rearrange the first term on the left-hand side slightly.

$$T_P \underbrace{[D_l A_l + D_r A_r - F_r + (F_r - F_l)]}_{a_p} = T_L \underbrace{[D_l A_l]}_{a_L} + T_R \underbrace{[D_r A_r - F_r]}_{a_R} + \underbrace{\bar{S}V}_{S_u} \quad (138)$$

The equation is now written in standard form, with the following coefficients:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (139)$$

$$a_L = D_l A_l \quad a_R = D_r A_r - F_r \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (140)$$


$$S_p = 0 \quad S_u = \bar{S}V \quad (141)$$

**(c) Flow From Either Direction**

The finite volume discretisation for the interior cell can be written concisely (accounting for flow from either direction) as:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (142)$$





**Figure 28:** A diagram of the temperature on the left and right faces of the boundary cell (left) computed using upwind differencing when the flow direction is (a) left to right and (b) right to left.

with the following coefficients:

$$a_L = D_l A_l + \max(F_l, 0) \quad (143)$$

$$a_R = D_R A_R + \max(-F_r, 0) \quad (144)$$

$$a_P = a_L + a_R + (F_r - F_l) - S_p \quad (145)$$

$$S_P = 0 \quad (146)$$

$$S_u = \bar{S}V \quad (147)$$

The coefficients  $a_L$  and  $a_R$  only receive a convective flow contribution ( $F$ ) when the flow is into the cell through that face. Now that the interior cell has been considered, the boundary cells on the left and right need to be considered.

### Boundary Cell (Left)

In the same manner as the interior cell, two different cases will be considered for the boundary cell. Firstly, the case where the flow is left to right will be considered, then the case where the flow is right to left.

#### (a) Flow From Left to Right ( $F > 0$ )

For the left boundary cell, consider the case where the flow direction is left to right, as shown in Figure 28 (a). The general finite volume discretisation for the left boundary cell is:

$$F_r T_r - F_l T_l = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_A) \quad (148)$$

In the same manner as the previous chapters, the diffusive flux through the left face contains a factor of 2 because the distance to the boundary face is half the distance to the boundary

cell centroid. As the flow direction is left to right, the temperature on the cell faces ( $T_l$  and  $T_r$ ) are assigned the following values when an upwind scheme is used.

$$T_l = T_A \quad T_r = T_P \quad (149)$$

Hence, the finite volume discretisation for the left boundary cell becomes:

$$F_r T_P - F_l T_A = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_A) \quad (150)$$

Rearrange the equation in terms of the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P [D_r A_r + 2D_l A_l + F_r] = T_R [D_r A_r] + T_A [2D_l A_l + F_l] \quad (151)$$

Rearrange the first term on the left-hand side slightly.

$$T_P \underbrace{[0 + D_r A_r + (F_r - F_l) + 2D_l A_l + F_l]}_{a_p} = T_L \underbrace{[0]}_{a_L} + T_R \underbrace{[D_r A_r]}_{a_R} + \underbrace{T_A [2D_l A_l + F_l]}_{S_u} \quad (152)$$

The equation is now written in standard form, with the following coefficients:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (153)$$

$$a_L = 0 \quad a_R = D_r A_r \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (154)$$

$$S_u = T_A (2D_l A_l + F_l) \quad S_p = -(2D_l A_l + F_l) \quad (155)$$

### (b) Flow From Right to Left ( $F < 0$ )

Now consider the case for the left boundary cell where the flow direction is right to left, as shown in Figure 28 (b). The general finite volume discretisation for the left boundary cell is:

$$F_r T_r - F_l T_l = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_A) \quad (156)$$

As the flow direction is right to left, the temperature on the cell faces ( $T_l$  and  $T_r$ ) are assigned the following values when an upwind scheme is used.

$$T_l = T_P \quad T_r = T_R \quad (157)$$

Hence, the finite volume discretisation for the left boundary cell becomes:

$$F_r T_R - F_l T_P = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_A) \quad (158)$$

Rearrange the equation in terms of the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P [D_r A_r - F_l + 2D_l A_l] = T_R [D_r A_r - F_r] + T_A [2D_l A_l] \quad (159)$$

Rearrange the first term on the left-hand side slightly.


$$T_P \underbrace{[0 + D_r A_r - F_r + (F_r - F_l) + 2D_l A_l]}_{a_p} = T_L \underbrace{[0]}_{a_L} + T_R \underbrace{[D_r A_r - F_r]}_{a_R} + \underbrace{T_A [2D_l A_l]}_{S_u} \quad (160)$$

The equation is now written in standard form, with the following coefficients:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (161)$$

$$a_L = 0 \quad a_R = D_r A_r - F_r \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (162)$$

$$S_p = -2D_l A_l \quad S_u = T_A (2D_l A_l) \quad (163)$$



**Figure 29:** A diagram of the temperature on the left and right faces of the boundary cell (right) computed using upwind differencing when the flow direction is (a) left to right and (b) right to left.

### (c) Flow From Either Direction

The finite volume discretisation for the boundary cell (left) can be written concisely (accounting for flow from either direction) as:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (164)$$

With the following coefficients:

$$a_L = 0 \quad (165)$$

$$a_R = D_r A_r + \max(-F_r, 0) \quad (166)$$

$$a_P = a_L + a_R + (F_r - F_l) - S_p \quad (167)$$

$$S_P = -(2D_l A_l + \max(F_l, 0)) \quad (168)$$

$$S_u = T_A (2D_l A_l + \max(F_l, 0)) \quad (169)$$

The source terms ( $S_u$  and  $S_p$ ) only receive a contribution when the convective flux from the left boundary is into the cell ( $F_l$  is positive). Conversely, the convective flux over the right face of the cell ( $a_R$ ) only receives a contribution when the flow is into the cell ( $F_r$  is negative).

### Boundary Cell (Right)

In the same manner as the boundary cell (left), two different cases will be considered for the boundary cell (right). Firstly, the case where the flow is left to right will be considered, then the case where the flow is right to left.

#### (a) Flow From Left to Right ( $F > 0$ )

For the right boundary cell, consider the case where the flow is left to right, as shown in Figure 29 (a). The temperature of the wall is  $T_B$  and the general finite volume discretisation of the right boundary cell is:

$$F_r T_r - F_l T_l = 2D_r A_r (T_B - T_P) - D_r A_r (T_P - T_L) \quad (170)$$

As with the previous treatment of boundary cells, a factor of 2 is introduced into the diffusive flux through the right face because the distance to the boundary face is half of the distance between cell centroids. As the flow direction is left to right, the temperature on the cell faces ( $T_l$  and  $T_r$ ) are assigned the following values when an upwind scheme is used:

$$T_l = T_L \quad T_r = T_P \quad (171)$$

Hence, the finite volume discretisation for the right boundary cell becomes:

$$F_r T_P - F_l T_L = 2D_r A_r (T_B - T_P) - D_l A_l (T_P - T_L) \quad (172)$$

Rearrange the equation in terms of the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P [D_l A_l + F_r + 2D_r A_r] = T_L [D_l A_l + F_l] + T_B [2D_r A_r] \quad (173)$$

Rearrange the first term on the left-hand side slightly.

$$T_P \underbrace{[D_l A_l + F_l + 0 + (F_r - F_l) + 2D_r A_r]}_{a_p} = T_L \underbrace{[D_l A_l + F_l]}_{a_L} + T_R \underbrace{[0]}_{a_R} + T_B \underbrace{[2D_r A_r]}_{S_u} \quad (174)$$

The equation is now written in standard form, with the following coefficients:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (175)$$

$$a_L = D_l A_l + F_l \quad a_R = 0 \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (176)$$

$$S_p = -2D_r A_r \quad S_u = 2D_r A_r T_B \quad (177)$$

### (b) Flow From Right to Left ( $F < 0$ )

Now consider the case on the right boundary cell where the flow direction is right to left, as shown in Figure 29 (b). The general finite volume discretisation of the right boundary cell is:

$$F_r T_r - F_l T_l = 2D_r A_r (T_B - T_P) - D_r A_r (T_P - T_L) \quad (178)$$

As the flow direction is right to left, the temperature on the cell faces ( $T_l$  and  $T_r$ ) are assigned the following values when an upwind scheme is used:

$$T_l = T_P \quad T_r = T_B \quad (179)$$

Hence, the finite volume discretisation for the right boundary cell becomes:

$$F_r T_B - F_l T_P = 2D_r A_r (T_B - T_P) - D_l A_l (T_P - T_L) \quad (180)$$

Rearrange the equation in terms of the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ).

$$T_P [D_l A_l - F_l + 2D_r A_r] = T_L [D_l A_l] + T_B [2D_r A_r - F_r] \quad (181)$$

Rearrange the first term on the left-hand side slightly.

$$T_P \underbrace{[D_l A_l + 0 + (F_r - F_l) + 2D_r A_r - F_r]}_{a_p} = T_L \underbrace{[D_l A_l]}_{a_L} + T_R \underbrace{[0]}_{a_R} + T_B \underbrace{[2D_r A_r - F_r]}_{S_u} \quad (182)$$

The equation is now written in standard form, with the following coefficients:

$$a_P T_P = a_L T_L + a_R T_R + S_u \quad (183)$$

$$a_L = D_l A_l \quad a_R = 0 \quad a_p = a_L + a_R + (F_r - F_l) - S_p \quad (184)$$

$$S_p = -(2D_r A_r - F_r) \quad S_u = T_B (2D_r A_r - F_r) \quad (185)$$

### (c) Flow From Either Direction

The finite volume discretisation for the boundary cell (left) can be written concisely (accounting for flow from either direction) as:

$$a_P T_p = a_L T_L + a_R T_R + S_u \quad (186)$$

With the following coefficients:

$$a_L = D_l A_l + \max(F_l, 0) \quad (187)$$

$$a_R = 0 \quad (188)$$

$$a_P = a_L + a_R + (F_r - F_l) - S_p \quad (189)$$

$$S_P = -(2D_r A_r + \max(-F_r, 0)) \quad (190)$$

$$S_u = T_B(2D_r A_r + \max(-F_r, 0)) \quad (191)$$

The source terms ( $S_u$  and  $S_p$ ) only receive a contribution from convection when the convective flux from the right boundary is into the cell ( $F_r$  is negative). Conversely, the convective flux over the left face of the cell ( $a_L$ ) only receives a contribution when the flow is into the cell ( $F_l$  is positive).

### Table of Coefficients

Assemble all of the coefficients into a table for ease of reference:


	$a_L$	$a_R$	$S_p$	$S_u$
Left	0	$D_r A_r$ $+ \max(-F_r, 0)$	$-(2D_l A_l$ $+ \max(F_l, 0))$	$T_A(2D_l A_l$ $+ \max(F_l, 0)) + \bar{S}V$
Interior	$D_l A_l$ $+ \max(F_l, 0)$	$D_r A_r$ $+ \max(-F_r, 0)$	0	$\bar{S}V$
Right	$D_l A_l +$ $\max(0, F_l)$	0	$-(2D_r A_r$ $+ \max(-F_r, 0))$	$T_B(2D_r A_r$ $+ \max(-F_r, 0)) + \bar{S}V$

Along with the relationship for the central coefficients:

$$a_P = a_L + a_R + (F_r - F_l) - S_p \quad (192)$$

### Example Problem: Conduction and Convection in a 1D Bar

For the worked example in this chapter, the same example from the previous chapter will be used. However, it will be shown that the upwind differencing scheme can achieve stable solutions at higher cell Peclet numbers which were not possible with the central differencing scheme in the previous chapter. As a reminder, Figure 30 shows a diagram of 1D convection and diffusion of heat in the bar (or channel). The bar has a length of 5m, a cross-sectional



**Figure 30:** An example problem to demonstrate 1D convection and diffusion in a bar.

area of  $0.1 \text{ m}^2$ , a thermal conductivity of  $100 \text{ W/mK}$  and a specific heat capacity of  $1000 \text{ J/Kg K}$ . The temperature at the left end of the bar ( $T_A$ ) is  $100^\circ\text{C}$  and the temperature at the right end ( $T_B$ ) is  $200^\circ\text{C}$ . There is a constant source of heat of  $1000 \text{ W/m}^3$  in the bar. Fluid flows through the bar from left to right at  $0.01 \text{ m/s}$ .

### Step 1: Divide the Geometry into a Mesh

Divide the geometry into a mesh of  $N = 5$  cells of equal length. The length of each cell ( $L_{\text{cell}}$ ) is given by:

$$L_{\text{cell}} = \frac{L}{N} = \frac{5}{5} = 1\text{m} \quad (193)$$

Because the cells are uniformly distributed and have equal size, the distance between cell centroids  $d$  is equivalent to the length of the cells. Hence:

$$d_{LP} = d_{PR} = d = 1\text{m} \quad (194)$$

### Step 2: Assign Material Properties

The thermal conductivity  $k$  and the cross-sectional area  $A$  are the same for every cell in the mesh. Hence, the parameter  $DA$  is given by:

$$DA = \frac{kA}{d} = \frac{100 * 0.1}{1} = 10 \text{ [W/K]} \quad (195)$$

$$D_l A_l = D_r A_r = DA = 10 \text{ [W/K]} \quad (196)$$

The convective heat flux through the cell faces is given by:

$$F = \rho c_p U A = 1.0 * 1000 * 0.01 * 0.1 = 1 \text{ [W/K]} \quad (197)$$

$$F_l = F_r = F = 1 \text{ [W/K]} \quad (198)$$

The heat source in each cell is given by:

$$\bar{S}V = \bar{S}AL_{\text{cell}} = 1000 * 0.1 * 1 = 100 \text{ [W]} \quad (199)$$

### Step 3: Calculate Matrix Coefficients

Now calculate the coefficients required to assemble the matrices. The most straightforward way is to fill in the table of coefficients:

	$a_L$	$a_R$	$a_p$	$S_p$	$S_u$
Boundary (Left)	0	10	31	-21	2200
Interior	11	10	21	0	100
Boundary (Right)	11	0	31	-20	4100

Notice that the calculated coefficients are different to the calculated coefficients from the previous chapter, which are shown in the table below.

	$a_L$	$a_R$	$a_p$	$S_p$	$S_u$
Boundary (Left)	0	9.5	30.5	-21	2200
Interior	10.5	9.5	20	0	100
Boundary (Right)	10.5	0	29.5	-19	3900

The difference in the coefficients arises because upwind differencing has been used to discretise the convection term in this chapter, rather than central differencing.

### Step 4: Assemble the Matrices

Assign the coefficients to their correct location in the matrix.


$$\begin{bmatrix} 31 & -10 & 0 & 0 & 0 \\ -11 & 21 & -10 & 0 & 0 \\ 0 & -11 & 21 & -10 & 0 \\ 0 & 0 & -11 & 21 & -10 \\ 0 & 0 & 0 & -11 & 31 \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} 2200 \\ 100 \\ 100 \\ 100 \\ 4100 \end{bmatrix} \quad (200)$$

### Step 5: Solve the Equations

Now that the matrices have been assembled, the matrix equation can be solved with an appropriate *iterative method*. Popular algorithms include Geometric Algebraic Multi-grid (GAMG) and Preconditioned Conjugate Gradient (PCG). However, as with the previous chapter, these algorithms will not be considered in detail here.

### Run the Example Problem Yourself!

Now, open either the Excel spreadsheet, the Python source code or the MATLAB source code and solve the problem yourself.



**Figure 31:** Temperature variation along the bar with a flow velocity is 0.01 m/s ( $Pe = 0.1$ ). Upwind differencing has been used for the convection term.

Excel	<code>solve1DConvectionDiffusionEquationUpwind.xlsx</code>
Python	<code>solve1DConvectionDiffusionEquationUpwind.py</code>
MATLAB	<code>solve1DConvectionDiffusionEquationUpwind.m</code>

Examine the calculation of the coefficients, the assembly of the matrices and run the code. You can even try changing some of the geometric and material properties of the problem (such as the thermal conductivity or the length of the bar) and examine the changes in the solution.


## Results

The temperature variation in the bar when upwind differencing is used is shown in Figure 31. The temperature profile is almost identical to the temperature profile from the previous chapter (where central differencing was used). This is because the strength of convection is relatively small in comparison with the strength of diffusion in the bar. However, comparing the solution vectors, it can be seen that the upwind differencing scheme computes a slightly different solution to the central differencing scheme.

$$T = \underbrace{\begin{bmatrix} 119.6 \\ 150.8 \\ 175.2 \\ 191.9 \\ 200.4 \end{bmatrix}}_{\text{Upwind}} \quad T = \underbrace{\begin{bmatrix} 119.2 \\ 151.1 \\ 175.9 \\ 192.7 \\ 200.8 \end{bmatrix}}_{\text{Central}} \quad (201)$$



The upwind scheme is less accurate than the central differencing scheme because the upwind scheme assumes a constant variation of temperature between the cell face and the cell centroid, rather than a linear variation (see Figure 26 for example). For this reason, the upwind differencing scheme is often referred to as *first-order accurate* in the literature.



**Figure 32:** Temperature variation along the bar with a flow velocity of 0.3 m/s ( $Pe = 3$ ). Upwind differencing has been used for the convection term.

### Increasing the Flow Velocity

Following the previous chapter, the flow velocity will now be increased to 0.3 m/s. This results in a Peclet number of 3. As shown in Figure 32, the upwind scheme is able to compute a solution that does not contain any non-physical oscillations. This is a significant improvement on the central differencing scheme from the previous chapter.

### Choice of Convection Scheme for RANS Computations

While the upwind scheme does not lead to non-physical oscillations at high  $Pe$ , upwind schemes reduce the accuracy of the solution as they assume a constant variation between the cell face and the cell centroid. To achieve a balance between accuracy and stability, a variety of discretisation schemes are available in modern CFD codes, such as *linear-upwind differencing*. These schemes are preferable for the convection term and should be selected (for RANS simulations) where possible, to achieve a balance between accuracy and stability.

# 1 Dirichlet and Neumann Boundary Conditions

In this chapter, the finite volume discretisation of the 1D diffusion equation from the previous course will be revisited. The diffusion equation will be used to introduce *Neumann* (fixed gradient) boundary conditions for the first time and revisit *Dirichlet* (fixed value) boundary conditions. While a general diffusion equation can be used to describe many transported quantities, the diffusion equation for thermal energy (temperature) will be considered in this course, as it is the easiest to physically interpret. Mathematically, the general scalar transport equation for thermal energy (temperature) for incompressible (low speed) flows is:

$$\underbrace{\frac{\partial(\rho c_p T)}{\partial t}}_{\text{Unsteady}} + \underbrace{\nabla \cdot (\rho c_p T \mathbf{U})}_{\text{Convection}} = \underbrace{\nabla \cdot (k \nabla T)}_{\text{Diffusion}} + S \quad (1)$$

where  $T$  is the temperature,  $\rho$  is the density,  $c_p$  is the specific heat capacity at constant pressure,  $k$  is the thermal conductivity,  $\mathbf{U}$  is the velocity vector and  $S$  is a source of thermal energy. Some readers may recognise this equation as the transport equation for *enthalpy*. To observe the transport equation for enthalpy ( $h$ ), define  $h = c_p T$  and substitute in to equation 1:

$$\frac{\partial(\rho h)}{\partial t} + \nabla \cdot (\rho \mathbf{U} h) = \nabla \cdot (k \nabla T) + S \quad (2)$$

However, this form of the thermal energy equation will not be used in this course, as temperature is an easier variable to interpret and follow than enthalpy.

The focus of this chapter will be the diffusion and source terms in equation 1, since the convection term was considered in the previous course and the unsteady term will be considered in a later course. Neglecting the convection and unsteady terms in equation 1, the diffusion equation for thermal energy is:

$$\cancel{\frac{\partial(\rho c_p T)}{\partial t}} + \cancel{\nabla \cdot (\rho c_p T \mathbf{U})} = \nabla \cdot (k \nabla T) + S \quad (3)$$

$$0 = \nabla \cdot (k \nabla T) + S \quad (4)$$

Expanding the gradient ( $\nabla$ ) and divergence ( $\nabla \cdot$ ) operators into Cartesian coordinates ( $x, y, z$ ):


$$0 = \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) + \frac{\partial}{\partial z} \left( k \frac{\partial T}{\partial z} \right) + S \quad (5)$$

To clearly demonstrate how Dirichlet and Neumann boundary conditions are implemented by CFD solvers, the diffusion equation will only be considered in 1D (the  $x$  direction) in this chapter. 2D geometries will be considered later in Chapter 2 of this course. In 1D, the diffusion equation for thermal energy (temperature) is:

$$0 = \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \cancel{\frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right)} + \cancel{\frac{\partial}{\partial z} \left( k \frac{\partial T}{\partial z} \right)} + S \quad (6)$$

$$0 = \frac{d}{dx} \left( k \frac{dT}{dx} \right) + S \quad (7)$$

The majority of modern CFD codes use the **finite volume method** to solve the transport equations for the various flow variables (velocity, temperature, pressure etc.). In the previous



**Figure 1:** A 1D finite volume of fluid with volume  $V$ , which has been isolated from the bar.

course, the finite volume method was reviewed in detail. To avoid repetition, only a concise overview of the finite volume method will be provided here, to ensure that the derivation and solution presented is continuous and coherent. Further detail can be found in the previous course. The first stage in the finite volume method is to integrate the transport equation over a finite-sized control volume (cell). As shown in Figure 1, a 1D cell can be thought of as a slice through a thin 1D bar or rod. Integrating the 1D diffusion equation (equation 7) over this cell:

$$0 = \int_V \left[ \frac{d}{dx} \left( k \frac{dT}{dx} \right) + S \right] dV \quad (8)$$

Integration and addition are commutative operations (is doesn't matter what order they are carried out in). Hence, the finite volume integral can be split into two separate integrals and each one can then be considered in turn.

$$0 = \int_V \left[ \frac{d}{dx} \left( k \frac{dT}{dx} \right) \right] dV + \int_V [S] dV \quad (9)$$

As shown in the previous course, Gauss's divergence theorem is used to replace the volume integral of the diffusion term with a surface integral. Recall (from the previous course) that the divergence theorem for a general vector field  $\mathbf{B}$  is written as:

$$\int_V (\nabla \cdot \mathbf{B}) dV = \int_A (\mathbf{B} \cdot \hat{\mathbf{n}}) dA \quad (10)$$

where  $\hat{\mathbf{n}}$  is the unit normal vector pointing out of the control volume and  $A$  is the surface area of the control volume. In 1D Cartesian coordinates, the divergence theorem can be written:


$$\int_V \left( \frac{\partial B_x}{\partial x} + \frac{\partial B_y}{\partial y} + \frac{\partial B_z}{\partial z} \right) dV = \int_A (B_x n_x + B_y n_y + B_z n_z) dA \quad (11)$$

$$\int_V \left( \frac{\partial B_x}{\partial x} + \cancel{\frac{\partial B_y}{\partial y}} + \cancel{\frac{\partial B_z}{\partial z}} \right) dV = \int_A \left( B_x n_x + \cancel{B_y n_y} + \cancel{B_z n_z} \right) dA \quad (12)$$

$$\int_V \left( \frac{\partial B_x}{\partial x} \right) dV = \int_A (B_x n_x) dA \quad (13)$$

For the heat diffusion equation  $\mathbf{B} = k \nabla T$ . Hence  $B_x = k \partial T / \partial x$  in 1D. Applying the 1D divergence theorem to the 1D heat diffusion equation leads to:

$$0 = \int_A \left[ k \frac{dT}{dx} n_x \right] dA + \int_V [S] dV \quad (14)$$



**Figure 2:** A diagram to show the face normal vectors on the left and right faces of the 1D cell. The cell normal vectors always point out of the cell.

The source term is averaged over the control volume, so it can be moved outside the volume integral.

$$0 = \int_A \left[ k \frac{dT}{dx} n_x \right] dA + \bar{S} \int_V dV \quad (15)$$

$$0 = \int_A \left[ k \frac{dT}{dx} n_x \right] dA + \bar{S} V \quad (16)$$

Recall that the unit normal vector ( $n_x$ ) always points out of the cell. As shown in Figure 2, on the left face of the cell ( $l$ ), the unit normal vector is negative. Conversely, the unit normal vector is positive on the right face of the cell ( $r$ ).

$$0 = \left[ kA \frac{dT}{dx} \right]_r - \left[ kA \frac{dT}{dx} \right]_l + \bar{S} V \quad (17)$$

This finite volume discretisation is valid for all cells in the mesh. However, different simplifications are required for interior and boundary cells before the equations can be solved.


## Interior Cells

Start with the general finite volume discretisation of the 1D diffusion equation.


$$0 = \left[ kA \frac{dT}{dx} \right]_r - \left[ kA \frac{dT}{dx} \right]_l + \bar{S} V \quad (18)$$

To simplify and solve this equation for the interior cells, the temperature gradient on the cell faces ( $l$  and  $r$ ) needs to be expressed in terms of temperatures at the cell centroids ( $L$ ,  $R$  and  $P$ ). This is because the unknowns in the matrix equations are the temperatures at the cell centroids and other variables need to be expressed in terms of these temperatures. Hence, the temperature (and other variables) are calculated and stored at the cell centroids, rather than the nodes or faces. This approach is called a **cell-centred** finite volume method and is used by the CFD codes OpenFOAM, ANSYS Fluent and Star CCM+ but not ANSYS CFX (which uses a **node based** finite volume method).

Throughout this course, the lower case subscripts ( $l$  and  $r$ ) will be used to refer to cell faces, while upper-case subscripts ( $L$ ,  $R$  and  $P$ ) will be used to refer to cell centroids, as shown in Figure 3. This notation has been chosen because the temperatures at the cell centroids are the unknowns in the system. The necessary simplification of the gradients on the cell faces can be accomplished with linear interpolation, which is often called **central-differencing**. To



**Figure 3:** A diagram to show the difference between the temperatures on the cell faces ( $T_l$  and  $T_r$ ) and the temperature at the cell centroids ( $T_L$  and  $T_R$ ).



**Figure 4:** Central differencing (linear interpolation) of the temperature gradient on the left face of the cell using the values at the cell centroids of the interior cell ( $T_P$ ) and the left cell ( $T_L$ ).

help understand this simplification, remember that the spatial gradient of temperature can be thought of as:

$$\frac{dT}{dx} \sim \frac{\Delta T}{\Delta x} = \frac{\text{Change in Temperature}}{\text{Distance}} \quad (19)$$

As shown in Figure 4, the temperature gradient on the left face can be expressed using central differencing as:

$$\left(\frac{dT}{dx}\right)_l = \frac{T_P - T_L}{d_{LP}} \quad (20)$$

where  $d_{LP}$  is the distance between the cell centroids  $L$  and  $P$ . In a similar manner, the temperature gradient on the right face can also be expressed using central differencing:

$$\left(\frac{dT}{dx}\right)_r = \frac{T_R - T_P}{d_{PR}} \quad (21)$$

Substitute this simplification into the 1D diffusion equation (equation 18).

$$\left(k_r A_r \frac{T_R - T_P}{d_{PR}}\right) - \left(k_l A_l \frac{T_P - T_L}{d_{LP}}\right) + \bar{S}V = 0 \quad (22)$$

The 1D diffusion equation can now be solved for the temperatures at the cell centroids ( $T_L$ ,  $T_R$  and  $T_P$ ). To simplify this process, rearrange the equation and collect the terms in terms of temperature of the interior cell ( $T_P$ ), temperature of the left cell ( $T_L$ ) and the temperature of the right cell ( $T_R$ ).

$$T_P \left(\frac{k_l A_l}{d_{LP}} + \frac{k_r A_r}{d_{PR}}\right) = T_L \left(\frac{k_l A_l}{d_{LP}}\right) + T_R \left(\frac{k_r A_r}{d_{PR}}\right) + \bar{S}V \quad (23)$$

At this stage, it is useful to introduce some new notation to simplify the finite volume discretisation. This new notation makes it easier to compare the finite volume discretisation of interior cells, boundary cells and add additional terms to the equation later on. The approach adopted in the previous course was to introduce the notation  $D = k/d$ . This quantity can be thought of as the diffusive flux of heat per unit area through the cell face and has units of  $W/m^2K$ . Using this notation, the finite volume discretisation becomes:

$$T_P (D_l A_l + D_r A_r) = T_L (D_l A_l) + T_R (D_r A_r) + \bar{S}V \quad (24)$$

For consistency with other equations that will be introduced later, write the above equation in the following form:

$$a_p T_P = a_L T_L + a_R T_R + S_u$$

$$T_P \underbrace{(D_l A_l + D_r A_r + 0)}_{a_p} = T_L \underbrace{(D_l A_l)}_{a_L} + T_R \underbrace{(D_r A_r)}_{a_R} + \underbrace{\bar{S}V}_{S_u} \quad (25)$$

This equation is valid for all cells in the mesh, except for the boundary cells. The boundary cells have to be considered separately.

Equation 23 can also be written using summation notation:

$$a_p T_P = \sum_N a_N T_N + S_u$$

$$a_p = \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \quad a_N = \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \quad S_u = \bar{S}V \quad (26)$$

where the summation is taken over the  $N$  cell neighbours. For 1D cells,  $N = 2$ . However, for 2D and 3D meshes, the summation notation becomes more useful as each cell has multiple cell neighbours and the finite volume discretisation can become quite long (this will be shown in Chapter 2)! Also notice that in the summation notation, the magnitude of the unit normal vector  $|\hat{\mathbf{n}}|$  and the vector  $|\mathbf{d}|$  are used. This is permissible because the unit normal vector and the vector  $\mathbf{d}$  are parallel with each other. In turn this is because the mesh used in this course is *structured* and *orthogonal*. Special treatment is required for *non-orthogonal* and *unstructured* meshes. However, the special treatment required for these meshes will not be considered in this course (for brevity).


## Boundary Cell (Left) - Dirichlet Boundary Condition

Now the boundary conditions on the left hand boundary cell will be considered, starting with the Dirichlet (fixed temperature) condition. Figure 5 shows a schematic diagram of this cell, with a fixed temperature  $T_w$  applied at the wall. The general finite volume discretisation for the 1D diffusion equation is:

$$\left( kA \frac{dT}{dx} \right)_r - \left( kA \frac{dT}{dx} \right)_l + \bar{S}V = 0 \quad (27)$$

The right face of the boundary cell is connected to an interior cell. Hence, the same central differencing scheme for the temperature gradient from the previous section can be used for the right face. However, the left face is connected to a boundary. As shown in Figure 5, the temperature gradient term for the left face is:

$$\left( \frac{dT}{dx} \right)_l = \frac{T_P - T_w}{d_{LP}/2} \quad (28)$$



**Figure 5:** The left boundary cell with temperature  $T_P$  at its centroid. The shared face between the boundary cell and the right cell is at a temperature  $T_r$  and the wall has a temperature  $T_l = T_w$ .

The factor of  $1/2$  is required as the distance from the cell centroid to the face is  $1/2$  of  $d_{LP}$  (the distance from the cell centroid to the cell centroid of the adjacent cell). The finite volume discretisation of the 1D heat-diffusion equation for the left boundary cell is now:

$$\left(k_r A_r \frac{T_R - T_P}{d_{PR}}\right) - \left(k_l A_l \frac{T_P - T_w}{d_{LP}/2}\right) + \bar{S}V = 0 \quad (29)$$

Again, introduce the notation  $D = k/d$  for the diffusive heat flux per unit area.

$$T_P (2D_l A_l + D_r A_r) = T_R (D_r A_r) + T_w (2D_l A_l) + \bar{S}V \quad (30)$$

For consistency with the interior cell, write in the standard form:

$$a_p T_p = a_L T_L + a_R T_R + S_u \quad (31)$$

$$T_P \underbrace{(0 + D_r A_r + 2D_l A_l)}_{a_p} = T_L \underbrace{(0)}_{a_L} + T_R \underbrace{(D_r A_r)}_{a_R} + \underbrace{T_w (2D_l A_l) + \bar{S}V}_{S_u} \quad (32)$$

For comparison with the interior cell, the boundary cell (left) has the following coefficients:


$$a_L = 0 \quad a_R = D_r A_r \quad a_p = a_L + a_R - S_p \quad (33)$$

$$S_p = -2D_l A_l \quad S_u = \bar{S}V + T_w (2D_l A_l) \quad (34)$$

It follows that the boundary temperature  $T_w$  enters the equation through the source terms  $S_u$  and  $S_p$ . The left coefficient  $a_L$  is also set to zero, as this face is not connected to an interior cell. Using summation notation, the finite volume discretisation for the boundary cell can be written:

$$\begin{aligned} a_p T_P &= \sum_N a_N T_N + S_u \\ a_p &= \left( \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \right) + \frac{k_w A_w}{|\mathbf{d}_{LP}|/2} |\hat{\mathbf{n}}| \quad a_N = \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \\ S_u &= \bar{S}V + T_w \left( \frac{k_w A_w}{|\mathbf{d}_{LP}|/2} |\hat{\mathbf{n}}| \right) \end{aligned} \quad (35)$$

When using summation notation, it should be noted that  $a_N = 0$  for the left boundary face and the summation for  $a_p$  does not include the left boundary face. The wall temperature enters the equation through the source terms  $S_u$  and  $S_p$  as before.



**Figure 6:** The left boundary cell with a temperature  $T_P$  at its centroid. The shared face between the boundary cell and the right cell is at a temperature  $T_r$  and a fixed heat flux of  $q_w$  is applied at the left boundary face. Positive  $q_w$  indicates heat passing out of the domain.

## Boundary Cell (Left) - Neumann Boundary Condition

Figure 6 shows a schematic diagram of the same boundary cell, but with a fixed heat flux (per unit area)  $q_w$  applied at the left wall, instead of a fixed temperature  $T_w$ . Mathematically, the heat flux from the wall (per unit area)  $q_w$  is given by Fourier's law:

$$q_w = -k \nabla T \cdot \hat{n} \quad [\text{W/m}^2] \quad (36)$$

$$q_w = -k \left( \frac{\partial T}{\partial x}, \frac{\partial T}{\partial y}, \frac{\partial T}{\partial z} \right) \cdot (n_x, n_y, n_z) \quad (37)$$

$$q_w = -k \left( \frac{\partial T}{\partial x} n_x + \frac{\partial T}{\partial y} n_y + \frac{\partial T}{\partial z} n_z \right) \quad (38)$$

where  $\hat{n}$  is the unit normal vector **out of the cell** into the wall. The negative sign is required to ensure that the heat flows in the opposite direction to the temperature gradient (high temperature to low temperature). In 1D, Fourier's Law for the wall heat flux reduces to:

$$q_w = -k \left( \frac{\partial T}{\partial x} n_x + \cancel{\frac{\partial T}{\partial y} n_y} + \cancel{\frac{\partial T}{\partial z} n_z} \right) \quad (39)$$

$$q_w = -k \frac{dT}{dx} n_x \quad [\text{W/m}^2] \quad (40)$$


Hence, the fixed heat flux boundary condition is a type of **Neumann** boundary condition, as the heat flux ( $q_w$ ) is being used to set the temperature gradient at the wall. To understand how heat flux boundary conditions are applied, the finite volume discretisation for a general 1D cell needs to be revisited.

$$\underbrace{\left( kA \frac{dT}{dx} n_x \right)_r}_{\text{Heat Flux Right Face}} + \underbrace{\left( kA \frac{dT}{dx} n_x \right)_l}_{\text{Heat Flux Left Face}} + \bar{S}V = 0 \quad (41)$$

The underlined terms in the above equation actually represent the heat flux **out** of the left and right faces of the cell. To understand why, consider Fourier's Law in 1D across an interior face in the mesh:

$$q = -k \frac{dT}{dx} n_x \quad [\text{W/m}^2] \quad (42)$$





**Figure 7:** Diagram to show the sign convention for positive heat flux through the (a) boundary and (b) interior faces of the mesh.

Substitute this form of Fourier's Law into the finite volume discretisation for the interior cells (equation 41):

$$\underbrace{(-q_r A_r)} + \underbrace{(-q_l A_l)} + \bar{S}V = 0 \quad (43)$$

As the unit normal vector always points out of the cells, each underlined term in the above equation represents a heat flux **out** of the cell, across its faces (except for the source term  $\bar{S}V$ ). Once again, the negative sign ensures that the heat flows in the opposite direction to the temperature gradient (high temperature to low temperature).

When considering the left boundary cell in Figure 6, a fixed heat flux  $q_w$  is applied at the left face.

$$q_w = -k_l \frac{dT}{dx} n_x \quad [\text{W/m}^2] \quad (44)$$

It should be noted that the heat flux out of the wall into the fluid is equal and opposite the heat flux out of the fluid into the wall. For consistency, the convention of positive heat flux passing **out of the fluid cell** into the wall will be taken as positive ( $q_w > 0$ ), while heat flux passing out of the wall into the fluid will be taken as negative ( $q_w < 0$ ). Figure 7 shows a schematic diagram to highlight the heat flux sign convention adopted for boundary and interior cells. Returning to Figure 6, the heat flux across the right face (interior face) of the left boundary cell can be calculated using central differencing from the previous section. Hence, the finite volume discretisation for this boundary cell becomes:

$$k_r A_r \left( \frac{T_R - T_P}{d_{LP}} \right) - q_w A_l + \bar{S}V = 0 \quad (45)$$

As the boundary heat flux per unit area ( $q_w$ ) has units of  $\text{W/m}^2$ , it is multiplied by the face area to obtain the correct units of  $\text{W}$ . To simplify this equation further, the diffusive heat flux per unit area ( $D = k/d$ ) will be introduced again.

$$D_r A_r (T_R - T_p) - q_w A_l + \bar{S}V = 0 \quad (46)$$

$$T_P (D_r A_r) = T_R (D_r A_r) - q_w A_l + \bar{S}V \quad (47)$$

For consistency with the interior cell, write in the standard form:

$$a_p T_p = a_L T_L + a_R T_R + S_u \quad (48)$$

$$T_P \underbrace{(0 + D_r A_r + 0)}_{a_p} = T_L \underbrace{(0)}_{a_L} + T_R \underbrace{(D_r A_r)}_{a_R} + \underbrace{-q_w A_l + \bar{S}V}_{S_u} \quad (49)$$

Hence, the boundary cell (left) has the following coefficients when a Neumann condition is applied:

$$a_L = 0 \quad a_R = D_r A_r \quad a_p = a_L + a_R - S_p \quad (50)$$

$$S_p = 0 \quad S_u = \bar{S}V - q_w A_l \quad (51)$$

Using summation notation, the finite volume discretisation for boundary cells with Neumann boundary conditions can be written:

$$a_p T_P = \sum_N a_N T_N + S_u$$

$$a_p = \left( \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \right) \quad a_N = \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \quad S_u = \bar{S}V - q_w A_l$$

As before, the coefficient  $a_N = 0$  for boundary faces. Notice that unlike the Dirichlet boundary condition, the Neumann boundary condition ( $q_w$ ) only makes a contribution to  $S_u$  and not  $a_p$ .

## Summary of Coefficients

A summary of the finite volume coefficients is provided in the table below for interior and boundary cells. Notice that the only difference between the Dirichlet and Neumann boundary conditions is the coefficients  $S_u$  and  $S_p$ .

Dirichlet Boundary Condition					
Cell Type	$a_L$	$a_R$	$a_p$	$S_p$	$S_u$
Boundary (L)	0	$D_R A_R$	$a_l + a_r - S_p$	$-2D_L A_L$	$T_w(2D_L A_L) + \bar{S}V$
Interior	$D_L A_L$	$D_R A_R$	$a_l + a_r - S_p$	0	$\bar{S}V$
Boundary (R)	$D_L A_L$	0	$a_l + a_r - S_p$	$-2D_R A_R$	$T_w(2D_R A_R) + \bar{S}V$

Neumann Boundary Condition					
Cell Type	$a_L$	$a_R$	$a_p$	$S_p$	$S_u$
Boundary (L)	0	$D_R A_R$	$a_l + a_r - S_p$	0	$-q_w A_l + \bar{S}V$
Interior	$D_L A_L$	$D_R A_R$	$a_l + a_r - S_p$	0	$\bar{S}V$
Boundary (R)	$D_L A_L$	0	$a_l + a_r - S_p$	0	$-q_w A_r + \bar{S}V$

The summation notation can also be summarised in a table. However, rather than arranging by cell type, this table is arranged by the face type on each cell. The contribution of each face to the cell total is then given (noting that we sum over the  $N$  cell faces):

Summation Notation			
Face Type	$a_P$	$a_N$	$S_u$
Interior	$\frac{k_N A_N}{ \mathbf{d}_{PN} }  \hat{\mathbf{n}} $	$\frac{k_N A_N}{ \mathbf{d}_{PN} }  \hat{\mathbf{n}} $	0
Dirichlet	$\frac{k_w A_w}{ \mathbf{d}_{LP} /2}  \hat{\mathbf{n}} $	0	$T_w \left( \frac{k_w A_w}{ \mathbf{d}_{LP} /2}  \hat{\mathbf{n}}  \right)$
Neumann	0	0	$-q_w A_w$

If the above (summation notation) table is used to assemble the equations, it should be remembered that the additional volumetric source contribution ( $\bar{S}V$ ), which is not included in the table, is still required.

## Assemble and Solve the Equations

As shown in the previous course, once the coefficients ( $a_p, a_l, a_r, S_u$ ) have been calculated, the finite volume equations can be assembled in matrix form. Start by writing an equation for each cell in the mesh. If the mesh has 5 cells, then the equations are:


Cell 1	Boundary Cell (Left)	$a_{p1}T_1 = a_{r1}T_2 + S_{u1}$
Cell 2	Interior Cell	$a_{p2}T_2 = a_{l2}T_1 + a_{r2}T_3 + S_{u2}$
Cell 3	Interior Cell	$a_{p3}T_3 = a_{l3}T_2 + a_{r3}T_4 + S_{u3}$
Cell 4	Interior Cell	$a_{p4}T_4 = a_{l4}T_3 + a_{r4}T_5 + S_{u4}$
Cell 5	Boundary Cell (Right)	$a_{p5}T_5 = a_{l5}T_4 + S_{u5}$

where the coefficients  $a_p, a_L, a_R$  and  $S_u$  are given in the summary in the previous section. Rearrange the equations, so that all the temperatures ( $T_P, T_L$  and  $T_R$ ) are on the left hand side and the source terms ( $S_u$ ) are on the right hand side.

Cell 1	Boundary Cell (Left)	$a_{p1}T_1 - a_{r1}T_2 = S_{u1}$
Cell 2	Interior Cell	$-a_{l2}T_1 + a_{p2}T_2 - a_{r2}T_3 = S_{u2}$
Cell 3	Interior Cell	$-a_{l3}T_2 + a_{p3}T_3 - a_{r3}T_4 = S_{u3}$
Cell 4	Interior Cell	$-a_{l4}T_3 + a_{p4}T_4 - a_{r4}T_5 = S_{u4}$
Cell 5	Boundary Cell (Right)	$-a_{l5}T_4 + a_{p5}T_5 = S_{u5}$

These equations can now be written concisely in matrix form ( $\mathbf{AT} = \mathbf{B}$ ):

$$\begin{bmatrix} a_{p1} & -a_{r1} & 0 & 0 & 0 \\ -a_{l2} & a_{p2} & -a_{r2} & 0 & 0 \\ 0 & -a_{l3} & a_{p3} & -a_{r3} & 0 \\ 0 & 0 & -a_{l4} & a_{p4} & -a_{r4} \\ 0 & 0 & 0 & -a_{l5} & a_{p5} \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} S_{u1} \\ S_{u2} \\ S_{u3} \\ S_{u4} \\ S_{u5} \end{bmatrix} \quad (52)$$



**Figure 8:** An example problem to demonstrate 1D heat diffusion in a bar. Two cases will be considered: (a) a fixed temperature ( $T_A$ ) of  $100^\circ\text{C}$  at the left end of the bar and (b) a fixed heat flux ( $q_w$ ) of  $100\text{W/m}^2$  at the left end of the bar.

Notice that the matrices have a diagonal banded structure. This is because the mesh is structured (the cells are ordered in a regular pattern) and the coefficients represent the connectivity to the neighbouring cells. The banded structure of the matrices will change slightly in later chapters, when 2D meshes are considered.

Commercial CFD solvers populate the matrices by calculating the coefficients ( $a_l$ ,  $a_p$  and  $a_r$ ) automatically for the user and then solve the matrix equations. In the next section, the entire process will be demonstrated with an example problem. A mesh will be defined, the coefficients will be calculated and then the matrices will be constructed and solved.

## Example Problem - Heat Diffusion in a Bar

To demonstrate the difference between the Neumann and Dirichlet boundary conditions an example problem will now be considered. Consider 1D steady-state diffusion of heat in a bar, as shown in Figure 8 (b). For ease of comparison, this example problem has the same geometry, mesh and material properties as the previous course. However, at the left hand end, a heat flux boundary condition will be applied (Figure 8 (b)), rather than a fixed temperature boundary condition (Figure 8 (a)), as was applied in the previous course. The bar has a length of 5m, a cross-sectional area of  $0.1\text{m}^2$  and a thermal conductivity of  $100\text{W/mK}$ . The temperature at the right end of the bar ( $T_B$ ) is  $200^\circ\text{C}$ . There is a constant heat source ( $\bar{S}$ ) of  $1000\text{W/m}^3$  in the bar. At the left end of the bar, a fixed heat flux ( $q_w$ ) of  $100\text{W/m}^2$  will be applied, rather than a fixed temperature ( $T_A$ ) of  $100^\circ\text{C}$ , as was applied in the previous course.

### Step 1: Divide the Geometry into a Mesh

For the example in Figure 8, divide the geometry into a mesh of 5 cells of equal length. The length of each cell ( $L_{\text{cell}}$ ) is given by:

$$L_{\text{cell}} = \frac{L}{N} = \frac{5}{5} = 1\text{m} \quad (53)$$

Because the cells are uniformly distributed and have equal size, the distance between cell centroids  $d$  is equivalent to the length of the cells. Hence:

$$d_{LP} = d_{PR} = d = 1\text{m} \quad (54)$$

## Step 2: Assign Material Properties

The thermal conductivity  $k$  and the cross-sectional area  $A$  are the same for every cell in the mesh. Hence, the parameter  $DA$  is given by:

$$DA = \frac{kA}{d} = \frac{100 * 0.1}{1} = 10 \text{ [W/K]} \quad (55)$$

The volumetric heat source in each cell is given by:

$$\bar{S}V = \bar{S}AL_{\text{cell}} = 1000 * 0.1 * 1 = 100 \text{ [W]} \quad (56)$$

## Step 3: Calculate Matrix Coefficients

Now calculate the coefficients required to assemble the matrices. The most straightforward way is to fill in the table of coefficients:

Neumann Boundary Conditions (at the left end of the bar)					
	$a_L$	$a_R$	$S_p$	$S_u$	$a_p$
Boundary (Left)	0	10	<b>0</b>	<b>90</b>	<b>10</b>
Interior	10	10	0	100	20
Boundary (Right)	10	0	-20	4100	30

For comparison, the matrix coefficients for the same problem with a Dirichlet boundary condition (fixed temperature) at the left end are shown below. The differences between the two sets of matrix coefficients are highlighted in red.

Dirichlet Boundary Conditions (at the left end of the bar)					
	$a_L$	$a_R$	$S_p$	$S_u$	$a_p$
Boundary (Left)	0	10	<b>-20</b>	<b>2100</b>	<b>30</b>
Interior	10	10	0	100	20
Boundary (Right)	10	0	-20	4100	30

Alternatively, the summation notation summary table can be filled in (noting that an additional source  $\bar{S}V = 100\text{W}$  is required in each cell):

## Dirichlet Boundary Conditions (at the left end of the bar)

Face Type	$a_P$	$a_N$	$S_u$
Interior	10	10	0
Dirichlet (Left)	20	0	2000
Dirichlet (Right)	20	0	4000
Neumann (Left)	0	0	-10

**Step 4: Assemble the Matrices**

Assign the coefficients to their correct locations in the matrix. Note that the final matrices will be identical, regardless of the method used to calculate the coefficients (summation notation,  $D = k/d$ , or otherwise).

For the Neumann (fixed heat flux) boundary condition at the left end:

$$\begin{bmatrix} \mathbf{10} & -10 & 0 & 0 & 0 \\ -10 & 20 & -10 & 0 & 0 \\ 0 & -10 & 20 & -10 & 0 \\ 0 & 0 & -10 & 20 & -10 \\ 0 & 0 & 0 & -10 & 30 \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} \mathbf{90} \\ 100 \\ 100 \\ 100 \\ 4100 \end{bmatrix} \quad (57)$$

and for the Dirichlet boundary condition (fixed temperature) at the left end:

$$\begin{bmatrix} \mathbf{30} & -10 & 0 & 0 & 0 \\ -10 & 20 & -10 & 0 & 0 \\ 0 & -10 & 20 & -10 & 0 \\ 0 & 0 & -10 & 20 & -10 \\ 0 & 0 & 0 & -10 & 30 \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} \mathbf{2100} \\ 100 \\ 100 \\ 100 \\ 4100 \end{bmatrix} \quad (58)$$


Once again, the differences between the Dirichlet and Neumann boundary conditions are highlighted in red.

**Step 5: Solve the Equations**

Now that the matrices have been assembled, the matrix equation can be solved with an appropriate *iterative method*. As with the previous course, different algorithms to solve the matrix equation  $\mathbf{AT} = \mathbf{B}$  will not be considered, as details can be found in any comprehensive text on linear algebra. Instead, the default algorithms used by Excel and Python will be used, as this is not the focus of this course.

**Run the Example Problem Yourself!**

Now, open either the Excel spreadsheets or the Python source code and solve the problem with the Neumann boundary condition (fixed heat flux) yourself. For the Dirichlet boundary condition, you can use the source code from the previous course.



**Figure 9:** Temperature variation along the 1D bar with a heat flux of (a) 100 W/m<sup>2</sup> and (b) 1000 W/m<sup>2</sup> applied at the left end.

Excel `neumannBoundaryConditions.xlsx`  
 Python `neumannBoundaryConditions.py`

Examine the calculation of the coefficients, the assembly of the matrices and run the code. You can even try changing the strength of the heat flux at the left hand end of the bar ( $q_w$ ), or even set an adiabatic condition (zero heat flux,  $q_w = 0$ ).

## Results

Figure 9 shows the temperature distribution in the bar with a heat flux of 100 W/m<sup>2</sup> applied at the left hand end. For comparison, the analytical solution is also shown:


$$T = \frac{\bar{S}}{2k} (L^2 - x^2) + \frac{q_w}{k}(x - L) + T_B \quad (59)$$

By changing the heat flux at the left boundary from 100 W/m<sup>2</sup> to 1000 W/m<sup>2</sup>, Figure 9(b) shows that the temperature of the left end of the bar is not fixed. The heat flux  $q_w$  implicitly sets the temperature gradient at the left end of the bar (as the thermal conductivity  $k$  is fixed) and the temperature profile develops to match this gradient.

$$q_w = -k \frac{dT}{dx} n_x \quad (60)$$

As a result, when a heat flux boundary condition is applied in a CFD code, the boundary temperature on that surface develops as part of the solution. To calculate the boundary temperature from the CFD solution ( $T_w$ ), the temperature must be extrapolated from the temperature at the cell centroid  $T_1$ . Central differencing can be used to extrapolate the boundary temperature from the temperature at the cell centroids.

$$q_w A_L = -k_L A_L \left( \frac{T_1 - T_A}{d_{LP}/2} \right) n_x \quad D_t A_t = \frac{k_L A_L}{d_{LP}} \quad (61)$$



**Figure 10:** A diagram to show the the heat flux out of the cell across the left ( $Q_l$ ) and right ( $Q_r$ ) faces of the cell.

$$T_A = T_1 + \frac{q_A A_L}{2D_l A_L n_x} \quad (62)$$

The use of central differencing to extrapolate and calculate the boundary temperature can be found in both the Excel spreadsheet and Python source code. Note that for the left boundary face, the unit normal vector ( $n_x$ ) points in the negative  $x$  direction, so  $n_x = -1$ .

## Heat Balancing

Once a CFD solution has been computed, a heat balance can be written for each of the cells in the mesh as an additional check of the solution. To understand the heat balance, start with the general finite volume discretisation for the interior cells:

$$k_l A_l \left( \frac{T_P - T_L}{d_{LP}} \right) n_x + k_r A_r \left( \frac{T_R - T_P}{d_{PR}} \right) n_x + \bar{S}V = 0 \quad (63)$$

The heat flux out of the left face of the cell ( $Q_l$ ) is:

$$Q_l = -k_l A_l \left( \frac{T_P - T_L}{d_{LP}} \right) n_x \quad [\text{W}] \quad (64)$$

and the heat flux out of the right face of the cell ( $Q_r$ ) is:

$$Q_r = -k_r A_r \left( \frac{T_R - T_P}{d_{PR}} \right) n_x \quad [\text{W}] \quad (65)$$

The negative sign is required to ensure that the heat flows in the opposite direction to the temperature gradient and the unit normal vector ensures that heat fluxes out of the cell are positive. Substitute these definitions into the general finite volume discretisation for the interior cell:

$$-Q_l - Q_r + \bar{S}V = 0 \quad (66)$$

For the left boundary cell, the distance from the boundary cell centroid to the wall is  $d_{LP}/2$ , so the heat flux balance is:

$$-2Q_l - Q_r + \bar{S}V = 0 \quad (67)$$

Likewise, for the right boundary face:

$$-Q_l - 2Q_r + \bar{S}V = 0 \quad (68)$$

Physically, these equations state that the sum of the heat fluxes into the cell (positive heat sources  $\bar{S}$  generate heat in the cell) is equal to zero. The equation will now be evaluated



explicitly, using the temperatures that were computed at the cell centroids. Remember that this is a post-processing operation and the temperatures are now known. As the matrix solvers are (generally) iterative, there will be some error in solving the finite volume equations. This error in the heat balance in each cell is given by:

$$\text{Error} = -Q_l - Q_r + \bar{S}V \quad (69)$$

The table below summarises the heat balance for each cell in the mesh:

Cell	$Q_l$ [W]	$Q_r$ [W]	$\bar{S}V$ [W]	Error
1	<b>10</b>	90	100	0
2	-90	190	100	0
3	-190	290	100	0
4	-290	390	100	0
5	-390	<b>490</b>	100	0

Total heat flux out of the bar = 10 + 490 = 500W  
 Total heat generated in the bar = 100 + 100 + 100 + 100 + 100 = 500W

The heat balance is useful as we can easily observe that the total heat flux out of the left and right faces of the bar (highlighted in red in the table), balances the total heat generated in the bar (500W). As both heat fluxes are positive, this indicates that heat is flowing out of the bar at both ends, with the majority of the heat flowing out of the right face as it is at a lower temperature (see Figure 9). As a further check, we can also see that the heat flux boundary condition has been applied correctly to the left boundary cell (cell 1):

$$Q_A = q_w A = 100 * 0.1 = 10 \text{ W} \quad (70)$$

It may be noted that for this problem, the error in the heat balance in every cell is zero. This is because a direct matrix solver has been used to solve the equations. However, real CFD codes use iterative matrix solvers and a small error will generally exist in every cell in the mesh. This error is often called the **residual** of the equation. As a vector, the root-mean-square and maximum values of the vector are often computed and reported to the user (instead of the entire vector) as a measure of the convergence of the solution.

$$\text{RMS} = \sqrt{\text{Error } 1^2 + \text{Error } 2^2 + \text{Error } 3^2 + \text{Error } 4^2 + \text{Error } 5^2} \quad (71)$$

$$\text{MAX} = \max(\text{Error } 1, \text{Error } 2, \text{Error } 3, \text{Error } 4, \text{Error } 5) \quad (72)$$

These are the values that are typically shown to the user as convergence graphs in the graphical user interface (GUI) of the CFD code.

## 2 Transport Equations in 2D

The heat diffusion equation will now be solved in 2D ( $x$  and  $y$ ) rather than just 1D ( $x$ ) using the finite volume method. This same approach can be used to integrate and solve any transport equation (momentum, turbulence, species concentration etc.) under consideration. Starting with the heat diffusion equation in vector notation:

$$0 = \nabla \cdot (k\nabla T) + S \quad (73)$$

In 2D Cartesian coordinates, the derivatives can be expanded to give:

$$0 = \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) + S \quad (74)$$

Following the same approach as the previous chapter, integrate the equation over a finite control volume (cell) with volume  $V$ .

$$0 = \int_V \left[ \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) + S \right] dV \quad (75)$$

Once again, split the integral into diffusion and source components. This is permissible as integration and addition are commutative operations (they can be performed in any order without changing the result).

$$0 = \int_V \left[ \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) \right] dV + \int_V [S] dV \quad (76)$$

As before, the source term is averaged over the control volume, so that it can be moved outside the integral.

$$0 = \int_V \left[ \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) \right] dV + \bar{S} \int_V dV \quad (77)$$

$$0 = \int_V \left[ \frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) \right] dV + \bar{S}V \quad (78)$$

The volume integral of the diffusion term can be simplified using Gauss's divergence theorem. Recall (from the previous course) that the divergence theorem for a general vector field  $\mathbf{B}$  is written as:

$$\int_V (\nabla \cdot \mathbf{B}) dV = \int_A (\mathbf{B} \cdot \hat{\mathbf{n}}) dA \quad (79)$$


$$\int_V \left( \frac{\partial B_x}{\partial x} + \frac{\partial B_y}{\partial y} + \frac{\partial B_z}{\partial z} \right) dV = \int_A (B_x n_x + B_y n_y + B_z n_z) dA \quad (80)$$

where  $\hat{\mathbf{n}}$  is the unit normal vector pointing out of the control volume and  $A$  is the surface area of the control volume. In 2D, the divergence theorem can be written:

$$\int_V \left( \frac{\partial B_x}{\partial x} + \frac{\partial B_y}{\partial y} \right) dV = \int_A (B_x n_x + B_y n_y) dA \quad (81)$$

For the 2D heat diffusion equation  $\mathbf{B} = k\nabla T$ . Hence  $B_x = k \partial T / \partial x$  and  $B_y = k \partial T / \partial y$ . Applying the 2D divergence theorem to the 2D heat diffusion equation leads to:

$$0 = \int_A \left[ k \frac{\partial T}{\partial x} n_x + k \frac{\partial T}{\partial y} n_y \right] dA + \bar{S}V \quad (82)$$



**Figure 11:** A diagram to show the face normal vectors on the left ( $l$ ), right ( $r$ ), top ( $t$ ) and bottom ( $b$ ) faces of the 2D cell. The cell normal vectors always point out of the cell.

The cell has a finite number of faces ( $N$ ). For a quadrilateral cell  $N = 4$ , while for a triangular cell  $N = 3$ . Hence, the surface integral over the entire surface can be replaced with an integral over each of the  $N$  faces of the cell.

$$0 = \sum_N \int_A \left[ k \frac{\partial T}{\partial x} n_x + k \frac{\partial T}{\partial y} n_y \right] dA + \bar{S}V \quad (83)$$

In the second-order finite volume method, the flow quantities all vary linearly across the face. The integral across the face can therefore be reduced to the value at the centre of the face (a constant value).

$$0 = \sum_N \left[ k \frac{\partial T}{\partial x} n_x + k \frac{\partial T}{\partial y} n_y \right] \int_A dA + \bar{S}V \quad (84)$$

$$0 = \sum_N \left[ k \frac{\partial T}{\partial x} n_x + k \frac{\partial T}{\partial y} n_y \right] A + \bar{S}V \quad (85)$$

It may be noted that this is equivalent to:


$$0 = \sum_N [kA (\nabla T \cdot \hat{n})] + \bar{S}V \quad (86)$$

To simplify the equation further, consider the 2D quadrilateral cell in Figure 11. The cell has a left face ( $l$ ), a right face ( $r$ ), a top face ( $t$ ) and a bottom face ( $b$ ). The unit normal vectors always point out of the cell. As the  $x$  direction is positive left to right and the  $y$  direction is positive bottom to top, the unit normal vectors on each face are:

Face	$n_x$	$n_y$
Left ( $l$ )	-1	0
Right ( $r$ )	1	0
Bottom ( $b$ )	0	-1
Top ( $t$ )	0	1

Hence, the finite volume discretisation can be simplified further:

$$0 = \left( kA \frac{\partial T}{\partial x} \right)_r - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial y} \right)_t - \left( kA \frac{\partial T}{\partial y} \right)_b + \bar{S}V \quad (87)$$



**Figure 12:** A diagram to show the distance between the cell centroid and the left cell ( $d_{LP}$ ), right cell ( $d_{PR}$ ), bottom cell ( $d_{BP}$ ) and top cell ( $d_{PT}$ ).

This discretisation is valid for all cells in the mesh that are the same shape and orientation as the quadrilateral cell in Figure 11 (a regular structured mesh). To simplify further, the interior and boundary cells need to be considered separately.

## Interior Cells

Starting with the general finite volume discretisation for the 2D quadrilateral cell:

$$0 = \left( kA \frac{\partial T}{\partial x} \right)_r - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial y} \right)_t - \left( kA \frac{\partial T}{\partial y} \right)_b + \bar{S}V \quad (88)$$

Central differencing will be used for all of the diffusion terms. Using the notation in Figure 12 for the distances between the cell centroids ( $d$ ):

$$0 = k_r A_r \frac{T_R - T_P}{d_{PR}} - k_l A_l \frac{T_P - T_L}{d_{LP}} + k_t A_t \frac{T_T - T_P}{d_{PT}} - k_b A_b \frac{T_P - T_B}{d_{BP}} + \bar{S}V \quad (89)$$

As before, the lowercase subscript notation ( $l, r, b, t$ ) is used to refer to the faces of the cell and the uppercase subscript notation ( $L, R, B, T, P$ ) is used to refer to the cell centroids. For simplicity, introduce the diffusive flux per unit area  $D = k/d$ , which has units of  $W/m^2K$ .


$$0 = D_r A_r (T_R - T_P) - D_l A_l (T_P - T_L) + D_t A_t (T_T - T_P) - D_b A_b (T_P - T_B) + \bar{S}V \quad (90)$$

Rearrange and group the terms by cell centroid temperatures ( $T_P, T_R, T_L, T_T, T_B$ ).

$$T_P [D_l A_l + D_r A_r + D_b A_b + D_t A_t] = T_L [D_l A_l] + T_R [D_r A_r] + T_B [D_b A_b] + T_T [D_t A_t] + \bar{S}V \quad (91)$$

Manipulate the equation slightly (add a zero to the  $T_P$  bracket) to express in standard form.

$$T_P \underbrace{[D_l A_l + D_r A_r + D_b A_b + D_t A_t + 0]}_{a_p} = T_L \underbrace{[D_l A_l]}_{a_L} + T_R \underbrace{[D_r A_r]}_{a_R} + T_B \underbrace{[D_b A_b]}_{a_B} + T_T \underbrace{[D_t A_t]}_{a_B} + \underbrace{\bar{S}V}_{S_u} \quad (92)$$



**Figure 13:** The boundary cell at the left of the domain with temperature  $T_P$  at its centroid. The wall (the left face of the cell) is at a fixed temperature  $T_{\text{wall}}$  and is shown in red.

The standard form is similar to the standard form used for the 1D diffusion equation.

$$\begin{aligned} a_p T_P &= a_L T_L + a_R T_R + a_B T_B + a_T T_T + S_u & [2D] \\ a_p T_P &= a_L T_L + a_R T_R + S_u & [1D] \end{aligned} \quad (93)$$

With the following coefficients for interior cells:

$$\begin{aligned} a_p &= a_L + a_R + a_T + a_B - S_p \\ a_L &= D_l A_l & a_R &= D_r A_r & a_B &= D_b A_b & a_T &= D_t A_t \\ S_p &= 0 & S_u &= \bar{S}V \end{aligned} \quad (94)$$

Using summation notation (from the previous chapter), the finite volume discretisation is identical to the 1D discretisation from the previous chapter.

$$\begin{aligned} a_p T_P &= \sum_N a_N T_N + S_u \\ a_p &= \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| & a_N &= \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| & S_u &= \bar{S}V \end{aligned} \quad (95)$$

The summation notation becomes more useful as the number of faces ( $N$ ) increases. Hence, it is often used by real CFD codes (and given in user manuals) as cells in 2D and 3D meshes may have many faces and it is easier to keep track of all the terms in the finite volume discretisation.

## Boundary Cells - Dirichlet Boundary Conditions

Figure 13 shows a boundary cell on the left of the domain, which will be used to simplify the finite volume discretisation for boundary cells. Starting with the general finite volume discretisation for the 2D heat diffusion equation:

$$0 = \left( kA \frac{\partial T}{\partial x} \right)_r - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial y} \right)_t - \left( kA \frac{\partial T}{\partial y} \right)_b + \bar{S}V \quad (96)$$

The right, top and bottom faces are connected to interior cells. Hence, the heat diffusion through these faces can be simplified using the same treatment as the interior cells.

$$0 = D_r A_r (T_R - T_P) - \left( k A \frac{\partial T}{\partial x} \right)_l + D_t A_t (T_T - T_P) - D_b A_b (T_P - T_B) + \bar{S} V \quad (97)$$

In this chapter, fixed value (Dirichlet) boundary conditions will be applied on the left face. However, the method used in the previous chapter for Neumann boundary conditions could be applied instead if desired. The left boundary face is at a temperature  $T_{\text{wall}}$  and the distance to the wall is half the distance to the next cell centroid. Hence the heat diffusion through the left face is:

$$\left( k A \frac{\partial T}{\partial x} \right)_l = k_l A_l \frac{T_P - T_{\text{wall}}}{d_{LP}/2} = 2D_l A_l (T_P - T_{\text{wall}}) \quad (98)$$

Substitute into the finite volume discretisation:

$$0 = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_{\text{wall}}) + D_t A_t (T_T - T_P) - D_b A_b (T_P - T_B) + \bar{S} V \quad (99)$$

Rearrange and group the terms by cell centroid temperatures ( $T_P, T_R, T_L, T_T, T_B$ ).

$$\begin{aligned} T_P [0 + D_r A_r + D_b A_b + D_t A_t + 2D_l A_l] &= T_L [0] + T_R [D_r A_r] \\ &+ T_B [D_b A_b] + T_T [D_t A_t] \\ &+ T_{\text{wall}} [2D_l A_l] + \bar{S} V \end{aligned} \quad (100)$$

The equation is now in standard form:

$$T_P \underbrace{[0 + D_r A_r + D_b A_b + D_t A_t + 2D_l A_l]}_{a_p} = T_L \underbrace{[0]}_{a_L} + T_R \underbrace{[D_r A_r]}_{a_R} \quad (101)$$

$$+ T_B \underbrace{[D_b A_b]}_{a_B} + T_T \underbrace{[D_t A_t]}_{a_T} \quad (102)$$

$$+ \underbrace{T_{\text{wall}} [2D_l A_l] + \bar{S} V}_{S_u} \quad (103)$$


With the following coefficients:

$$\begin{aligned} a_p &= a_L + a_R + a_T + a_B - S_p \\ a_L &= 0 \quad a_R = D_r A_r \quad a_B = D_b A_b \quad a_T = D_t A_t \\ S_p &= -2D_l A_l \quad S_u = T_{\text{wall}}(2D_l A_l) + \bar{S} V \end{aligned} \quad (104)$$

Using summation notation (from the previous chapter), the finite volume discretisation is identical to the 1D discretisation from the previous chapter.

$$\begin{aligned} a_p T_P &= \sum_N a_N T_N + S_u \\ a_p &= \left( \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \right) + \frac{k_w A_w}{|\mathbf{d}_{LP}|/2} |\hat{\mathbf{n}}| \quad a_N = \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \\ S_u &= \bar{S} V + T_{\text{wall}} \left( \frac{k_w A_w}{|\mathbf{d}_{LP}|/2} |\hat{\mathbf{n}}| \right) \end{aligned} \quad (105)$$

Once again it should be remembered that when using the summation notation  $a_N = 0$  for the boundary faces and the summation for  $a_P$  does not include the boundary faces.



**Figure 14:** The boundary cell at the left of the domain with temperature  $T_P$  at its centroid. A fixed heat flux  $q_{\text{wall}}$  is applied at the wall (the left face of the cell).

## Boundary Cells - Neumann Boundary Conditions

Now consider the case where a fixed heat flux (Neumann boundary condition) is applied to the left boundary face, as shown in Figure 14. Starting with the general finite volume discretisation for the 2D heat diffusion equation:

$$0 = \left( kA \frac{\partial T}{\partial x} \right)_r - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial y} \right)_t - \left( kA \frac{\partial T}{\partial y} \right)_b + \bar{S}V \quad (106)$$

The right, top and bottom faces are connected to interior cells. Hence, the heat flux through these faces can be simplified using the same treatment as the interior cells.

$$0 = D_r A_r (T_R - T_P) - \left( kA \frac{\partial T}{\partial x} \right)_l + D_t A_t (T_T - T_P) - D_b A_b (T_P - T_B) + \bar{S}V \quad (107)$$

With a Neumann boundary condition, the heat flux per unit area **out** of the left face of the cell is:

$$q_{\text{wall}} = -k_l \frac{\partial T}{\partial x} n_x \quad (108)$$

Note that the unit normal vector for this cell  $n_x = -1$ . Hence:

$$q_{\text{wall}} = k_l \frac{\partial T}{\partial x} \quad (109)$$

Hence, the finite volume discretisation now becomes:

$$0 = D_r A_r (T_R - T_P) - q_{\text{wall}} A_l + D_t A_t (T_T - T_P) - D_b A_b (T_P - T_B) + \bar{S}V \quad (110)$$

Rearrange and group the terms by cell centroid temperatures ( $T_P, T_R, T_L, T_T, T_B$ ).

$$\begin{aligned} T_P [0 + D_r A_r + D_b A_b + D_t A_t + 0] &= T_L [0] + T_R [D_r A_r] \\ &+ T_B [D_b A_b] + T_T [D_t A_t] \\ &- q_{\text{wall}} A_l + \bar{S}V \end{aligned} \quad (111)$$

The equation is now in standard form:

$$T_P \underbrace{[0 + D_r A_r + D_b A_b + D_t A_t + 0]}_{a_p} = T_L \underbrace{[0]}_{a_L} + T_R \underbrace{[D_r A_r]}_{a_R} + T_B \underbrace{[D_b A_b]}_{a_B} + T_T \underbrace{[D_t A_t]}_{a_T} + \underbrace{-q_{\text{wall}} A_l + \bar{S}V}_{S_u} \quad (112)$$

With the following coefficients:

$$\begin{aligned} a_p &= a_L + a_R + a_T + a_B - S_p \\ a_L &= 0 \quad a_R = D_r A_r \quad a_B = D_b A_b \quad a_T = D_t A_t \\ S_p &= 0 \quad S_u = -q_{\text{wall}} A_l + \bar{S}V \end{aligned} \quad (113)$$

Using summation notation (from the previous chapter), the finite volume discretisation is identical to the 1D discretisation from the previous chapter.

$$a_p T_P = \sum_N a_N T_N + S_u$$

$$a_p = \left( \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \right) \quad a_N = \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \quad S_u = \bar{S}V - q_w A_w$$


Once again it should be remembered that when using the summation notation  $a_N = 0$  for the boundary faces and the summation for  $a_p$  does not include the boundary faces.

## Summary of Coefficients

The tables below summarise the coefficients for each of the boundary and interior cells in the mesh when Dirichlet and Neumann boundary conditions are applied.

Dirichlet Boundary Condition (2D)						
	$a_L$	$a_R$	$a_B$	$a_T$	$S_p$	$S_u$
Interior	$D_L A_L$	$D_R A_R$	$D_B A_B$	$D_T A_T$	0	$\bar{S}V$
Boundary (L)	0	$D_R A_R$	$D_B A_B$	$D_T A_T$	$-2D_L A_L$	$T_{\text{wall}}(2D_L A_L) + \bar{S}V$
Boundary (R)	$D_L A_L$	0	$D_B A_B$	$D_T A_T$	$-2D_R A_R$	$T_{\text{wall}}(2D_R A_R) + \bar{S}V$
Boundary (B)	$D_L A_L$	$D_R A_R$	0	$D_T A_T$	$-2D_B A_B$	$T_{\text{wall}}(2D_B A_B) + \bar{S}V$
Boundary (T)	$D_L A_L$	$D_R A_R$	$D_T A_T$	0	$-2D_T A_T$	$T_{\text{wall}}(2D_T A_T) + \bar{S}V$





**Figure 15:** The boundary cell at the top-left of the domain with temperature  $T_P$  at its centroid. The top and left walls are at fixed temperatures of  $T_{\text{wall}, l}$  and  $T_{\text{wall}, t}$

### Neumann Boundary Condition (2D)

	$a_L$	$a_R$	$a_B$	$a_T$	$S_p$	$S_u$
Interior	$D_L A_L$	$D_R A_R$	$D_B A_B$	$D_T A_T$	0	$\bar{S}V$
Boundary (L)	0	$D_R A_R$	$D_B A_B$	$D_T A_T$	0	$-q_{\text{wall}} A_l + \bar{S}V$
Boundary (R)	$D_L A_L$	0	$D_B A_B$	$D_T A_T$	0	$-q_{\text{wall}} A_r + \bar{S}V$
Boundary (B)	$D_L A_L$	$D_R A_R$	0	$D_T A_T$	0	$-q_{\text{wall}} A_b + \bar{S}V$
Boundary (T)	$D_L A_L$	$D_R A_R$	$D_T A_T$	0	0	$-q_{\text{wall}} A_t + \bar{S}V$

The summation notation can also be summarised in a table. Following the previous chapter, this table gives the contribution of each face to the cell total:

### Summation Notation

Face Type	$a_P$	$a_N$	$S_u$
Interior	$\frac{k_N A_N}{ \mathbf{d}_{PN} }  \hat{\mathbf{n}} $	$\frac{k_N A_N}{ \mathbf{d}_{PN} }  \hat{\mathbf{n}} $	0
Dirichlet	$\frac{k_w A_w}{ \mathbf{d}_{LP} /2}  \hat{\mathbf{n}} $	0	$T_w \left( \frac{k_w A_w}{ \mathbf{d}_{LP} /2}  \hat{\mathbf{n}}  \right)$
Neumann	0	0	$-q_{\text{wall}} A_w$

It should be emphasised once again that with the summation notation, the contribution of the volumetric source term ( $\bar{S}V$ ) also needs to be included in the total for  $S_u$ .

## Cells with Multiple Boundary Faces

For 2D and 3D meshes, some boundary cells may have more than 1 boundary face. Furthermore, the boundary conditions on these boundary faces may be different. Figure 15 shows an example cell with 2 boundary faces. For this cell, the finite volume discretisation is:

$$0 = \left( kA \frac{\partial T}{\partial x} \right)_r - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial y} \right)_t - \left( kA \frac{\partial T}{\partial y} \right)_b + \bar{S}V \quad (114)$$

The right and bottom faces are connected to interior cells. Hence, central differencing can be used to simplify the heat flux through these faces.

$$0 = k_r A_r \frac{T_R - T_P}{d_{PR}} - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial x} \right)_t - k_b A_b \frac{T_P - T_B}{d_{BP}} + \bar{S}V \quad (115)$$

Introduce the diffusive flux per unit  $D = k/d$ , as normal.

$$0 = D_r A_r (T_R - T_P) - \left( kA \frac{\partial T}{\partial x} \right)_l + \left( kA \frac{\partial T}{\partial x} \right)_t - D_b A_b (T_P - T_B) + \bar{S}V \quad (116)$$

If the boundary faces are at fixed temperatures of  $T_{\text{wall}, l}$  on the left and  $T_{\text{wall}, t}$  on the top, then central differencing can also be used on the boundary faces.

$$0 = D_r A_r (T_R - T_P) - 2D_l A_l (T_P - T_{\text{wall}, l}) + 2D_t A_t (T_{\text{wall}, t} - T_P) - D_b A_b (T_P - T_B) + \bar{S}V \quad (117)$$

Rearrange and collect the temperatures at the cell centroids ( $T_P, T_R, T_T$ ).

$$\begin{aligned} T_P [0 + D_r A_r + D_b A_b + 0 + 2D_l A_l + 2D_t A_t] &= T_L [0] + T_r [D_r A_r] \\ &+ T_B [D_b A_b] + T_P [0] + \bar{S}V \\ &+ T_{\text{wall}, l} (2D_l A_l) + T_{\text{wall}, t} (2D_t A_t) \end{aligned} \quad (118)$$

The equation is in standard form:

$$a_p = a_L + a_R + a_T + a_B - S_p \quad (119)$$

With the following coefficients:


$$\begin{aligned} a_L &= 0 & a_R &= D_r A_r & a_B &= D_b A_b & a_T &= 0 \\ S_p &= -2D_l A_l - 2D_t A_t & S_u &= \bar{S}V + T_{\text{wall}, 1} (2D_l A_l) + T_{\text{wall}, 2} (2D_t A_t) \end{aligned} \quad (120)$$

Hence, when a cell has multiple boundary faces the contribution of those faces to  $a_p = 0$ . These faces then add their contribution to  $S_p$  and  $S_u$  instead.

When using summation notation, additional summation symbols are used in the definition of  $a_p$  and  $S_u$  to emphasise that additional contributions are added for each boundary face  $M$  that the cell has. Otherwise the equations are identical.

$$\begin{aligned} a_p T_P &= \sum_N a_N T_N + S_u \\ a_p &= \left( \sum_N \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \right) + \left( \sum_M \frac{k_w A_w}{|\mathbf{d}_{LP}|/2} |\hat{\mathbf{n}}| \right) & a_N &= \frac{k_N A_N}{|\mathbf{d}_{PN}|} |\hat{\mathbf{n}}| \\ S_u &= \bar{S}V + \sum_M T_{\text{wall}} \left( \frac{k_w A_w}{|\mathbf{d}_{LP}|/2} |\hat{\mathbf{n}}| \right) \end{aligned} \quad (121)$$

Cells with multiple boundary faces will be considered further in the example problem in this chapter.




**Figure 16:** Cell numbering scheme for a 4x4 mesh. The mesh stencil around cell 10 is highlighted.

## Assembling the Matrices

When applying the finite volume method in 2D and 3D, a cell numbering scheme must be adopted to ensure that the correct cells are connected together. Figure 16 shows an example numbering scheme for a mesh with 16 cells (4 x 4). For each cell in the mesh, it is useful to visualise a stencil of 4 cells that surround the cell under consideration (also shown in Figure 16). This stencil allows us to identify the neighbouring cells more easily. As shown in the previous course, an algebraic equation is written for each cell in the mesh individually. For the mesh in Figure 16, the algebraic equations are:

$$\begin{aligned}
 a_{p1}T_1 &= a_{r2}T_2 + a_{b5}T_5 + S_{u1} \\
 a_{p2}T_2 &= a_{l1}T_1 + a_{r3}T_3 + a_{b6}T_6 + S_{u2} \\
 a_{p3}T_3 &= a_{l2}T_2 + a_{r4}T_4 + a_{b7}T_7 + S_{u3} \\
 a_{p4}T_4 &= a_{l3}T_3 + a_{b8}T_8 + S_{u4} \\
 a_{p5}T_5 &= a_{t1}T_1 + a_{r6}T_6 + a_{b9}T_9 + S_{u5} \\
 a_{p6}T_6 &= a_{l2}T_2 + a_{t5}T_5 + a_{r7}T_7 + a_{b10}T_{10} + S_{u6} \\
 a_{p7}T_7 &= a_{l3}T_3 + a_{t6}T_6 + a_{r8}T_8 + a_{b11}T_{11} + S_{u7} \\
 a_{p8}T_8 &= a_{l4}T_4 + a_{t7}T_7 + a_{b12}T_{12} + S_{u8} \\
 a_{p9}T_9 &= a_{r5}T_5 + a_{t10}T_{10} + a_{b13}T_{13} + S_{u9} \\
 a_{p10}T_{10} &= a_{l6}T_6 + a_{r9}T_9 + a_{t11}T_{11} + a_{b14}T_{14} + S_{u10} \\
 a_{p11}T_{11} &= a_{l7}T_7 + a_{r10}T_{10} + a_{t12}T_{12} + a_{b15}T_{15} + S_{u11} \\
 a_{p12}T_{12} &= a_{l8}T_8 + a_{t11}T_{11} + a_{b16}T_{16} + S_{u12} \\
 a_{p13}T_{13} &= a_{t9}T_9 + a_{r14}T_{14} + S_{u13} \\
 a_{p14}T_{14} &= a_{l10}T_{10} + a_{t13}T_{13} + a_{r15}T_{15} + S_{u14} \\
 a_{p15}T_{15} &= a_{l11}T_{11} + a_{t14}T_{14} + a_{r16}T_{16} + S_{u15} \\
 a_{p16}T_{16} &= a_{l12}T_{12} + a_{t15}T_{15} + S_{u16}
 \end{aligned} \tag{122}$$



**Figure 17:** Example geometry used for heat diffusion in a 2D plate.

As before, the equations are then arranged into matrix form.

$$\mathbf{A} = \begin{bmatrix}
 a_{p1} & -a_{r2} & 0 & 0 & -a_{b5} & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 -a_{l1} & a_{p1} & -a_{r3} & 0 & 0 & -a_{b6} & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 0 & -a_{l2} & a_{p3} & -a_{r4} & 0 & 0 & -a_{b7} & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 0 & 0 & -a_{l3} & a_{p4} & -a_{r5} & 0 & 0 & -a_{b8} & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 -a_{t1} & 0 & 0 & -a_{l4} & a_{p5} & -a_{r6} & 0 & 0 & -a_{b9} & 0 & 0 & 0 & 0 & 0 & 0 \\
 0 & -a_{t2} & 0 & 0 & -a_{l5} & a_{p6} & -a_{r7} & 0 & 0 & -a_{b10} & 0 & 0 & 0 & 0 & 0 \\
 0 & 0 & -a_{t3} & 0 & 0 & -a_{l6} & a_{p7} & -a_{r8} & 0 & 0 & -a_{b11} & 0 & 0 & 0 & 0 \\
 0 & 0 & 0 & -a_{t4} & 0 & 0 & -a_{l7} & a_{p8} & -a_{r9} & 0 & 0 & -a_{b12} & 0 & 0 & 0 \\
 0 & 0 & 0 & 0 & -a_{t5} & 0 & 0 & -a_{l8} & a_{p9} & -a_{r10} & 0 & 0 & -a_{b13} & 0 & 0 \\
 0 & 0 & 0 & 0 & 0 & -a_{t6} & 0 & 0 & -a_{l9} & a_{p10} & -a_{r11} & 0 & 0 & -a_{b14} & 0 \\
 0 & 0 & 0 & 0 & 0 & 0 & -a_{t7} & 0 & 0 & -a_{l10} & a_{p11} & -a_{r12} & 0 & 0 & -a_{b15} \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & -a_{t8} & 0 & 0 & -a_{l11} & a_{p12} & -a_{r13} & 0 & 0 & -a_{b16} \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -a_{t9} & 0 & 0 & -a_{l12} & a_{p13} & -a_{r14} & 0 & 0 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -a_{t10} & 0 & 0 & -a_{l13} & a_{p14} & -a_{r15} & 0 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -a_{t11} & 0 & 0 & -a_{l14} & a_{p15} & -a_{r16} \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -a_{t12} & 0 & 0 & -a_{l15} & a_{p16}
 \end{bmatrix}$$


$$\mathbf{T} = [T_1 \ T_2 \ T_3 \ T_4 \ T_5 \ T_6 \ T_7 \ T_8 \ T_9 \ T_{10} \ T_{11} \ \dots \\
 \dots \ T_{12} \ T_{13} \ T_{14} \ T_{15} \ T_{16}]^T \tag{123}$$

$$\mathbf{B} = [S_{u1} \ S_{u2} \ S_{u3} \ S_{u4} \ S_{u5} \ S_{u6} \ S_{u7} \ S_{u8} \ S_{u9} \ S_{u10} \ S_{u11} \ \dots \\
 \dots \ S_{u12} \ S_{u13} \ S_{u14} \ S_{u15} \ S_{u16}]^T \tag{124}$$

In the same manner as the 1D flow case, the  $\mathbf{A}$  matrix has a diagonal banded structure. However, rather than having 2 off-diagonal bands (representing the left and right faces of the cell), the matrix now has 4 bands. The additional bands represent the connectivity to the top and bottom cells.

## Example Problem - Heat Diffusion in a 2D Plate

Consider steady-state diffusion of heat in a 2D plate, as shown in Figure 17. The plate has a length of 4m, a width of 4m, a thickness of 0.1m and a thermal conductivity of 100 W/mK.



**Figure 18:** A diagram to show the dimensions of a cell in the mesh. The cross-sectional area that is used to calculate the heat fluxes in the  $x$  direction is highlighted in red and the cross-sectional area that is used to calculate the heat fluxes in the  $y$  direction is highlighted in green.

The temperature on the sides of the plate are fixed at  $100^{\circ}\text{C}$ ,  $150^{\circ}\text{C}$ ,  $200^{\circ}\text{C}$  and  $250^{\circ}\text{C}$  on the left, bottom, right and top faces respectively. There is a constant heat source of  $1000 \text{ W/m}^3$  in the plate. The temperature field in the plate is governed by the 2D steady-state diffusion equation.

$$\frac{\partial}{\partial x} \left( k \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k \frac{\partial T}{\partial y} \right) + S = 0 \quad (125)$$

### Step 1: Divide the Geometry into a Mesh

For the example in Figure 17, divide the geometry into a mesh of 16 quadrilateral cells (4 cells in each direction). These cells have equal length and equal width. The length of each cell ( $L_{\text{cell}}$ ) is given by:

$$L_{\text{cell}} = \frac{L}{N} = \frac{4}{4} = 1\text{m} \quad (126)$$

Because the cells are uniformly distributed and have equal size, the distance between cell centroids  $d$  is equivalent to the length of the cells. Hence:

$$d_{LP} = d_{PR} = d_{BP} = d_{PT} = d = 1\text{m} \quad (127)$$

As shown in Figure 18, the cross-sectional area of all of the cells (in the  $x$  and  $y$  directions) is:

$$A = 1.0 * 0.1 = 0.1\text{m}^2 \quad (128)$$

### Step 2: Assign Material Properties

The thermal conductivity  $k$  and the cross-sectional area  $A$  are the same for every cell in the mesh. Hence, the parameter  $DA$  is given by:

$$DA = \frac{kA}{d} = \frac{100 * 0.1}{1} = 10 \text{ [W/K]} \quad (129)$$

The heat source in each cell is given by:

$$\overline{SV} = \overline{S}L_{\text{cell}}Wt = 1000 * 1 * 1 * 0.1 = 100 \text{ [W]} \quad (130)$$

### Step 3: Calculate Matrix Coefficients

Now calculate the coefficients required to assemble the matrices. The most straightforward way is to fill in the table of coefficients:

Cell	$a_L$	$a_R$	$a_b$	$a_t$	$S_p$	$S_u$	$a_p$
1	0	10	10	0	-40	7100	60
2	10	10	10	0	-20	5100	50
3	10	10	10	0	-20	5100	50
4	10	0	10	0	-40	9100	60
5	0	10	10	10	-20	2100	50
6	10	10	10	10	0	100	40
7	10	10	10	10	0	100	40
8	10	0	10	10	-20	4100	50
9	0	10	10	10	-20	2100	50
10	10	10	10	10	0	100	40
11	10	10	10	10	0	100	40
12	10	0	10	10	-20	4100	50
13	0	10	0	10	-40	5100	60
14	10	10	0	10	-20	3100	50
15	10	10	0	10	-20	3100	50
16	10	0	0	10	-40	7100	60

Alternatively, the summation notation summary table can be filled in (noting that an additional source  $\overline{SV} = 100W$  is required in each cell):

Face Type	$a_P$	$a_N$	$S_u$
Interior	10	10	0
Dirichlet (Left)	20	0	2000
Dirichlet (Bottom)	20	0	3000
Dirichlet (Right)	20	0	4000
Dirichlet (Top)	20	0	5000

### Step 4: Assemble the Matrices

Assign the coefficients to their correct location in the matrix.

$$\mathbf{A} = \begin{bmatrix}
 60 & -10 & 0 & 0 & -10 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 -10 & 50 & -10 & 0 & 0 & -10 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 0 & -10 & 50 & -10 & 0 & 0 & -10 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 0 & 0 & -10 & 60 & 0 & 0 & 0 & -10 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\
 -10 & 0 & 0 & 0 & 50 & -10 & 0 & 0 & -10 & 0 & 0 & 0 & 0 & 0 & 0 \\
 0 & -10 & 0 & 0 & -10 & 40 & -10 & 0 & 0 & -10 & 0 & 0 & 0 & 0 & 0 \\
 0 & 0 & -10 & 0 & 0 & -10 & 40 & -10 & 0 & 0 & -10 & 0 & 0 & 0 & 0 \\
 0 & 0 & 0 & -10 & 0 & 0 & -10 & 50 & 0 & 0 & 0 & -10 & 0 & 0 & 0 \\
 0 & 0 & 0 & 0 & -10 & 0 & 0 & 0 & 50 & -10 & 0 & 0 & -10 & 0 & 0 \\
 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & -10 & 40 & -10 & 0 & 0 & -10 & 0 \\
 0 & 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & -10 & 40 & -10 & 0 & 0 & -10 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & -10 & 50 & 0 & 0 & -10 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & 0 & 60 & -10 & 0 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & -10 & 50 & -10 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & -10 & 50 \\
 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -10 & 0 & 0 & -10 & 60
 \end{bmatrix} \quad (131)$$

$$\mathbf{T} = [T_1 \ T_2 \ T_3 \ T_4 \ T_5 \ T_6 \ T_7 \ T_8 \ T_9 \ T_{10} \ T_{11} \ \dots \\
 \dots \ T_{12} \ T_{13} \ T_{14} \ T_{15} \ T_{16}]^T \quad (132)$$

$$\mathbf{B} = [7100 \ 5100 \ 5100 \ 9100 \ 2100 \ 100 \ 100 \ 4100 \ 2100 \ 100 \ 100 \ \dots \\
 \dots \ 4100 \ 5100 \ 3100 \ 3100 \ 7100]^T \quad (133)$$

### Step 5: Solve the Equations


Now that the matrices have been assembled, the matrix equation can be solved with an appropriate *iterative method*. As with the previous course, different algorithms to solve the matrix equation  $\mathbf{AT} = \mathbf{B}$  will not be considered and the default algorithms used by Excel and Python will be used instead.

### Run the Example Problem Yourself!


Now, open either the Excel spreadsheets or the Python source code and solve the problem yourself.

Excel `solve2DDiffusionEquation.xlsx`

Python `solve2DDiffusionEquation.py`



**Figure 19:** Temperature variation across the 2D plate with (a) a coarse mesh and (b) a fine mesh.



**Figure 20:** A diagram to show the centroids numbering scheme used in the mesh. The centroids are shown as dark blue circles, the boundary nodes as red circles and the interior nodes as white circles.

## Results

Figure 19 shows the temperature variation across the plate with (a) a coarse mesh and (b) a fine mesh. To plot the temperature variation as a contour plot, it is more convenient to plot the temperature at the mesh **nodes** rather than the mesh **centroids**. As shown in Figure 20, this is because the boundary temperatures are specified at the nodes (shown in red) and these would be missed if a contour plot was generated from the mesh centroids (shown in blue).

The CFD solution is computed at the cell centroids. Hence, the interior nodal values (shown in white in Figure 20) have to be computed by interpolating between the centroid values (shown in blue). This interpolation has already been carried out in the Excel spreadsheet and the python source code for you.

## Heat Balancing

Now that a CFD solution has been computed, a heat balance can be written for every cell in the mesh. In the same manner as the previous chapter, the sum of the heat fluxes into the



cell and the heat generated in the cell must be equal to zero for energy to be conserved.

$$0 = k_r A_r \left( \frac{T_R - T_P}{d_{PR}} \right) n_x + k_l A_l \left( \frac{T_P - T_L}{d_{LP}} \right) n_x + k_t A_t \left( \frac{T_T - T_P}{d_{PT}} \right) n_y + k_b A_b \left( \frac{T_P - T_B}{d_{BP}} \right) n_y + \bar{S}V \quad (134)$$

From Fourier's Law, the heat conduction across each face is given by:

$$Q_l = -k_l A_l \left( \frac{T_P - T_L}{d_{LP}} \right) n_x \quad Q_r = -k_r A_r \left( \frac{T_R - T_P}{d_{PR}} \right) n_x$$

$$Q_b = -k_b A_b \left( \frac{T_P - T_B}{d_{BP}} \right) n_y \quad Q_t = -k_t A_t \left( \frac{T_T - T_P}{d_{PT}} \right) n_y \quad (135)$$

The negative sign is required to ensure that the heat flows in the opposite direction to the temperature gradient and the unit normal vectors ensure that positive heat fluxes are out of the cell. By substituting Fourier's Law (equation 135) into the finite volume discretisation (equation 134), the heat balance for each cell can be written in concise form as:

$$-Q_r - Q_l - Q_t - Q_b + \bar{S}V = 0 \quad (136)$$

$$\sum_N (-Q) + \bar{S}V = 0 \quad (137)$$

The error in the heat flux balance for 2D quadrilateral cells can therefore be written as:

$$\text{Error} = -Q_r - Q_l - Q_t - Q_b + \bar{S}V \quad (138)$$

The table below summarises the heat balance for every cell in the mesh. The heat fluxes across the boundaries of the plate are highlighted in blue.

Cell Heat Flux Balance Table

Cell	$Q_l$ [W]	$Q_r$ [W]	$Q_t$ [W]	$Q_b$ [W]	$\bar{S}V$ [W]	Error
1	<b>1575.0</b>	-427.3	<b>-1425.0</b>	377.3	100	0
2	427.3	-109.2	<b>-570.4</b>	352.3	100	0
3	109.2	74.4	<b>-351.9</b>	268.3	100	0
4	-74.4	<b>499.4</b>	<b>-500.6</b>	175.6	100	0
5	<b>820.4</b>	-452.3	-377.3	109.2	100	0
6	452.3	-193.3	-352.3	193.3	100	0
7	193.3	-18.3	-268.3	193.3	100	0
8	18.3	<b>148.1</b>	-175.6	109.2	100	0
9	<b>601.9</b>	-368.3	-109.2	-24.4	100	0
10	368.3	-193.3	-193.3	118.3	100	0
11	192.3	-102.3	-193.3	202.3	100	0
12	102.3	<b>-70.4</b>	-109.2	177.3	100	0
13	<b>650.6</b>	-225.6	24.4	<b>-349.4</b>	100	0
14	225.6	-109.2	-118.3	<b>101.9</b>	100	0
15	109.2	-127.3	-202.3	<b>320.4</b>	100	0
16	127.3	<b>-425.0</b>	-177.3	<b>575.0</b>	100	0

The cell heat flux balance table can also be used to calculate the total heat flux out of each of the faces of the plate (across all the boundaries). By summing the heat flux out of each of the boundary faces (highlighted in blue in the table above):

Boundary	Heat Flux Out [W]	Total [W]
Left	1575.0 + 820.4 + 601.9 + 650.6	3647.9
Right	499.4 + 148.1 - 70.4 - 425.0	152.1
Bottom	-349.4 + 101.9 + 320.4 + 575.0	647.9
Top	-1425 - 570.4 - 351.9 - 500.6	-2847.9
Total		<b>1600</b>

Once again positive heat fluxes indicate heat travelling out of the plate across the boundary, while negative heat fluxes indicate heat travelling into the plate. As the coldest face, the left face of the plate ( $100^{\circ}\text{C}$ ) experiences the largest heat flux out of the plate. Conversely, the top face of the plate experiences a negative heat flux as heat is drawn into the plate by the hot boundary temperature ( $250^{\circ}\text{C}$ ). The total of these heat fluxes (1600W) balances the total heat generated in the plate (1600W), so energy is conserved. As the mesh is refined, the same total heat flux (1600W) is conserved. However, the temperature distribution in the plate and the heat flux across each of the individual cells changes as a result of the mesh refinement.

### 3 Wall Functions

In the second order finite volume method, the flow variables (temperature, velocity, pressure etc.) vary linearly across the cell. Hence, when there are steep gradients in the flow variables, many cells are required to resolve the profiles with sufficient accuracy. As shown in Figure 21, the gradients are particularly steep close to the wall. This is due to the boundary layer that develops on a solid surface in contact with the flow. In order to resolve the steep gradients near the wall accurately, many thin cells are required normal to the wall. The gradients across the cell that is immediately adjacent to the wall are particularly important, as the gradients across this cell determine the wall shear stress and the wall heat flux. In general, the wall shear stress  $\tau_w$  and the wall heat flux  $q_w$  are given by Newton's Law of Viscosity and Fourier's Law of Heat Conduction:

$$\frac{\tau_w}{\rho} = -\nu \left. \frac{\partial U}{\partial y} \right|_{y=0} \quad \frac{q_w}{\rho c_p} = -\alpha \left. \frac{\partial T}{\partial y} \right|_{y=0} \quad (139)$$

where  $\rho$  is the fluid density,  $\nu$  is the kinematic viscosity of the fluid,  $\alpha$  is the thermal diffusivity of the fluid,  $U$  is the velocity component parallel with the wall,  $T$  is the temperature and  $y$  is the direction normal to the wall. As the profile is non-linear (the gradient changes with distance from the wall), the gradient is evaluated at the wall ( $y = 0$ ). The minus sign is required because the wall shear stress acts in the opposite direction to the velocity profile and heat flux is in the opposite direction to the temperature gradient (high temperature to low temperature).


When generating a mesh for CFD simulations, a fine mesh should be used with many thin cells normal to the wall. If the mesh is sufficiently fine, then the piecewise linear variation that is computed by the CFD code has a sufficient number of nodes to accurately reproduce the real flow profile normal to the wall. However, for some flow simulations it is not possible to use many thin cells normal to the wall, as this would lead to a high cell count (and sometimes poor cell quality). For these flow scenarios, the cell adjacent to the wall is too large to accurately reproduce the flow profile. As shown in Figure 22, the velocity and temperature gradients at the wall ( $\partial U/\partial y$  and  $\partial T/\partial y$ ) will be incorrect if the cell is too large. This will lead to inaccuracies in the wall shear stress and wall heat flux (equation 139), unless the CFD code is corrected appropriately. The focus of this Chapter is the method used to correct the flow at the wall when the cells adjacent to the wall are too large.

### Background Theory


In order to compute the correct wall shear stress, the **product** of the near wall kinematic viscosity and the velocity gradient at the wall must be correct.

$$\frac{\tau_w}{\rho} = -\nu \left. \frac{\partial U}{\partial y} \right|_{y=0} = -\text{Kinematic Viscosity} \times \text{Velocity Gradient at the Wall} \quad (140)$$


Hence, even though the gradient at the wall ( $\partial U/\partial y$ ) is incorrect, if the near wall kinematic viscosity ( $\nu$ ) is modified appropriately, then the wall shear stress will be correct. This approach of modifying the near wall kinematic viscosity and the near wall thermal diffusivity is used by the majority of modern CFD codes to correct the solution when the cells are too large.



**Figure 21:** A diagram to show the approximation of a real flow profile (velocity or temperature) by a finite volume mesh. The finite volume method uses a piecewise linear approximation of the real profile.



**Figure 22:** A diagram to show the difference in the piecewise linear approximation of the near wall velocity or temperature profile when (a) thin and (b) large cells are used. The gradient at the wall is incorrect when large cells are used.




**Figure 23:** A diagram to show the linear variation of velocity and temperature across the wall adjacent cell in the mesh.

The velocity and temperature variation across the cell are **always** linear. Hence, as shown in Figure 23, the wall shear stress and wall heat flux computed by the CFD code are:

$$\tau_w = -\rho\nu_w \frac{U_p}{y_p} \quad q_w = -\rho c_p \alpha_w \left( \frac{T_p - T_w}{y_p} \right) \quad (141)$$

where  $y_p$  is the distance from the wall to the wall adjacent cell centroid,  $U_p$  is the velocity at the cell centroid,  $T_p$  is the temperature at the cell centroid and  $T_w$  is the temperature of



**Figure 24:** Experimental measurements of (a) the velocity profile and (b) the temperature profile normal to the wall in a turbulent flow of air over a flat plate.


the wall. The kinematic viscosity  $\nu_w$  and the thermal diffusivity  $\alpha_w$  are now denoted with a subscript  $w$  and will be described as the **near wall** kinematic viscosity ( $\nu_w$ ) and the **near wall** thermal diffusivity ( $\alpha_w$ ). The change in notation is to emphasise that these quantities have been modified. The modification is required to ensure that the product of these quantities and the (incorrect) velocity and temperature gradients produces the correct wall shear stress and wall heat flux. The modification to the near wall kinematic viscosity and the near wall thermal diffusivity is called a **wall function**, as the modification is only carried out in the cells that are adjacent to the wall.

At this stage it should be emphasised that a wall function is a modification to  $\nu_w$  and  $\alpha_w$  in the wall adjacent cell. The wall function is not a modification to the velocity and temperature profiles (despite sometimes being called a velocity or temperature wall function in the literature) because the variation across the cell in a CFD code is always linear. The modifications to  $\alpha_w$  and  $\nu_w$  may result in a change in the velocity and temperature solution fields, but the velocity and temperature in the wall adjacent cell are not set directly by a wall function.

## Wall Functions for $\nu_w$ and $\alpha_w$

In order to propose wall functions for  $\nu_w$  and  $\alpha_w$ , the real variation of velocity and temperature between the cell centroid and the wall is required first. These are the actual velocity and temperature profiles that we are trying to model and are non-linear. Figure 24 shows the real variation of velocity and temperature normal to the wall, which were extracted from experimental measurements of fully developed turbulent flow between 2 parallel plates. Further experimental measurements found this profile to be relatively universal (independent of Reynolds number and streamwise pressure gradient) close to the wall. Hence, the profile is often called '**The Universal Law of the Wall**'. Mathematically, the experimental data in Figure 24 can be reasonably approximated by the following function:

$$U^+ = \begin{cases} y^+ & y^+ < 11.25 \\ \frac{1}{\kappa} \log(Ey^+) & y^+ > 11.25 \end{cases} \quad (142)$$



**Figure 25:** Experimental measurements of (a) the velocity profile and (b) the temperature profile normal to the wall in a turbulent flow of air. The light blue and light green lines show the mathematical functions that are fitted to the data for  $y^+ < y_L^+$  and  $y^+ > y_L^+$  respectively.

where  $\kappa = 0.4187$  and  $E = 9.793$  are empirical constants that were fitted to the data. As shown in Figure 25, these profiles are less accurate at reproducing the experimental data when  $5 < y^+ < 30$  (the buffer region). Hence, it is normally recommended to ensure that  $y^+ < 5$  or  $y^+ > 30$  for the final solution to be accurate.

The two profiles intersect where:

$$y^+ = \frac{1}{\kappa} \log(Ey^+) \quad (143)$$

$$y^+ - \frac{1}{\kappa} \log(Ey^+) = 0 \quad \longrightarrow \quad f(y^+) = 0 \quad (144)$$

Substituting in the empirical coefficients  $E = 9.7983$  and  $\kappa = 0.4187$  and solving for  $y^+$  with a root-finding algorithm (like the bisection method or Newton-Raphson method) results in an intersection point of  $y^+ = 11.25$ . This process of root finding will be demonstrated later in the example problem. A similar mathematical function can also be fitted to the temperature profile.


$$T^+ = \begin{cases} Pr y^+ & y^+ < y_L^+ \\ Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right) & y^+ > y_L^+ \end{cases} \quad (145)$$

where  $Pr = \nu/\alpha$  is the molecular Prandtl number,  $Pr_t$  is the turbulent Prandtl number (0.85) and  $P$  is an empirical function of  $Pr$  and  $Pr_t$ .

$$P = 9.24 \left[ \left( \frac{Pr}{Pr_t} \right)^{3/4} - 1 \right] \left[ 1 + 0.28e^{-0.007Pr/Pr_t} \right] \quad (146)$$

The reason for the differences between the velocity and temperature wall functions is that (unlike the velocity profile) the dimensionless temperature profile is **different for different fluids**. The difference is captured by the molecular Prandtl number  $Pr$ . For water and air for example, the molecular Prandtl numbers are:

	$Pr = \nu/\alpha$
Water	0.71
Air	5.68



**Figure 26:** A diagram to show the differences in the temperature profiles for water and air.

A value of  $Pr < 1$  indicates that thermal energy diffuses into the flow faster than momentum. This means that the thermal boundary layer is thinner than the velocity boundary layer when  $Pr < 1$ . A consequence of the temperature profile being different for different fluids is that the intersection between the 2 profiles does not occur at 11.25 (as it does for the velocity profile). The intersection point  $y_L^+$  can be determined by equating the profiles in equation 145.

$$Pr y^+ = Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right) \quad (147)$$

$$Pr y^+ - Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right) = 0 \quad \longrightarrow \quad f(y^+) = 0 \quad (148)$$

Substitute in the values of  $Pr$  for the fluid of interest. Then solve the non-linear equation for  $y^+$  using a root-finding algorithm (this process will be demonstrated later in the example problem). This is the intersection point of the two curves ( $y_L^+$ ) and is different for different fluids.


	$Pr$	$y_L^+$
Water	0.71	7.1
Air	5.68	11.8

Figure 26 compares the temperature profiles for water and air. Unlike the velocity profile (which is the same for water and air), the profiles are different and have a different intersection point. This difference in the profiles will also be reflected in the wall function for  $\alpha_w$ . Once again it should be emphasised that the mathematical functions for velocity and temperature are **not applied directly** in the CFD code. The equations are actually used to derive equations for the near wall kinematic viscosity  $\nu_w$  and the near wall thermal diffusivity  $\alpha_w$ . This derivation will be demonstrated in the next section. It is these wall functions for  $\nu_w$  and  $\alpha_w$  that are actually applied in the CFD code.

### $y^+$ and $y^*$

The velocity and temperature profiles in equations 142 and 145 are expressed in dimensionless wall units.

$$U^+ = \frac{U}{u_\tau} \quad y^+ = \frac{\rho u_\tau y}{\mu} \quad T^+ = \frac{(T_w - T_p)\rho c_p u_\tau}{q_w} \quad (149)$$



**Figure 27:** A schematic diagram of the experimental set up that was used to derive the velocity profiles normal to the wall.

The reason for using dimensionless units is so that the profiles are universal and can be applied to any flow scenario (flow over an aerofoil, flow in a pipe, flow over a flat plate etc.), as long as we are close to the wall. This is a reasonable theory, as the flow close to the wall at small scales should be universal, regardless of the freestream flow and the overall shape of the geometry.

However, to define these dimensionless groups, appropriate choices of velocity scale ( $u_\tau$ ) and length scale ( $y$ ) are required. Since the flow is close to the wall, the appropriate length scale  $y$  is the distance normal to the wall. For the velocity scale, it would not be appropriate to use the free-stream velocity ( $U_\infty$ ), as the flow is close to the wall where viscous effects are dominant and the velocity is much lower than the freestream velocity. However, the velocity at the wall itself is zero due to the no-slip condition, so this cannot be used as a velocity scale either. The original approach in the experiments was to chose a velocity scale based on the (square-root of the) wall shear stress. This velocity scale ( $u_\tau$ ) is called the friction-velocity.

$$u_\tau = \sqrt{\frac{|\tau_w|}{\rho}} \quad [\text{m/s}] \quad (150)$$

However, the problem with using a friction velocity based on the wall shear stress is that the wall shear stress is zero at separation points. This would result in a friction velocity of 0, which would create difficulties for the CFD code. An alternative is to use a friction velocity based on the turbulent kinetic energy  $k$  (which would have been more difficult to attain in the experiments).

$$u_\tau = \sqrt{C_\mu^{1/2} k} \quad C_\mu = 0.09 \quad (151)$$

A dimensionless velocity scale based on the turbulent kinetic energy is denoted as  $y^*$  rather than  $y^+$  by CFD codes.

$$U^* = \frac{U}{u_\tau} \quad y^* = \frac{\rho u_\tau y}{\mu} \quad T^* = \frac{(T_w - T_p)\rho c_p u_\tau}{q_w} \quad u_\tau = \sqrt{C_\mu^{1/2} k} \quad (152)$$

In most scenarios,  $y^+$  and  $y^*$  are almost identical and either can be used. However, the majority of modern CFD codes prefer to use  $y^*$  in their calculations.

## Deriving a Wall Function for $\nu_w$

We now have a mathematical model for the velocity profile normal to the wall:

$$U^+ = \begin{cases} y^+ & y^+ < 11.25 \\ \frac{1}{\kappa} \log(Ey^+) & y^+ > 11.25 \end{cases} \quad (153)$$



Replace the dimensionless variables with the actual variables ( $U^+ = U/u_\tau$  and  $y^+ = \rho u_\tau y/\mu$ ):

$$\begin{aligned} \frac{U}{u_\tau} &= \frac{\rho u_\tau y}{\mu} & y^+ < 11.25 \\ \frac{U}{u_\tau} &= \frac{1}{\kappa} \log\left(E \frac{\rho u_\tau y}{\mu}\right) & y^+ > 11.25 \end{aligned} \quad (154)$$

The trick to calculating the wall shear stress  $\tau_w$  from these profiles is to write:

$$\frac{U}{u_\tau} = \frac{U u_\tau}{u_\tau^2} \quad (155)$$

Then recall that  $u_\tau = \sqrt{|\tau_w|/\rho}$  and therefore  $u_\tau^2 = -\tau_w/\rho$

$$\frac{U}{u_\tau} = \frac{U u_\tau}{u_\tau^2} = -\frac{U \rho u_\tau}{\tau_w} \quad (156)$$

The velocity profile then becomes:

$$\begin{aligned} -\frac{U \rho u_\tau}{\tau_w} &= \frac{\rho u_\tau y}{\mu} & y^+ < 11.25 \\ -\frac{U \rho u_\tau}{\tau_w} &= \frac{1}{\kappa} \log\left(E \frac{\rho u_\tau y}{\mu}\right) & y^+ > 11.25 \end{aligned} \quad (157)$$

Rearrange for the wall shear stress ( $\tau_w$ ):

$$\begin{aligned} \tau_w &= -\mu \frac{U}{y} & y^+ < 11.25 \\ \tau_w &= -\frac{U \rho u_\tau}{\frac{1}{\kappa} \log\left(E \frac{\rho u_\tau y}{\mu}\right)} & y^+ > 11.25 \end{aligned} \quad (158)$$

This equation gives the **real** wall shear stress that is exhibited by a turbulent velocity profile over a flat plate. In a CFD code, the velocity profile between the wall adjacent cell centroid and the wall is always linear. As shown in Figure 23, the velocity at the cell centroid is  $U_p$  and the cell is a height  $y_p$  normal to the wall. Hence, the wall shear stress **in the CFD code** is always:


$$\tau_w = -\rho \nu \left. \frac{\partial U}{\partial y} \right|_{y=0} = -\rho \nu_w \frac{U_p}{y_p} \quad (159)$$

To ensure that the CFD code always computes the correct wall shear stress, equate equation 159 with equation 158 (noting that the velocity and wall normal distance in equation 158 are now evaluated at the cell centroid,  $U = U_p$  and  $y = y_p$ ).


$$\begin{aligned} -\rho \nu_w \frac{U_p}{y_p} &= -\rho \nu \frac{U_p}{y_p} & y^+ < 11.25 \\ -\rho \nu_w \frac{U_p}{y_p} &= -\frac{U_p \rho u_\tau}{\frac{1}{\kappa} \log\left(E \frac{\rho u_\tau y_p}{\mu}\right)} & y^+ > 11.25 \end{aligned} \quad (160)$$

Rearrange for  $\nu_w$ .

$$\begin{aligned} \nu_w &= \nu & y^+ < 11.25 \\ \nu_w &= \frac{u_\tau y_p}{\frac{1}{\kappa} \log\left(E \frac{\rho u_\tau y_p}{\mu}\right)} & y^+ > 11.25 \end{aligned} \quad (161)$$



**Figure 28:** The variation of near wall kinematic viscosity  $\nu_w$  with  $y^+$



**Figure 29:** A diagram to show the difference in wall treatment when (a)  $y^+ < 11.25$  and (b)  $y^+ > 11.25$


Make a final substitution ( $y^+ = y_p u_\tau / \nu$ ) to simplify the equation:

$$\nu_w = \begin{cases} \nu & y^+ < 11.25 \\ \nu \left( \frac{y^+}{\frac{1}{\kappa} \log(Ey^+)} \right) & y^+ > 11.25 \end{cases} \quad (162)$$

Equation 162 is the **wall function** for the near wall kinematic viscosity  $\nu_w$  and is plotted in Figure 28. Physically, the equation states that if the wall adjacent cell is thin enough ( $y^+ < 11.25$ ), then the near wall kinematic viscosity is set equal to the molecular viscosity of the fluid ( $\nu$ ). This will result in the correct wall shear stress as the true velocity profile is linear. However, if the cell is large ( $y^+ > 11.25$ ), then the CFD code assumes that the velocity profile between the wall adjacent cell centroid and the wall is linear. This is not correct, as the real velocity profile is non-linear. However, if the near wall kinematic viscosity is increased using equation 162, the the **product** of the near wall kinematic viscosity and the (incorrect) velocity gradient will yield the correct wall shear stress.

$$\frac{\tau_w}{\rho} = -\text{Near Wall Kinematic Viscosity} \times \text{Velocity Gradient} \quad (163)$$

Figure 29 shows a diagram to illustrate this process. The astute reader will notice that



**Figure 30:** The variation of the near wall thermal diffusivity  $\alpha_w$  with  $y^+$  for air and water.

equation 162 can be written concisely as:

$$\nu_w = \nu * \left[ \frac{y^+}{f(y^+)} \right] \quad (164)$$

where  $f(y^+)$  is given by equation 153. Hence, if a new function for  $U^+$  is proposed (replacing equation 142), then the wall function for  $\nu_w$  can be deduced directly from the above equation.

It should also be noted that  $y^*$  can be used in place of  $y^+$  in the wall function for near wall kinematic viscosity.

$$\nu_w = \begin{cases} \nu & y^* < 11.25 \\ \nu \left( \frac{y^*}{\frac{1}{\kappa} \log(Ey^*)} \right) & y^* > 11.25 \end{cases} \quad (165)$$


The majority of CFD codes (ANSYS Fluent, ANSYS CFX, Star CCM+) use the  $y^*$  formulation instead of  $y^+$ . OpenFOAM offers the choice of both: `nutUWallFunction` (for  $y^+$ ) and `nutkWallFunction` (for  $y^*$ ).

## Wall Function for $\alpha_w$

The wall function for the near wall thermal diffusivity ( $\alpha_w$ ) takes a similar form to  $\nu_w$ :

$$\alpha_w = \begin{cases} \alpha & y^+ < y_L^+ \\ \alpha \left[ \frac{Pr y^+}{Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right)} \right] & y^+ > y_L^+ \end{cases} \quad (166)$$

For brevity, the derivation will not be provided here, as it follows an identical process to the wall function for  $\nu_w$  in the previous section. The wall function for  $\alpha_w$  is shown in Figure 30 for air and water. In the same manner as  $\nu_w$ , for  $y^+ < y_L^+$ ,  $\alpha_w$  takes the value of the molecular thermal diffusivity  $\alpha$ . For  $y^+ > y_L^+$ , the thermal diffusivity is increased, to ensure that the product of the near wall thermal diffusivity and the temperature gradient gives the correct wall heat flux. Notice (in Figure 30) that air and water have different values of  $y_L^+$



**Figure 31:** An example problem to demonstrate 1D heat diffusion in a bar. A wall function is applied at the right hand end (where the temperature is fixed).

and the rate of increase of  $\alpha_w$  with  $y^+$  is greater for water than air. In general, the shape of the wall function will be different for every fluid, depending on  $Pr$ . The wall function for  $\nu_w$  however, is universal for all fluids.

Now that the wall functions for  $\nu_w$  and  $\alpha_w$  have been presented, the remainder of the chapter will demonstrate how the wall functions are incorporated into CFD codes. This demonstration will be carried through an example problem.

### Example Problem: Heat Diffusion in a Bar

Consider 1D steady-state diffusion of heat in a bar, as shown in Figure 31. The left end of the bar has a fixed heat flux ( $q_{wall}$ ) of  $100 \text{ W/m}^2$ , while the right end of the bar is at a fixed temperature of ( $T_B$ )  $200^\circ\text{C}$ . There is a constant heat source ( $\bar{S}$ ) of  $1000 \text{ W/m}^3$  applied to the bar. The bar has a density of  $8000 \text{ kg/m}^3$  and a specific heat capacity of  $500 \text{ J/kg K}$ . For ease of comparison, this example problem has the same geometry, mesh and boundary conditions as the previous chapter. However, unlike the previous chapter, a wall function for the thermal diffusivity  $\alpha_w$  will be applied at the right hand end (where the fixed temperature is applied). To evaluate the wall function, the material is assumed to have a Prandtl number ( $Pr$ ) of  $0.71$  and the right boundary cell has a  $y^+ = 30$ .

### Step 1: Divide the Geometry into a Mesh

For the example in Figure 31, divide the geometry into a mesh of 5 cells of equal length. The length of each cell ( $L_{cell}$ ) is given by:

$$L_{cell} = \frac{L}{N} = \frac{5}{5} = 1\text{m} \tag{167}$$

Because the cells are uniformly distributed and have equal size, the distance between cell centroids  $d$  is equivalent to the length of the cells. Hence:

$$d_{LP} = d_{PR} = d = 1\text{m} \tag{168}$$

### Step 2: Evaluate the Wall Function

Before the material properties can be assigned, the wall function needs to be evaluated. As the wall function for  $\alpha_w$  is being applied (equation 166), the first stage is to evaluate the empirical

function  $P$ . For a molecular Prandtl number of 0.71 and a turbulent Prandtl number of 0.85, the function  $P$  evaluates as:

$$P = 9.24 \left[ \left( \frac{Pr}{Pr_t} \right)^{3/4} - 1 \right] \left[ 1 + 0.28e^{-0.007Pr/Pr_t} \right] = -1.491 \quad (169)$$

Now the intersection point between the two sections of the wall function ( $y_L^+$ ) needs to be calculated. This requires the solution of the following non-linear equation for  $y^+$  (equation 148):

$$Pr y^+ - Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right) = 0 \quad (170)$$

This non-linear equation can be solved with any root finding algorithm (Bisection, Newton-Raphson etc.). The Newton-Raphson method gives rapid convergence and will be used here. To use the Newton-Raphson method, define:

$$f = Pr y^+ - Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right) \quad (171)$$

$$\frac{df}{dy^+} = Pr - \frac{Pr_t}{\kappa y^+} \quad (172)$$

The Newton-Raphson iteration proceeds by evaluating:

$$y_{i+1}^+ = y_i^+ - \frac{f}{df/dy^+} \quad (173)$$

Starting from an initial guess ( $y_0^+$ ) of 11.0, the Newton-Raphson iteration gives:

Iteration	$y_i^+$	$y_{i+1}^+$
1	11.000	11.806
2	11.806	11.796
3	11.796	11.796

Hence, the solution of the Newton Raphson procedure gives  $y_L^+ = 11.796$  when  $Pr = 0.71$ . Now that  $y_L^+$  has been evaluated,  $\alpha_w$  can be calculated (using equation 166).


$$\alpha_w = \begin{cases} \alpha & y^+ < y_L^+ \\ \alpha \left[ \frac{Pr y^+}{Pr_t \left( \frac{1}{\kappa} \log(Ey^+) + P \right)} \right] & y^+ > y_L^+ \end{cases} \quad (174)$$

In this example,  $y^+ = 30$ . Hence,  $\alpha_w/\alpha = 2.074$  and the near wall thermal diffusivity will be approximately double the thermal diffusivity of the interior cells.

## Step 2: Assign Material Properties

The wall function is applied to the molecular thermal diffusivity  $\alpha$ . The molecular thermal diffusivity is defined as:

$$\alpha = \frac{k}{\rho c_p} \quad (175)$$



**Figure 32:** Thermal conductivity of each of the faces in the mesh when a wall function is applied to the right end of the bar.

where  $k$  is the thermal conductivity,  $\rho$  is the material density and  $c_p$  is the specific heat capacity. For the example problem considered here:

$$\alpha = \frac{k}{\rho c_p} = \frac{100}{8000 * 500} = 2.5 \times 10^{-5} \text{ [m}^2\text{/s]} \quad (176)$$

This is the thermal diffusivity for all the interior cells and interior faces in the mesh. For the right boundary face, the thermal diffusivity is modified by the wall function:

$$\frac{\alpha_w}{\alpha} = 2.074 \quad \alpha_w = 5.185 \times 10^{-5} \text{ [m}^2\text{/s]} \quad (177)$$

As the thermal diffusivity of the right boundary face is now  $\alpha_w$ , then the thermal conductivity of the face  $k_w$  is also modified.

$$k_w = \rho c_p \alpha_w = 8000 * 500 * 5.185 \times 10^{-5} = 207.4 \text{ [W/mK]} \quad (178)$$

It follows that the thermal conductivity of all the faces in the mesh is constant (100 W/mK), except for the right boundary face, where  $k$  is modified by the wall function. The variation of thermal conductivity across the mesh is shown in Figure 32. For the interior cells in the mesh, the diffusive heat flux across the cell faces  $DA$  is given by:

$$DA = \frac{kA}{d} = \frac{100 * 0.1}{1} = 10 \text{ [W/K]} \quad (179)$$

For the right boundary cell, the diffusive heat flux is evaluated using the modified thermal conductivity ( $k_w$ ).

$$DA = \frac{k_w A}{d} = \frac{207.4 * 0.1}{1} = 20.74 \text{ [W/K]} \quad (180)$$

The heat source in each cell is not affected by the wall function. It is given by:

$$\bar{S}V = \bar{S}AL_{\text{cell}} = 1000 * 0.1 * 1 = 100 \text{ [W]} \quad (181)$$

### Step 3: Calculate the Matrix Coefficients

The matrix coefficients for 1D heat diffusion in a bar with fixed temperature (Dirichlet) boundary conditions at the left end and fixed heat flux (Neumann) boundary conditions at the right end are:

## Matrix Coefficients

	$a_L$	$a_R$	$a_P$	$S_p$	$S_u$
Boundary (L)	0	$D_R A_R$	$a_l + a_r - S_p$	0	$-q_A A_L + \bar{S}V$
Interior	$D_L A_L$	$D_R A_R$	$a_l + a_r - S_p$	0	$\bar{S}V$
Boundary (R)	$D_L A_L$	0	$a_l + a_r - \mathbf{S_P}$	$-2\mathbf{D_R A_R}$	$T_B(2\mathbf{D_R A_R}) + \bar{S}V$

However, as a wall function is applied to the right face of the right boundary cell, the coefficient  $D_R$  (highlighted in **red** in the table above) is modified by the wall function. The other coefficients remain unchanged by the wall function. Filling in the table with the calculated coefficients:

## Matrix Coefficients

	$a_L$	$a_R$	$a_P$	$S_p$	$S_u$
Boundary (L)	0	10	10	0	90
Interior	10	10	20	0	100
Boundary (R)	10	0	<b>51.5</b>	<b>-41.5</b>	<b>8395.9</b>

It is clear that the wall function enters the matrix equations through the diagonal coefficient  $a_p$  and the source term  $S_u$  of the cell that contains the boundary face. The coefficients in the other cells remain unchanged.

Using summation notation, the wall function modifies the face contribution of the right boundary face through  $k_w$ . No other changes are made to the face contributions of the other faces.

## Summation Notation

Face Type	$a_P$	$a_N$	$S_u$
Interior	10	10	0
Neumann (Left)	0	0	-10
Dirichlet (Right, No Wall Function)	<b>20</b>	0	<b>4000</b>
Dirichlet (Right, Wall Function)	<b>41.5</b>	0	<b>8295.9</b>

## Step 4: Assemble and Solve the Matrices

As a reminder, the matrices are populated in the following manner:

$$\begin{bmatrix} a_{p1} & -a_{r1} & 0 & 0 & 0 \\ -a_{l2} & a_{p2} & -a_{r2} & 0 & 0 \\ 0 & -a_{l3} & a_{p3} & -a_{r3} & 0 \\ 0 & 0 & -a_{l4} & a_{p4} & -a_{r4} \\ 0 & 0 & 0 & -a_{l5} & a_{p5} \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} S_{u1} \\ S_{u2} \\ S_{u3} \\ S_{u4} \\ S_{u5} \end{bmatrix} \quad (182)$$

Filling in the known coefficients from the table above:

$$\begin{bmatrix} 10 & -10 & 0 & 0 & 0 \\ -10 & 20 & -10 & 0 & 0 \\ 0 & -10 & 20 & -10 & 0 \\ 0 & 0 & -10 & 20 & -10 \\ 0 & 0 & 0 & -10 & \mathbf{51.5} \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} 90 \\ 100 \\ 100 \\ 100 \\ \mathbf{8395.9} \end{bmatrix} \quad (183)$$

For the case when a wall function is not applied,  $D_R A_R = kA/d = 10 \text{ W/mK}$  and the matrices reduce back to the same matrices from the previous chapter.

$$\begin{bmatrix} 10 & -10 & 0 & 0 & 0 \\ -10 & 20 & -10 & 0 & 0 \\ 0 & -10 & 20 & -10 & 0 \\ 0 & 0 & -10 & 20 & -10 \\ 0 & 0 & 0 & -10 & \mathbf{30} \end{bmatrix} \begin{bmatrix} T_1 \\ T_2 \\ T_3 \\ T_4 \\ T_5 \end{bmatrix} = \begin{bmatrix} 90 \\ 100 \\ 100 \\ 100 \\ \mathbf{4100} \end{bmatrix} \quad (184)$$

Hence, the effect of the wall function is localised to the cell where the wall function is applied.

### Run the Example Problem Yourself!

Now, open either the Excel spreadsheets or the Python source code and solve the problem for yourself.

Excel `wallFunction.xlsx`


Python `wallFunction.py`

Examine the calculation of the coefficients, the assembly of the matrices and run the code. A fixed value of  $y^+ = 30$  has been set initially. Try changing the value of  $y^+$  and observe the changes in the solution. Note that in a real CFD code,  $y^+$  changes automatically in response to changes in the mesh. In this problem, we are specifying the value of  $y^+$  **directly** instead, so that we can observe the changes in solution for a **fixed mesh**. Hence, the solution is not strictly accurate, but is useful for demonstration purposes.

## Results

Figure 33 shows the temperature variation along the bar, for different values of  $y^+$  on the right boundary face. Notice that the temperature of the right boundary face is fixed at





**Figure 33:** Temperature variation along the 1D bar with different values of  $y^+$  on the right boundary face.

200°C. However, the temperature of the wall adjacent cell centroid ( $T_5$ ) is modified by the wall function. This results in a change in shape of the entire temperature profile.

The temperature of the wall adjacent cell centroid ( $T_5$ ) is not modified because the wall function changes its temperature directly. The temperature of the cell is modified because the wall function modifies the thermal conductivity of the right face of this cell from 100 W/mK to 207.4 W/mK. In order to maintain the same heat flux from the wall ( $q_w$ ), the temperature gradient ( $dT/dx$ ) is reduced to counterbalance the increase in  $k_w$ . The table below summarises the heat flux balance for every cell in the mesh for a  $y^+$  of (a) 5 and (b) 30. It is clear that the heat flux through the faces of each of the cells remains unchanged by the wall function, but the temperature profile does change (see Figure 33).

## Heat Flux Balance

(a)  $y^+ = 5$ 

Cell	$Q_l$ [W]	$Q_r$ [W]	$\bar{S}V$ [W]	Error
1	<b>10</b>	90	100	0
2	-90	190	100	0
3	-190	290	100	0
4	-290	390	100	0
5	-390	<b>490</b>	100	0

Heat flux out of the bar =  $490 + 10 = 500\text{W}$ Heat generated in the bar =  $100 + 100 + 100 + 100 + 100 = 500\text{W}$ (b)  $y^+ = 30$ 

Cell	$Q_l$ [W]	$Q_r$ [W]	$\bar{S}V$ [W]	Error
1	<b>10</b>	90	100	0
2	-90	190	100	0
3	-190	290	100	0
4	-290	390	100	0
5	-390	<b>490</b>	100	0

Heat flux out of the bar =  $490 + 10 = 500\text{W}$ Heat generated in the bar =  $100 + 100 + 100 + 100 + 100 = 500\text{W}$ 

As the heat flux from the left end of the bar is fixed by the boundary condition (10W) and 500W is generated in the bar, 490W must pass out of the bar at the right end. Hence, as the wall function modifies  $\alpha_w$ , the temperature gradient at the wall changes, so that the heat flux remains the same (490W).

## 2 Inflation Layer Calculator

### First Cell Height

Start by calculating the flow Reynolds number ( $Re$ ).

$$Re = \frac{\rho UL}{\mu} \quad (1)$$

where  $\rho$  is the fluid density,  $U$  is the freestream velocity,  $L$  is the characteristic length of the geometry and  $\mu$  is the dynamic viscosity. An empirical correlation for fully developed turbulent flow over a flat plate is then used to estimate the skin friction coefficient ( $c_f$ ):

$$c_f = [2 \log_{10}(Re) - 0.65]^{-2.3} \quad (2)$$

This particular correlation has been taken from Schlichting (1979) for fully turbulent flow with  $Re < 10^9$ . This correlation could be replaced with any other empirical correlation for turbulent flow over a flat plate. However, as this calculator is only used as an estimate, small differences arising from the choice of correlation do not matter significantly.

Having computed the skin friction coefficient, the wall shear stress ( $\tau_w$ ) is calculated.

$$\tau_w = \frac{1}{2} \rho U^2 c_f \quad (3)$$

The friction velocity ( $u_\tau$ ) can then be computed from the wall shear stress:

$$u_\tau = \sqrt{\frac{\tau_w}{\rho}} \quad (4)$$

Finally, the equation for  $y^+$  can be rearranged to give the height of the wall adjacent cell centroid from the wall ( $y_p$ ):

$$y^+ = \frac{\rho y_p u_\tau}{\mu} \quad (5)$$

$$y_p = \frac{y^+ \mu}{u_\tau \rho} \quad (6)$$

The distance of the cell centroid from the wall is given by  $y_p$  while the height of the cell ( $y_H$ ) is double  $y_p$ .

$$y_H = 2y_p \quad (7)$$

Most mesh generators give the user control over the node spacing normal to the wall. Hence, the overall size of the cell ( $y_H$ ) is a more useful output from this calculator, as the size of the cell is equal to the node spacing.  $y_H$  can be used directly in the mesh generator.

Having created an initial mesh, an initial CFD analysis should be carried out with this mesh. The first cell height calculated with this calculator is **only an estimate** and will need to be updated using information from this initial CFD analysis. For example, if you were targeting  $y^+ = 1$  and the initial CFD analysis showed  $y^+ = 2.2$ , then you would need to reduce your cell height by a factor of  $\sim 2.2$  for your real calculations.

The first cell height calculated with this calculator is only an estimate because the equation for the skin friction coefficient is an empirical correlation for a specific flow scenario (turbulent flow over a flat plate without an applied pressure gradient). Real CFD calculations which use a different geometry are likely to have a similar skin friction coefficient to a flat plate, but not the same. Hence, the calculator can only be an estimate at best.

## Growth Ratio

In addition to calculating the size of the first cell ( $y_H$ ), most mesh generators require a growth ratio ( $r$ ) to be specified normal to the wall. This allows the layers to inflate (grow) normal to the wall.

When constructing the mesh, it is conventional in CFD to aim for a number of cells through the thickness of the boundary layer. For aerodynamic flows using Reynolds-averaged Navier-Stokes (RANS) turbulence modelling, CFD engineers often aim for 15 - 30 inflation layers ( $N = 15 - 30$ ) through the thickness of the boundary layer. We can use this criteria to calculate a maximum growth ratio normal to the wall.

Start by using empirical correlations to estimate the boundary layer thickness  $\delta_{99}$ . If the flow is laminar, then the Blasius solution gives:

$$\delta_{99} = \frac{4.91L}{\sqrt{Re_L}} \quad Re < 5 \times 10^5 \quad (8)$$

Conversely, if the flow is turbulent then an alternative correlation is used:

$$\delta_{99} = \frac{0.38L}{Re_L^{1/5}} \quad Re > 5 \times 10^5 \quad (9)$$

This correlation has been taken from Cengel & Cimbala (2006, Section 10.6).

The next stage in the calculation is to calculate the total thickness of the inflation layers ( $y_T$ ), for a given number of layers  $N$  and growth ratio  $r$ . We can then match this to the boundary layer thickness  $\delta_{99}$  to allow the inflation layers to cover the boundary layer thickness.

The growth ratio  $r$  is the ratio between the height of two consecutive cells. As the cells get larger as we move away from the wall  $r > 1$ . We can write the total thickness of the first two inflation layers as:

$$y_T = y_H + y_H r \quad (10)$$

Using the same logic, the total thickness of the first three inflation layers is:

$$y_T = y_H + y_H r + y_H r^2 \quad (11)$$

It follows that the total thickness of  $N$  inflation layers is:

$$y_T = y_H + y_H r + y_H r^2 + y_H r^3 + \dots + y_H r^{N-1} \quad (12)$$

This can be written concisely with summation notation:

$$y_T = \sum_{k=0}^{N-1} y_H r^k \quad (13)$$

This is the formula of a *geometric series*. It is convenient to re-write the geometric series using the identity:

$$\sum_{k=0}^{N-1} y_H r^k = y_H \frac{1 - r^N}{1 - r} \quad (14)$$

You can find this identity on *Wikipedia* or in any mathematics textbook. Hence, the total height of the inflation layers is:

$$y_T = y_H \left( \frac{1 - r^N}{1 - r} \right) \quad (15)$$

We would like the total height of the inflation layers to be equal to (or greater than) the thickness of the boundary layer  $\delta_{99}$ .

$$\delta_{99} = y_H \left( \frac{1 - r^N}{1 - r} \right) \quad (16)$$

It is difficult to solve this equation directly for the required growth ratio  $r$ . A numerical solution is more straightforward. If we estimate what the growth ratio  $r$  should be, then the error in this guess is:

$$\text{err} = y_H \left( \frac{1 - r^N}{1 - r} \right) - \delta_{99} \quad (17)$$

We can write the error as a function of growth ratio  $r$ :

$$f(r) = y_H \left( \frac{1 - r^N}{1 - r} \right) - \delta_{99} \quad (18)$$

The growth ratio which results in an error of  $f(r) = 0$ , is the growth ratio that has the total height of the inflation layers equal the boundary layer thickness. Hence, we can use a root finding algorithm to solve the equation:

$$f(r) = 0 \quad (19)$$

The bisection method or Newton-Raphson root finding algorithms could be used here. We know that the growth ratio ( $r$ ) must be great than 1, and is most likely to be less than 2.0. Hence, we can use initial guesses of 1.01 and 2.0 to bound the root in the root finding algorithm.

Once the root finding algorithm has converged, the solution ( $r$ ) is the maximum growth ratio that will result in the inflation layers being equal to the boundary layer thickness. In reality, the user will normally specify a growth ratio less than this, to ensure that the boundary layer thickness is within the inflation layers.

## Final Layer Thickness

When applying inflation layers, it is desirable that the transition from the final inflation layer to the freestream mesh does not lead to a significant change in cell volume. This is particularly important for Large Eddy Simulation (LES), as the sub-grid viscosity is proportional to the cell volume. Hence, sudden changes in cell volume result in sudden changes in sub-grid viscosity, which can lead to inaccuracies and instability.

To make an assessment of the change in cell volume from the inflation layers to the freestream mesh, a simple approach is to compare the thickness of the final inflation layer with the length scale of the freestream mesh. The final layer thickness is:

$$y_{\text{Final}} = y_H r^{N-1} \quad (20)$$

This calculation is carried out at the end, as it requires the growth ratio  $r$  (which was computed in the previous section).

## Mesh Quality

It should be emphasised that **these criteria alone (first cell height, growth ratio, final layer height) are not sufficient** to determine if a mesh is suitable for CFD analysis. The user will also need to check the mesh quality metrics and overall level of resolution in regions of high gradient, to ensure that the mesh is sufficient. These criteria will vary on a case-by-case basis and should be considered carefully by the user.

## References

1. H. Schlichting and K. Gersten *Boundary-layer Theory*, ISBN 0-07-055334-3, 7th Edition, 1979.
2. Y. Cengel and J. Cimbala *Fluid Mechanics : Fundamentals and Applications*, ISBN 0-07-247236-7, McGraw-Hill Education, 2006.
3. Wikipedia, *Geometric Series*, Accessed 2021.

### 3 Inlet Turbulence Conditions Calculator

Start by calculating the turbulent kinetic energy ( $k$ ) from the turbulence intensity ( $I$ ) and the inlet velocity ( $U$ ):

$$k = \frac{3}{2} U^2 I^2 \quad (21)$$

Next the user needs to specify the length scale ( $l$ ) of the turbulence at the inlet. For an internal pipe flow, this is usually  $\sim 10\%$  of the pipe diameter. For external flows the length-scale is likely to be significantly different and an appropriate value should be chosen carefully, depending on the ambient conditions.

Using the turbulent length-scale ( $l$ ), the turbulent dissipation rate ( $\epsilon$ ) is calculated next.  $C_\mu = 0.09$  is a model coefficient of the  $k - \epsilon$  and  $k - \omega$  turbulence models.

$$\epsilon = C_\mu \frac{k^{3/2}}{l} \quad (22)$$

From the definition of the specific dissipation rate,  $\omega$  is calculated next.

$$\omega = \frac{\epsilon}{C_\mu k} \quad (23)$$

Finally, the kinematic viscosity is computed:

$$\nu_t = \frac{k}{\omega} \quad (24)$$

## 4 Particle Settling Velocity Calculator

Start with an initial guess for the settling velocity of the particle ( $U$ ), by taking Stokes solution for the terminal settling velocity of a spherical particle falling in a viscous fluid.

$$U = \frac{gD^2}{18\mu}(\rho_p - \rho_f) \quad (25)$$

where  $g$  is the acceleration due to gravity ( $9.81 \text{ m/s}^2$ ),  $D$  is the diameter of the particle,  $\mu$  is the dynamic viscosity of the fluid,  $\rho_p$  is the density of the particle and  $\rho_f$  is the density of the fluid.

However, Stokes solution is only valid for  $Re < 1$ . Hence, evaluate the particle Reynolds number ( $Re$ ) next:

$$Re = \frac{\rho UD}{\mu} \quad (26)$$

With the particle Reynolds number, we can evaluate the actual drag coefficient of the particle using the Schiller-Naumann empirical model.

$$C_D = \begin{cases} \frac{24}{Re} (1 + 0.15Re^{0.687}) & Re < 1000 \\ 0.44 & Re > 1000 \end{cases} \quad (27)$$

Now that the drag coefficient has been calculated, an updated guess can be made for the particle settling velocity. To simplify the iteration process, define a drag function  $f$ :

$$f = \frac{C_D Re}{24} \quad (28)$$

With the drag function computed, update the settling velocity using a modified form of Stokes solution:

$$U = \frac{gD^2}{18\mu f}(\rho_p - \rho_f) \quad (29)$$

Now continue to iterate, by calculating the particle Reynolds number, the drag function and the settling velocity until converged. Use under-relaxation for stability.



## 5 Humidity Calculator

Start by calculating the saturated vapour pressure ( $P_g$ ) using the Arden-Buck equation. Note that the temperature ( $T$ ) is in  $^{\circ}\text{C}$  (not Kelvin) and the calculated vapour pressure is in kPa.

$$P_g = \begin{cases} 0.61121 \exp \left[ \left( 18.678 - \frac{T}{234.5} \right) * \left( \frac{T}{T+257.14} \right) \right] & T > 0^{\circ}\text{C} \\ 0.61121 \exp \left[ \left( 23.036 - \frac{T}{333.7} \right) * \left( \frac{T}{T+279.82} \right) \right] & T < 0^{\circ}\text{C} \end{cases} \quad (30)$$

Now calculate the partial pressure of the water vapour ( $P_{H20}$ ) in the air-water vapour mixture, by rearranging the definition of the relative humidity ( $\phi$ ):

$$\phi = \frac{P_{H20}}{P_g} \quad (31)$$

$$P_{H20} = \phi P_g \quad (32)$$

Next, calculate the specific humidity ( $\omega$ ), which is defined as the ratio of the mass of water-vapour to the mass of dry air:

$$\omega = \frac{m_{H20}}{m_{air}} \quad (33)$$

$$\omega = \frac{M_{H20}}{M_{Air}} \left( \frac{P_{H20}}{P - P_{H20}} \right) \quad (34)$$

**NOTE:** This equation can be derived by applying the ideal gas law to the dry air and water vapour individually. ( $V$ ) is the gas volume, ( $R_{Air}$ ) is the specific gas constant for air, ( $R_U$ ) is the universal gas constant and ( $M_{Air}$ ) is the molar mass of air.

$$P_{Air} V = m_{Air} R_{Air} T \quad (35)$$

$$P_{H20} V = m_{H20} R_{H20} T \quad (36)$$

$$\omega = \frac{m_{H20}}{m_{Air}} \quad (37)$$

$$\omega = \frac{R_{Air} P_{H20}}{R_{H20} P_{Air}} \quad (38)$$

$$\omega = \frac{(R_U/M_{Air}) P_{H20}}{(R_U/M_{H20}) P_{Air}} \quad (39)$$

Apply Dalton's Law of partial pressures:

$$P = P_{Air} + P_{H20} \quad (40)$$

$$\omega = \frac{M_{H20}}{M_{Air}} \left( \frac{P_{H20}}{P - P_{H20}} \right) \quad (41)$$

Finally, compute the absolute humidity ( $\varphi$ ) from the specific humidity. The absolute humidity is defined as the mass of water vapour per unit mass of air-water vapour mixture.

$$\varphi = \frac{m_{H20}}{m_{Air} + m_{H20}} \quad (42)$$

$$\varphi = \frac{m_{H20}/m_{Air}}{1 + m_{H20}/m_{Air}} \quad (43)$$

$$\varphi = \frac{\omega}{1 + \omega} \quad (44)$$

The mass-fraction of water vapour ( $Y_{H20}$ ) in the CFD computations is equivalent to the absolute humidity. Apply this at the inlet to the CFD computations:

$$Y_{H20} = \varphi \quad (45)$$

## References

1. Buck, A. L. (1981), 'New equations for computing vapor pressure and enhancement factor, J. Appl. Meteorol., 20: 1527–1532
2. Buck, A. L. (2012), Model CR-1A Hygrometer with autofill operating manual, Buck Research Instruments, LLC.